



IEI Technology Corp.

**MODEL:  
ICE-PV-N4551/D525**



**COM Express Module (Type 2)  
Intel® ATOM™ CPU  
RoHS Compliant**

# User Manual

Rev. 1.02 – 3 April, 2012



# Revision

Date	Version	Changes
3 April, 2012	1.02	Minor correction to Table 3-1: ICE-PV-N4551/D5251 Interface Connectors and Section 3.2 Peripheral Interface Connectors
14 February, 2012	1.01	Minor correction to Table 3-3: COM Express Connector AB Pin Definitions and Section 1.5 Technical Specifications
27 September, 2011	1.00	Initial release

# Copyright

## COPYRIGHT NOTICE

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

## TRADEMARKS

All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

# Packing List



## NOTE:

If any of the components listed in the checklist below are missing, please do not proceed with the installation. Contact the IEI reseller or vendor you purchased the ICE-PV-N4551/D5251 from or contact an IEI sales representative directly. To contact an IEI sales representative, please send an email to [sales@iei.com.tw](mailto:sales@iei.com.tw)

The items listed below should all be included in the ICE-PV-N4551/D5251 package.

- 1 x ICE-PV-N4551/D5251
- 1 x Heatspreader
- 1 x Utility CD
- 1 x QIG (quick installation guide)

Images of the above items are shown in **Chapter 3**.

# Table of Contents

<b>1 INTRODUCTION.....</b>	<b>1</b>
1.1 OVERVIEW.....	2
<i>1.1.1 Applications .....</i>	2
<i>1.1.2 Benefits.....</i>	3
<i>1.1.3 Features .....</i>	3
1.2 DIMENSIONS.....	4
<i>1.2.1 Top View .....</i>	4
<i>1.2.2 Side View .....</i>	5
1.3 DATA FLOW .....	6
1.4 CONNECTORS .....	7
<i>1.4.1 IO Interface Support .....</i>	8
1.5 TECHNICAL SPECIFICATIONS .....	9
<b>2 UNPACKING .....</b>	<b>11</b>
2.1 ANTI-STATIC PRECAUTIONS .....	12
2.2 UNPACKING.....	12
<i>2.2.1 Unpacking Precautions.....</i>	12
2.3 UNPACKING CHECKLIST .....	13
<i>2.3.1 Package Contents.....</i>	13
<b>3 CONNECTORS .....</b>	<b>15</b>
3.1 PERIPHERAL INTERFACE CONNECTORS.....	16
<i>3.1.1 ICE-PV-N4551/D5251 Layout.....</i>	16
<i>3.1.2 Peripheral Interface Connectors .....</i>	17
3.2 PERIPHERAL INTERFACE CONNECTORS.....	18
<i>3.2.1 COM Express Connector CD.....</i>	18
<i>3.2.2 COM Express Connector AB .....</i>	22
<i>3.2.3 SO-DIMM Connector.....</i>	27
<i>3.2.4 SPI Connector.....</i>	27
<b>4 INSTALLATION .....</b>	<b>30</b>

4.1 INSTALLATION CONSIDERATIONS.....	31
4.2 UNPACKING.....	32
4.2.1 <i>Unpacking Precautions</i> .....	32
4.2.2 <i>Checklist</i> .....	32
4.3 SO-DIMM INSTALLATION .....	33
4.4 JUMPER SETTINGS .....	34
4.4.1 <i>LVDS Panel Resolution</i> .....	35
4.5 MOUNTING THE ICE-PV-N4551/D5251 .....	35
<b>5 BIOS SETUP .....</b>	<b>37</b>
5.1 INTRODUCTION.....	38
5.1.1 <i>Starting Setup</i> .....	38
5.1.2 <i>Using Setup</i> .....	38
5.1.3 <i>Getting Help</i> .....	39
5.1.4 <i>Unable to Reboot After Configuration Changes</i> .....	39
5.1.5 <i>BIOS Menu Bar</i> .....	39
5.2 MAIN.....	40
5.3 ADVANCED .....	41
5.3.1 <i>ACPI Settings</i> .....	42
5.3.2 <i>CPU Configuration</i> .....	43
5.3.3 <i>IDE Configuration</i> .....	45
5.3.4 <i>USB Configuration</i> .....	46
5.3.5 <i>F75387 HardWare Monitor</i> .....	47
5.3.6 <i>Secondary Super IO Configuration</i> .....	49
5.3.6.1 <i>COM 3 Configuration</i> .....	49
5.3.6.2 <i>COM 4 Configuration</i> .....	50
5.3.6.3 <i>COM 5 Configuration</i> .....	51
5.3.6.4 <i>COM 6 Configuration</i> .....	52
5.3.7 <i>Super IO Configuration</i> .....	53
5.3.7.1 <i>Floppy Disk Controller Configuration</i> .....	53
5.3.7.2 <i>COM 1 Configuration</i> .....	54
5.3.7.3 <i>COM 2 Configuration</i> .....	55
5.3.7.4 <i>Parallel Port Configuration</i> .....	56
5.3.8 <i>WinBond W83627EHG HardWare Monitor</i> .....	57
5.3.9 <i>Serial Port Console Redirection</i> .....	59

5.4 CHIPSET .....	60
<i>5.4.1 Host Bridge Configuration .....</i>	<i>61</i>
<i>5.4.2 South Bridge Configuration.....</i>	<i>63</i>
<i>5.4.3 Intel IGD SWSCI OpRegion.....</i>	<i>64</i>
5.5 BOOT.....	66
5.6 SECURITY.....	67
5.7 EXIT .....	68
<b>6 SOFTWARE INSTALLATION .....</b>	<b>70</b>
6.1 AVAILABLE SOFTWARE DRIVERS .....	71
6.2 STARTING THE DRIVER PROGRAM .....	71
<b>A BIOS OPTIONS .....</b>	<b>74</b>
<b>B TERMINOLOGY.....</b>	<b>77</b>
<b>C WATCHDOG TIMER .....</b>	<b>81</b>
<b>D HAZARDOUS MATERIALS DISCLOSURE .....</b>	<b>84</b>
D.1 HAZARDOUS MATERIALS DISCLOSURE TABLE FOR IPB PRODUCTS CERTIFIED AS RoHS COMPLIANT UNDER 2002/95/EC WITHOUT MERCURY .....	85

# List of Figures

---

Figure 1-1: ICE-PV-N4551/D5251 .....	2
Figure 1-2: Front View (mm) .....	4
Figure 1-3: Side Dimensions (mm) .....	5
Figure 1-4: Data Flow Block Diagram .....	6
Figure 1-5: ICE-PV-N4551/D5251 Overview (Front Side) .....	7
Figure 1-6: ICE-PV-N4551/D5251 Overview (Reverse Side) .....	8
Figure 3-1: Connector and Jumper Locations (Front Side) .....	16
Figure 3-2: Connector and Jumper Locations (Back Side) .....	17
Figure 3-3: COM Express Connector CD Location .....	18
Figure 3-4: COM Express Connector AB Location .....	23
Figure 3-5: SO-DIMM Connector Location .....	27
Figure 3-6: SPI Flash Connector Location .....	28
Figure 4-1: SO-DIMM Installation .....	33
Figure 4-2: Jumper Locations .....	34
Figure 6-1: Start Up Screen .....	72
Figure 6-2: Drivers .....	73

# List of Tables

---

Table 1-1: Technical Specifications.....	10
Table 2-1: Package List Contents .....	14
Table 3-1: ICE-PV-N4551/D5251 Interface Connectors .....	17
Table 3-2: COM Express Connector CD Pin Definitions.....	22
Table 3-3: COM Express Connector AB Pin Definitions.....	27
Table 3-4: SPI Flash Connector Pin Definitions .....	29
Table 4-1: Jumpers .....	34
Table 4-2: LVDS Panel Resolution.....	35
Table 5-1: BIOS Navigation Keys .....	39

# BIOS Menus

---

BIOS Menu 1: Main .....	40
BIOS Menu 2: Advanced .....	42
BIOS Menu 3: ACPI Settings .....	42
BIOS Menu 4: CPU Configuration .....	43
BIOS Menu 5: IDE Configuration.....	45
BIOS Menu 6: USB Configuration .....	46
BIOS Menu 7: F75387 HardWare Monitor.....	48
BIOS Menu 8: Secondary Super IO Configuration .....	49
BIOS Menu 9: Chipset .....	53
BIOS Menu 10: F75387 HardWare Monitor.....	58
BIOS Menu 11: Chipset .....	59
BIOS Menu 12: Chipset .....	61
BIOS Menu 13: Host Bridge Chipset Configuration.....	61
BIOS Menu 14:South Bridge Chipset Configuration.....	63
BIOS Menu 15: Intel IGD SWSCI OpRegion .....	64
BIOS Menu 16: Boot .....	66
BIOS Menu 17: Security .....	67
BIOS Menu 18: Exit.....	68

Chapter

1

# Introduction

---

## 1.1 Overview



**Figure 1–1: ICE-PV-N4551/D5251**

The ICE-PV-N4551/D5251 COM Express module provides the main processing chips and is connected to a compatible COM Express carrier board. The ICE-PV-N4551/D5251 is equipped with an Intel® Atom™ N455/D525 CPU, Intel® Atom™ N455/D525 Northbridge and Intel® ICH8M Southbridge and provides multiple modern serial I/O options, while offering limited support for legacy I/Os. The COM Express standard allows the COM Express carrier board to be designed, while leaving the choice of processor till the later stages of design. The ICE-PV-N4551/D5251 provides a low power option with the full range of modern I/O options. The ICE-PV-N4551/D5251 embedded module is designed for flexible integration by system developers into customized platform devices.

### 1.1.1 Applications

The ICE-PV-N4551/D5251 is designed to a COM Express carrier board for being embedded in customized baseboards for flexible applications.

## ICE-PV-N4551\_D5251 COM Express Type 2 Module

### 1.1.2 Benefits

Some of the ICE-PV-N4551/D5251 embedded platform benefits include:

- Low power, high performance
- Easy integration into customized baseboards
- Easy upgrading
- Easy maintenance
- Easy design compatibility
- Low cost product development

### 1.1.3 Features

Some of the ICE-PV-N4551/D5251 features are listed below:

- Complies with COM Express form factor
- Complies with RoHS
- Embedded Intel® Atom™ N455/D525 CPU
- Supports up to 2 GB of 800 MHz DDR3 SDRAM SO-DIMM
- Comes with a high performance gigabit Ethernet (GbE) controller
- Support for eight USB 2.0 devices
- Support for one IDE device

## 1.2 Dimensions

The dimensions of the board are listed below:

- **Length:** 95 mm
- **Width:** 95 mm

### 1.2.1 Top View

The figure below shows the dimensions from the top view.




Figure 1-2: Front View (mm)

### 1.2.2 Side View

The figure below shows the dimensions as viewed from the side.




Figure 1-3: Side Dimensions (mm)

## 1.3 Data Flow

Figure 1-4 shows the data flow between the two on-board chipsets and other components installed on the motherboard and described in the following sections of this chapter.




Figure 1-4: Data Flow Block Diagram

## 1.4 Connectors

The ICE-PV-N4551/D5251 embedded module has the following connectors as seen in **Figure 1-5** and **Figure 1-6**.




Figure 1-5: ICE-PV-N4551/D5251 Overview (Front Side)




Figure 1-6: ICE-PV-N4551/D5251 Overview (Reverse Side)

#### 1.4.1 IO Interface Support

The ICE-PV-N4551/D5251 embedded module supports the following IO interfaces on the baseboard:

- 1 x IDE channel (signal to base board)
- 3 x SATA 3Gb/s (to base board)
- 8 x USB 2.0 (to base board)
- 5 x PCIe x1
- 4 x PCI
- 1 x GbE

## ICE-PV-N4551\_D5251 COM Express Type 2 Module

- HD Audio (through HD audio chip on the baseboard, connected to HD audio interface on the ICE-PV-N4551/D5251)
- Legacy ports (COM, LPT, BIOS, and PS/2) through super I/O on the baseboard connected to the LPC interface on the ICE-PV-N4551/D5251.

### 1.5 Technical Specifications

ICE-PV-N4551/D5251 technical specifications are listed in **Table 1-1**. Detailed descriptions of each specification can be found in the detailed specifications chapter.

Specification	Value
<b>CPUs Supported</b>	Intel® Atom™ N455/D525
<b>System Chipset</b>	Intel® ICH8M
<b>Ethernet</b>	Intel® 82567V GbE
<b>Memory</b>	One 204-pin 800MHz DDR3 SDRAM SO-DIMM up to 2.0 GB supported
<b>Graphic Chipset</b>	GMA 3150 Graphic core speed 400MHz for D525 Graphic core speed 200MHz for N455
<b>Display</b>	Analog CRT (VGA) integrated in Intel® N455/D525 (signal to base board) 18-bit single-channel LVDS (signal to base board)
<b>I/O Interfaces</b>	8 x USB 2.0 3 x SATA 3Gb/s 1 x IDE 1 x GbE
<b>Expansion</b>	5 x PCIe x1 4 x PCI (32-bit, 33 MHz)
<b>BIOS</b>	UEFI
<b>Power Support</b>	12V only, AT/ATX power supported
<b>Power Consumption</b>	12V @ 1.25A (Intel® Atom™ D525 1.8GHz with DDR3 1GB)

Specification	Value
<b>Watchdog Timer</b>	Software programmable supports 1~255 sec. system reset
<b>Physical Dimensions</b>	95 mm x 95 mm
<b>Weight</b>	GW: 600 g NW: 200 g
<b>Operating Temperature</b>	-20°C ~ 60°C with free air, -20°C ~ 70°C with force air for D525 processor -20°C ~ 70°C with free air, -20°C ~ 75°C with force air for N455 processor
<b>Humidity</b>	Operation: 5% ~ 95%, non-condensing

**Table 1-1: Technical Specifications**

Chapter

2

# Unpacking

---

## 2.1 Anti-static Precautions



### WARNING:

Failure to take ESD precautions during the installation of the ICE-PV-N4551/D5251 may result in permanent damage to the ICE-PV-N4551/D5251 and severe injury to the user.

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the ICE-PV-N4551/D5251. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the ICE-PV-N4551/D5251 or any other electrical component is handled, the following anti-static precautions are strictly adhered to.

- ***Wear an anti-static wristband:*** Wearing a simple anti-static wristband can help to prevent ESD from damaging the board.
- ***Self-grounding:*** Before handling the board, touch any grounded conducting material. During the time the board is handled, frequently touch any conducting materials that are connected to the ground.
- ***Use an anti-static pad:*** When configuring the ICE-PV-N4551/D5251, place it on an anti-static pad. This reduces the possibility of ESD damaging the ICE-PV-N4551/D5251.
- ***Only handle the edges of the PCB:*** When handling the PCB, hold the PCB by the edges.

## 2.2 Unpacking

### 2.2.1 Unpacking Precautions

When the ICE-PV-N4551/D5251 is unpacked, please do the following:

- Follow the anti-static precautions outlined in **Section 2.1**.
- Make sure the packing box is facing upwards so the ICE-PV-N4551/D5251 does not fall out of the box.
- Make sure all the components shown in **Section 2.3** are present.

## 2.3 Unpacking Checklist



### NOTE:

If some of the components listed in the checklist below are missing, please do not proceed with the installation. Contact the IEI reseller or vendor you purchased the ICE-PV-N4551/D5251 from or contact an IEI sales representative directly. To contact an IEI sales representative, please send an email to [sales@iei.com.tw](mailto:sales@iei.com.tw).

### 2.3.1 Package Contents

The ICE-PV-N4551/D5251 is shipped with the following components:

Quantity	Item	Image
1	ICE-PV-N4551/D5251	
1	Heatspreader	
1	Quick Installation Guide	

Quantity	Item	Image
1	Utility CD	

Table 2-1: Package List Contents

Chapter

3

# Connectors

---

### 3.1 Peripheral Interface Connectors

**Section 3.1.1** shows interface connector locations. **Section 3.1.2** lists all the interface connectors seen in **Section 3.1.1**.

#### 3.1.1 ICE-PV-N4551/D5251 Layout

**Figure 3-1** shows the on-board peripheral connectors, backplane peripheral connectors and on-board jumpers.




Figure 3-1: Connector and Jumper Locations (Front Side)




Figure 3-2: Connector and Jumper Locations (Back Side)

### 3.1.2 Peripheral Interface Connectors

Table 3-1 shows a list of the interface connectors on the ICE-PV-N4551/D5251. Detailed descriptions of these connectors can be found in **Section 3.2**.

Connector	Type	Label
COM Express connector CD	COM Express connector	J4
COM Express connector AB	COM Express connector	J3
SO-DIMM socket	SO-DIMM socket	DIMM1
SPI programming connector	6-pin connector	SPI1

Table 3-1: ICE-PV-N4551/D5251 Interface Connectors

## 3.2 Peripheral Interface Connectors

The location of the pins and the pinout descriptions of the peripheral interface connectors are given below.

### 3.2.1 COM Express Connector CD

**CN Label:** J4

**CN Type:** 220-pin COM Express connector

**CN Location:** See **Figure 3-3**

**CN Pinouts:** See **Table 3-2**

The standard COM Express connector locations and pinouts are shown below.




Figure 3-3: COM Express Connector CD Location

**ICE-PV-N4551\_D5251 COM Express Type 2 Module**

Pin No.	Description	Pin No.	Description
C1	GND	D1	GND
C2	IDE_D7	D2	IDE_D5
C3	IDE_D6	D3	IDE_D10
C4	IDE_D3	D4	IDE_D11
C5	IDE_D15	D5	IDE_D12
C6	IDE_D8	D6	IDE_D4
C7	IDE_D9	D7	IDE_D0
C8	IDE_D2	D8	IDE_REQ
C9	IDE_D13	D9	IDE_IOW#
C10	IDE_D1	D10	IDE_ACK#
C11	GND	D11	GND
C12	IDE_D14	D12	IDE_IRQ
C13	IDE_IORDY	D13	IDE_A0
C14	IDE_IOR#	D14	IDE_A1
C15	PCI_PME#	D15	IDE_A2
C16	PCI_GNT2#	D16	IDE_CS1#
C17	PCI_REQ2#	D17	IDE_CS3#
C18	PCI_GNT1#	D18	IDE_RESET#
C19	PCI_REQ1#	D19	PCI_GNT3#
C20	PCI_GNT0#	D20	PCI_REQ3#
C21	GND	D21	GND
C22	PCI_REQ0#	D22	PCI_AD1
C23	PCI_RESET#	D23	PCI_AD3
C24	PCI_AD0	D24	PCI_AD5
C25	PCI_AD2	D25	PCI_AD7
C26	PCI_AD4	D26	PCI_C/BEO#
C27	PCI_AD6	D27	PCI_AD9
C28	PCI_AD8	D28	PCI_AD11
C29	PCI_AD10	D29	PCI_AD13
C30	PCI_AD12	D30	PCI_AD15
C31	GND	D31	GND
C32	PCI_AD14	D32	PCI_PAR

<b>Pin No.</b>	<b>Description</b>	<b>Pin No.</b>	<b>Description</b>
C33	PCI_C/BE1#	D33	PCI_SERR#
C34	PCI_PERR#	D34	PCI_STOP#
C35	PCI_LOCK#	D35	PCI_TRDY#
C36	PCI_DEVSEL#	D36	PCI_FRAME#
C37	PCI_IRDY#	D37	PCI_AD16
C38	PCI_C/BE2#	D38	PCI_AD18
C39	PCI_AD17	D39	PCI_AD20
C40	PCI_AD19	D40	PCI_AD22
C41	GND	D41	GND
C42	PCI_AD21	D42	PCI_AD24
C43	PCI_AD23	D43	PCI_AD26
C44	PCI_C/BE3#	D44	PCI_AD28
C45	PCI_AD25	D45	PCI_AD30
C46	PCI_AD27	D46	PCI IRQC#
C47	PCI_AD29	D47	PCI IRQD#
C48	PCI_AD31	D48	PCI_CLKRUN#
C49	PCI_IRQA#	D49	PCI_M66EN
C50	PCI_IROB#	D50	PCI_CLK
C51	GND	D51	GND
C52	PEG_RX0+	D52	PEG_TX0+
C53	PEG_RX0-	D53	PEG_TX0-
C54	TYPE0#	D54	PEG_LANE_RV#
C55	PEG_RX1+	D55	PEG_TX1+
C56	PEG_RX1-	D56	PEG_TX1-
C57	TYPE1#	D57	TYPE2#
C58	PEG_RX2+	D58	PEG_TX2+
C59	PEG_RX2-	D59	PEG_TX2-
C60	GND	D60	GND
C61	PEG_RX3+	D61	PEG_TX3+
C62	PEG_RX3-	D62	PEG_TX3-
C63	RSVD	D63	RSVD
C64	RSVD	D64	RSVD

**ICE-PV-N4551\_D5251 COM Express Type 2 Module**

Pin No.	Description	Pin No.	Description
C65	PEG_RX4+	D65	PEG_TX4+
C66	PEG_RX4-	D66	PEG_TX4-
C67	FAN_PWMOUT	D67	GND
C68	PEG_RX5+	D68	PEG_TX5+
C69	PEG_RX5-	D69	PEG_TX5-
C70	GND	D70	GND
C71	PEG_RX6+	D71	PEG_TX6+
C72	PEG_RX6-	D72	PEG_TX6-
C73	SDVO_DATA	D73	SVDO_CLK
C74	PEG_RX7+	D74	PEG_TX7+
C75	PEG_RX7-	D75	PEG_TX7-
C76	GND	D76	GND
C77	FAN_TACHOIN	D77	IDE_CBLID#
C78	PEG_RX8+	D78	PEG_TX8+
C79	PEG_RX8-	D79	PEG_TX8-
C80	GND	D80	GND
C81	PEG_RX9+	D81	PEG_TX9+
C82	PEG_RX9-	D82	PEG_TX9-
C83	RSVD	D83	RSVD
C84	GND	D84	GND
C85	PEG_RX10+	D85	PEG_TX10+
C86	PEG_RX10-	D86	PEG_TX10-
C87	GND	D87	GND
C88	PEG_RX11+	D88	PEG_TX11+
C89	PEG_RX11-	D89	PEG_TX11-
C90	GND	D90	GND
C91	PEG_RX12+	D91	PEG_TX12+
C92	PEG_RX12-	D92	PEG_TX12-
C93	GND	D93	GND
C94	PEG_RX13+	D94	PEG_TX13+
C95	PEG_RX13-	D95	PEG_TX13-
C96	GND	D96	GND

Pin No.	Description	Pin No.	Description
C97	RSVD	D97	PEG_ENABLE#
C98	PEG_RX14+	D98	PEG_TX14+
C99	PEG_RX14-	D99	PEG_TX14-
C100	GND	D100	GND
C101	PEG_RX15+	D101	PEG_TX15+
C102	PEG_RX15-	D102	PEG_TX15-
C103	GND	D103	GND
C104	+V12	D104	+V12
C105	+V12	D105	+V12
C106	+V12	D106	+V12
C107	+V12	D107	+V12
C108	+V12	D108	+V12
C109	+V12	D109	+V12
C110	GND	D110	GND

**Table 3-2: COM Express Connector CD Pin Definitions**

### 3.2.2 COM Express Connector AB

**CN Label:** J3

**CN Type:** 220-pin COM Express connector

**CN Location:** See [Figure 3-4](#)

**CN Pinouts:** See [Table 3-3](#)

The standard COM Express connector locations and pinouts are shown below.

## ICE-PV-N4551\_D5251 COM Express Type 2 Module




Figure 3-4: COM Express Connector AB Location

Pin No.	Description	Pin No.	Description
A1	GND	B1	GND
A2	GBEO_MDI3-	B2	GBEO_ACT#
A3	GBEO_MDI3+	B3	LPC_FRAME#
A4	GBEO_LINK100#	B4	LPC_ADO
A5	GBEO_LINK1000#	B5	LPC_AD1
A6	GBEO_MDI2-	B6	LPC_AD2
A7	GBEO_MDI2+	B7	LPC_AD3
A8	GBEO_LINK#	B8	LPC_DRQ0#
A9	GBEO_MDI1-	B9	LPC_DRQ1#
A10	GBEO_MDI1+	B10	LPC_CLK
A11	GND	B11	GND
A12	GBEO_MDIO-	B12	PWRBTN#

<b>Pin No.</b>	<b>Description</b>	<b>Pin No.</b>	<b>Description</b>
A13	GBEO_MDIO+	B13	SMB_CK
A14	GBEO_CTREF	B14	SMB_DAT
A15	SUS_S3#	B15	SMB_ALERT#
A16	SATA0_TX+	B16	SATA1_TX+
A17	SATA0_TX-	B17	SATA1_TX-
A18	SUS_S4#	B18	SUS_STAT#
A19	SATA0_RX+	B19	SATA1_RX+
A20	SATA0_RX-	B20	SATA1_RX-
A21	GND	B21	GND
A22	SATA2_TX+	B22	SATA3_TX+
A23	SATA2_TX-	B23	SATA3_TX-
A24	SUS_S5#	B24	PWR_OK
A25	SATA2_RX+	B25	SATA3_RX+
A26	SATA2_RX-	B26	SATA3_RX-
A27	BATLOW#	B27	WDT
A28	ATA_ACT#	B28	AC_SDIN2
A29	AC_SYNC	B29	AC_SDIN1
A30	AC_RST#	B30	AC_SDIN0
A31	GND	B31	GND
A32	AC_BITCLK	B32	SPKR
A33	AC_SDOUT	B33	I2C_CK
A34	BIOS_DISABLE#	B34	I2C_DAT
A35	THRMTRIP#	B35	THRM#
A36	USB6-	B36	USB7-
A37	USB6+	B37	USB7+
A38	USB_6_7_OC#	B38	USB_4_5_OC#
A39	USB4-	B39	USB5-
A40	USB4+	B40	USB5+
A41	GND	B41	GND
A42	USB2-	B42	USB3-
A43	USB2+	B43	USB3+
A44	USB_2_3_OC#	B44	USB_0_1_OC#

## ICE-PV-N4551\_D5251 COM Express Type 2 Module

Pin No.	Description	Pin No.	Description
A45	USB0-	B45	USB1-
A46	USB0+	B46	USB1+
A47	VCC_RTC	B47	EXCD1_PERST#
A48	EXCD0_PERST#	B48	EXCD1_CPPE#
A49	EXCD0_CPPE#	B49	SYS_RESET#
A50	LPC_SERIRQ	B50	CB_RESET#
A51	GND	B51	GND
A52	NC	B52	NC
A53	NC	B53	NC
A54	GPIO	B54	GPO1
A55	PCIE_TX4+	B55	PCIE_RX4+
A56	PCIE_TX4-	B56	PCIE_RX4-
A57	GND	B57	GPO2
A58	PCIE_TX3+	B58	PCIE_RX3+
A59	PCIE_TX3-	B59	PCIE_RX3-
A60	GND	B60	GND
A61	PCIE_TX2+	B61	PCIE_RX2+
A62	PCIE_TX2-	B62	PCIE_RX2-
A63	GPI1	B63	GPO3
A64	PCIE_TX1+	B64	PCIE_RX1+
A65	PCIE_TX1-	B65	PCIE_RX1-
A66	GND	B66	WAKE0#
A67	GPI2	B67	WAKE1#
A68	PCIE_TX0+	B68	PCIE_RX0+
A69	PCIE_TX0-	B69	PCIE_RX0-
A70	GND	B70	GND
A71	LVDS_A0+	B71	LVDS_B0+
A72	LVDS_A0-	B72	LVDS_B0-
A73	LVDS_A1+	B73	LVDS_B1+
A74	LVDS_A1-	B74	LVDS_B1-
A75	LVDS_A2+	B75	LVDS_B2+
A76	LVDS_A2-	B76	LVDS_B2-

<b>Pin No.</b>	<b>Description</b>	<b>Pin No.</b>	<b>Description</b>
A77	LVDS_VDD_EN	B77	LVDS_B3+
A78	LVDS_A3+	B78	LVDS_B3-
A79	LVDS_A3-	B79	LVDS_BKLT_EN
A80	GND	B80	GND
A81	LVDS_A_CK+	B81	LVDS_B_CK+
A82	LVDS_A_CK-	B82	LVDS_B_CK-
A83	LVDS_I2C_CK	B83	LVDS_BKLT_CTRL
A84	LVDS_I2C_DAT	B84	5 VSB
A85	GPI3	B85	5 VSB
A86	KBD_RST#	B86	5 VSB
A87	KBD_A20GATE	B87	5 VSB
A88	PCIE0_CK_REF+	B88	RSVD
A89	PCIE0_CK_REF-	B89	VGA_RED
A90	GND	B90	GND
A91	RSVD	B91	VGA_GRN
A92	RSVD	B92	VGA_BLU
A93	GPO0	B93	VGA_HSYNC
A94	RSVD	B94	VGA_VSYNC
A95	RSVD	B95	VGA_I2C_CK
A96	GND	B96	VGA_I2C_DAT
A97	+V12	B97	TV_DAC_A
A98	+V12	B98	TV_DAC_B
A99	+V12	B99	TV_DAC_C
A100	GND	B100	GND
A101	+V12	B101	+V12
A102	+V12	B102	+V12
A103	+V12	B103	+V12
A104	+V12	B104	+V12
A105	+V12	B105	+V12
A106	+V12	B106	+V12
A107	+V12	B107	+V12
A108	+V12	B108	+V12

Pin No.	Description	Pin No.	Description
A109	+V12	B109	+V12
A110	GND	B110	GND

Table 3-3: COM Express Connector AB Pin Definitions

### 3.2.3 SO-DIMM Connector

**CN Label:** DIMM1

**CN Type:** SO-DIMM connector

**CN Location:** See **Figure 3-5**

The SO-DIMM socket is for installing SO-DIMM memory.




Figure 3-5: SO-DIMM Connector Location

### 3.2.4 SPI Connector


**CN Label:** SPI1

**CN Type:** 6-pin connector

**CN Location:** See **Figure 3-6**

**CN Pinouts:** See **Table 3-4**

The SPI connector is for flashing new BIOS onto the SPI BIOS chip.



**Figure 3-6: SPI Flash Connector Location**

Pin No.	Description
1	GND
2	SPI_MOSI
3	SPI_CLK
4	SPI_MISO
5	SPI_CS#

## ICE-PV-N4551\_D5251 COM Express Type 2 Module

Pin No.	Description
6	SPI_VCC (+3.3V)

Table 3-4: SPI Flash Connector Pin Definitions

Chapter

4

# Installation

---

## 4.1 Installation Considerations



### NOTE:

The following installation notices and installation considerations should be read and understood before the CPU module is installed. All installation notices pertaining to the installation of the CPU module should be strictly adhered to. Failing to adhere to these precautions may lead to severe damage of the CPU module and injury to the person installing the CPU module.

Before and during the installation of the ICE-PV-N4551/D5251, please do the following:

- Read the user manual
  - The user manual provides a complete description of the ICE-PV-N4551/D5251, installation instructions and configuration options.
- Wear an electrostatic discharge cuff (ESD)
  - Electronic components are easily damaged by ESD. Wearing an ESD cuff removes ESD from the body and helps prevent ESD damage.
- Place the CPU module on an antistatic pad
  - When installing or configuring the CPU module, place it on an antistatic pad. This helps to prevent potential ESD damage.
- Turn off all power to the ICE-PV-N4551/D5251
  - When working with the CPU module, make sure that it is disconnected from all power supplies and that no electricity is being fed into the system.

Before and during the installation of the ICE-PV-N4551/D5251 DO NOT:

- **DO NOT** remove any of the stickers on the PCB board. These stickers are required for warranty validation.
- **DO NOT** use the product before verifying all the cables and power connectors are properly connected.
- **DO NOT** allow screws to come in contact with the PCB circuit, connector pins, or its components.

## 4.2 Unpacking



### NOTE:

If any of the items listed below are missing when the ICE-PV-N4551/D5251 is unpacked, do not proceed with the installation and contact the ICE-PV-N4551/D5251 reseller or vendor.

### 4.2.1 Unpacking Precautions

Before installing the ICE-PV-N4551/D5251, unpack the CPU module. Some components on ICE-PV-N4551/D5251 are very sensitive to static electricity and can be damaged by a sudden rush of power. To protect it from being damaged, follow these precautions:

- The user should ground them self to remove any static charge before touching the ICE-PV-N4551/D5251. To do so wear a grounded wrist strap at all times or frequently touch any conducting materials that is connected to the ground.
- Handle the ICE-PV-N4551/D5251 by its edges. Do not touch the IC chips, leads or circuitry if not necessary.

Do not place a PCB on top of an anti-static bag. Only the inside of the bag is safe from static discharge.

### 4.2.2 Checklist


When unpacking the ICE-PV-N4551/D5251, please make sure that the package contains the following items.

- 1 x ICE-PV-N4551/D5251 embedded module
- 1 x Heatspreader
- 1 x Utility CD
- 1 x QIG

If one or more of these items are missing, please contact the reseller or vendor the ICE-PV-N4551/D5251 was purchased from and do not proceed any further with the installation.

### 4.3 SO-DIMM Installation

To install a SO-DIMM into a SO-DIMM socket, please follow the steps below and refer to **Figure 4-1**.



**Figure 4-1: SO-DIMM Installation**

**Step 1: Locate the SO-DIMM socket.** Place the ICE-PV-N4551/D5251 on an anti-static pad.

**Step 2: Align the SO-DIMM with the socket.** The SO-DIMM must be oriented in such a way that the notch in the middle of the SO-DIMM must be aligned with the plastic bridge in the socket.

**Step 3: Insert the SO-DIMM.** Push the SO-DIMM chip into the socket at an angle. (See **Figure 4-1**)

**Step 4: Open the SO-DIMM socket arms.** Gently pull the arms of the SO-DIMM socket out and push the rear of the SO-DIMM down. (See **Figure 4-1**)


**Step 5: Secure the SO-DIMM.** Release the arms on the SO-DIMM socket. They clip into place and secure the SO-DIMM in the socket.

## 4.4 Jumper Settings



### NOTE:

A jumper is a metal bridge used to close an electrical circuit. It consists of two or three metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To CLOSE/SHORT a jumper means connecting the pins of the jumper with the plastic clip and to OPEN a jumper means removing the plastic clip from a jumper.




**Jumper Locations**

Before the ICE-PV-N4551/D5251 is installed in the system, the jumpers must be set in accordance with the desired configuration. The jumpers on the ICE-PV-N4551/D5251 are listed in **Table 4-1** and shown in **Figure 4-2**.

Description	Type	Label
LVDS panel resolution	4-in-1 switch	SW1

**Table 4-1: Jumpers**



**Figure 4-2: Jumper Locations**

#### 4.4.1 LVDS Panel Resolution

- Jumper Label:** SW1  
**Jumper Type:** 4-in-1 switch  
**Jumper Settings:** See **Table 4-2**  
**Jumper Location:** See **Figure 4-2**

This switch sets the resolution of the panel attached to the LVDS output. Settings are shown in **Table 4-2**.

1-8	2-7	3-6	4-5	DESCRIPTION	VBIOS ID
OPEN	OPEN	OPEN	OPEN	640 x 480 (18-bit)	1
CLOSED	OPEN	OPEN	OPEN	800 x 480 (18-bit)	2
OPEN	CLOSED	OPEN	OPEN	800 x 600 (18-bit)	3
CLOSED	CLOSED	OPEN	OPEN	1024 x 768 (18-bit)	5
OPEN	OPEN	CLOSED	OPEN	1280 x 1024 (18-bit)	11
CLOSED	OPEN	CLOSED	OPEN	1366 x 768 (18-bit)	10
OPEN	CLOSED	CLOSED	OPEN	1280 x 800 (18-bit)	7
CLOSED	CLOSED	CLOSED	OPEN	1280 x 600 (18-bit)	15

**Table 4-2: LVDS Panel Resolution**

#### 4.5 Mounting the ICE-PV-N4551/D5251



##### **WARNING!**

Never run the embedded module without an appropriate heat sink.

**WARNING!**

Please note that the installation instructions described in this manual should be carefully followed in order to avoid damage to the CPU module components and injury to the user.

**WARNING!**

When installing electronic components onto the embedded module or installing the embedded module onto the baseboard, always take anti-static precautions in order to prevent ESD damage to the CPU module and other electronic components like the CPU and SO-DIMM module.

The ICE-PV-N4551/D5251 embedded module has two standard COM Express connectors on the reverse side. Align these COM Express connectors with the corresponding connectors on a compatible baseboard. Gently push the embedded module down to ensure the connectors are properly connected.

Baseboard can be designed by the end user, customized by IEI, or purchased from IEI. For more information visit the IEI website ([www.ieeworld.com](http://www.ieeworld.com)) or contact an IEI sales representative.

Chapter

5

# BIOS Setup

---

## 5.1 Introduction



### NOTE:

The BIOS items shown below are from an ICE-PV-N4551/D5251 installed on the ICE-DB-9S-R10 reference carrier board. The ICE-DB-9S-R10 reference carrier board is available from iEI, contact [sales@iei.com.tw](mailto:sales@iei.com.tw) or go to <http://www.ieiworld.com> for more information.

The BIOS is programmed onto the BIOS chip. The BIOS setup program allows changes to certain system settings. This chapter outlines the options that can be changed.

### 5.1.1 Starting Setup

The UEFI BIOS is activated when the computer is turned on. The setup program can be activated in one of two ways.

1. Press the **F2** key as soon as the system is turned on or
2. Press the **F2** key when the “**Press F2 to enter SETUP**” message appears on the screen.

If the message disappears before the **F2** key is pressed, restart the computer and try again.

### 5.1.2 Using Setup

Use the arrow keys to highlight items, press **ENTER** to select, use the PageUp and PageDown keys to change entries, press **F1** for help and press **Esc** to quit. Navigation keys are shown in.

Key	Function
Up arrow	Move to the item above
Down arrow	Move to the item below
Left arrow	Move to the item on the left hand side

Key	Function
Right arrow	Move to the item on the right hand side
+	Increase the numeric value or make changes
-	Decrease the numeric value or make changes
Page up	Move to the next page
Page down	Move to the previous page
Esc	Main Menu – Quit and do not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
F1	General help, only for Status Page Setup Menu and Option Page Setup Menu
F9	Load optimized defaults
F10	Save changes and Exit BIOS

Table 5-1: BIOS Navigation Keys

### 5.1.3 Getting Help

When **F1** is pressed a small help window describing the appropriate keys to use and the possible selections for the highlighted item appears. To exit the Help Window press **Esc** or the **F1** key again.

### 5.1.4 Unable to Reboot After Configuration Changes

If the computer cannot boot after changes to the system configuration is made, CMOS defaults. Use the jumper described in Chapter 4.

### 5.1.5 BIOS Menu Bar

The **menu bar** on top of the BIOS screen has the following main items:

- Main – Changes the basic system configuration.
- Advanced – Changes the advanced system settings.
- Chipset – Changes the chipset settings.
- Boot – Changes the system boot configuration.


- Security – Sets User and Supervisor Passwords.
- Save & Exit – Selects exit options and loads default settings

The following sections completely describe the configuration options found in the menu items at the top of the BIOS screen and listed above.

## 5.2 Main

The **Main** BIOS menu (**BIOS Menu 1**) appears when the **BIOS Setup** program is entered.

The **Main** menu gives an overview of the basic system information.



### BIOS Menu 1: Main

#### → BIOS Information

The **BIOS Information** lists a brief summary of the BIOS. The fields in **BIOS Information** cannot be changed. The items shown in the system overview include:

- **BIOS Vendor:** Installed BIOS vendor
- **Core Version:** Current BIOS version
- **Compliance:** Current compliance version
- **Project Version:** The board version
- **Build Date and Time:** Date the current BIOS version was made

The System Overview field also has two user configurable fields:

→ **System Date [xx/xx/xx]**

Use the **System Date** option to set the system date. Manually enter the day, month and year.

→ **System Time [xx:xx:xx]**

Use the **System Time** option to set the system time. Manually enter the hours, minutes and seconds.

### 5.3 Advanced


Use the **Advanced** menu (**BIOS Menu 2**) to configure the CPU and peripheral devices through the following sub-menus:



#### WARNING!


Setting the wrong values in the sections below may cause the system to malfunction. Make sure that the settings made are compatible with the hardware.

---

**BIOS Menu 2: Advanced**

### 5.3.1 ACPI Settings

Use the **ACPI Settings** menu (**BIOS Menu 3**) to configure the Advanced Configuration and Power Interface (ACPI) options.

**BIOS Menu 3: ACPI Settings**


→ **ACPI Sleep State [S1 (CPU Stop Clock)]**

Use the **ACPI Sleep State** option to specify the sleep state the system enters when it is not being used.

- **S1 (CPU DEFAULT Stop Clock)** The system enters S1 (POS) sleep state. The system appears off. The CPU is stopped; RAM is refreshed; the system is running in a low power mode.
- **S3 (Suspend to RAM)** The caches are flushed and the CPU is powered off. Power to the RAM is maintained. The computer returns slower to a working state, but more power is saved.

### 5.3.2 CPU Configuration

Use the **CPU Configuration** menu (**BIOS Menu 4**) to view detailed CPU specifications and configure the CPU.



#### BIOS Menu 4: CPU Configuration

The CPU Configuration menu lists the following CPU details:

- Processor Type: Lists the brand name of the CPU being used
- EMT64: Indicates if the EM64T is supported by the CPU.
- Processor Speed: Lists the CPU processing speed
- System Bus Speed: Lists the system bus speed
- Ratio Status: Lists the ratio status
- Actual Ratio: Lists the actual ratio
- Processor Stepping: Lists the CPU processing stepping
- Microcode Revision: Lists the microcode revision
- L1 Cache RAM: Lists the CPU L1 cache size
- L2 Cache RAM: Lists the CPU L2 cache size
- Processor Core: Lists the number of the processor core
- Hyper-Threading: Indicates if the Intel® HT Technology is supported by the CPU.

#### → **Hyper Threading [Enabled]**

Use the **Hyper Threading** to enable or disable the CPU hyper threading function.

- |                  |                |  |
|------------------|----------------|--|
| <b>→ Enabled</b> | <b>DEFAULT</b> | Disables the use of hyper threading technology |
| <b>→ Enabled</b> | <b>DEFAULT</b> | Enables the use of hyper threading technology  |


#### → **Intel® Virtualization Technology [Disabled]**

Use the **Intel® Virtualization Technology** option to enable or disable virtualization on the system. When combined with third party software, Intel Virtualization technology allows several OSes to run on the same system at the same time.

- |                  |                |  |       |                |
|------------------|----------------|--|-------|----------------|
| <b>→ Enabled</b> | <b>DEFAULT</b> | Disables                                 | Intel | Virtualization |
|                  |                | Technology.                              |       |                |
| <b>→ Enabled</b> |                | Enables Intel Virtualization Technology. |       |                |

### 5.3.3 IDE Configuration

Use the **IDE Configuration** menu (**BIOS Menu 5**) to change and/or set the configuration of the IDE devices installed in the system.



#### BIOS Menu 5: IDE Configuration

##### → ATA Or IDE Configurations [Enhanced]

Use the **ATA Or IDE Configurations** option to configure the ATA/IDE controller.

- **Disabled** Disables the on-board ATA/IDE controller.
- **Enhanced** **DEFAULT** Configures the on-board ATA/IDE controller to be in Enhanced mode. In this mode, IDE channels and SATA channels are separated. This mode supports up to 6 storage devices. Some legacy OS do not support this mode.

##### → Configure SATA as [IDE]


Use the **Configure SATA as** option to configure SATA devices as normal IDE devices.

- **IDE** **DEFAULT** Configures SATA devices as normal IDE device.

- AHCI      Configures SATA devices as AHCI device.

### 5.3.4 USB Configuration

Use the **USB Configuration** menu (**BIOS Menu 6**) to read USB configuration information and configure the USB settings.



#### BIOS Menu 6: USB Configuration

##### → USB Devices

The **USB Devices Enabled** field lists the USB devices that are enabled on the system

##### → USB Function [Enabled]

Use the **USB Function** BIOS option to enable or disable USB function support.

→ **Disabled**      USB function support disabled

→ **Enabled**      **DEFAULT**      USB function support enabled

##### → USB 2.0(EHCI) Support [Enabled]

Use the **USB 2.0(EHCI) Support** BIOS option to enable or disable USB 2.0 (EHCI) support.

- ➔ **Disabled** USB 2.0 (EHCI) support disabled
- ➔ **Enabled** **DEFAULT** USB 2.0 (EHCI) support enabled


#### ➔ **Legacy USB Support [Enabled]**

Use the **Legacy USB Support** BIOS option to enable USB mouse and USB keyboard support. Normally if this option is not enabled, any attached USB mouse or USB keyboard does not become available until a USB compatible operating system is fully booted with all USB drivers loaded. When this option is enabled, any attached USB mouse or USB keyboard can control the system even when there is no USB driver loaded onto the system.

- ➔ **Enabled** **DEFAULT** Legacy USB support enabled
- ➔ **Disabled** Legacy USB support disabled
- ➔ **Auto** Legacy USB support disabled if no USB devices are connected

### 5.3.5 F75387 HardWare Monitor

The F75387 HardWare Monitor menu (**BIOS Menu 7**) shows the operating temperature, fan speeds and system voltages.



### BIOS Menu 7: F75387 HardWare Monitor

#### → PC Health Status

The following system parameters and values are shown. The system parameters that are monitored are:

- CPU Temperature
- System Temperature
- FAN 3 Speed
- Vcc3
- VCORE
- 3.3V
- VBAT

#### → Temperature Source [Manual Fan]

Use the **Temperature Source** BIOS option to set the fan speed as manual or automatic.

- **Manual Fan**      **DEFAULT**      Enables manual fan speed settings.
- **Auto Fan**                  Enables auto fan speed settings.

### 5.3.6 Secondary Super IO Configuration

The **Secondary Super IO Configuration** menu (**BIOS Menu 8**) displays IO chip type and the submenus for configuring the COM ports 4-6.



**BIOS Menu 8: Secondary Super IO Configuration**

#### 5.3.6.1 COM 3 Configuration

##### → **Serial Port [Enabled]**

Use the **Serial Port** option to enable or disable the serial port.

→ **Disabled** Disable the serial port

→ **Enabled** **DEFAULT** Enable the serial port

##### → **Change Settings [Auto]**

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

→ **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.

- ➔ IO=2C0h;  
IRQ=10      Serial Port I/O port address is 2C0h and the interrupt address is IRQ10
- ➔ IO=2C0h;  
IRQ=10, 11    Serial Port I/O port address is 2C0h and the interrupt address is IRQ10, 11
- ➔ IO=2C8h;  
IRQ=10, 11    Serial Port I/O port address is 2C8h and the interrupt address is IRQ10, 11
- ➔ IO=2D0h;  
IRQ=10, 11    Serial Port I/O port address is 2D0h and the interrupt address is IRQ10, 11
- ➔ IO=2D8h;  
IRQ=10, 11    Serial Port I/O port address is 2D8h and the interrupt address is IRQ10, 11

### 5.3.6.2 COM 4 Configuration

#### ➔ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled**      Disable the serial port
- ➔ **Enabled**    **DEFAULT**    Enable the serial port

#### ➔ Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- ➔ **Auto**    **DEFAULT**    The serial port IO port address and interrupt address are automatically detected.
- ➔ IO=2C8h;  
IRQ=10      Serial Port I/O port address is 2C8h and the interrupt address is IRQ10
- ➔ IO=2C0h;  
IRQ=10, 11    Serial Port I/O port address is 2C0h and the interrupt address is IRQ10, 11
- ➔ IO=2C8h;  
IRQ=10, 11    Serial Port I/O port address is 2C8h and the interrupt address is IRQ10, 11

- ➔ IO=2D0h;  
IRQ=10, 11      Serial Port I/O port address is 2D0h and the interrupt address is IRQ10, 11
- ➔ IO=2D8h;  
IRQ=10, 11      Serial Port I/O port address is 2D8h and the interrupt address is IRQ10, 11

### 5.3.6.3 COM 5 Configuration

#### ➔ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled**      Disable the serial port
- ➔ **Enabled**      **DEFAULT**      Enable the serial port

#### ➔ Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- ➔ **Auto**      **DEFAULT**      The serial port IO port address and interrupt address are automatically detected.
- ➔ IO=2D0h;  
IRQ=10      Serial Port I/O port address is 2D0h and the interrupt address is IRQ10
- ➔ IO=2C0h;  
IRQ=10, 11      Serial Port I/O port address is 2C0h and the interrupt address is IRQ10, 11
- ➔ IO=2C8h;  
IRQ=10, 11      Serial Port I/O port address is 2C8h and the interrupt address is IRQ10, 11
- ➔ IO=2D0h;  
IRQ=10, 11      Serial Port I/O port address is 2D0h and the interrupt address is IRQ10, 11
- ➔ IO=2D8h;  
IRQ=10, 11      Serial Port I/O port address is 2D8h and the interrupt address is IRQ10, 11

### 5.3.6.4 COM 6 Configuration

#### → Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- **Disabled** Disable the serial port
- **Enabled** **DEFAULT** Enable the serial port

#### → Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.
- **IO=2D8h;  
IRQ=10** Serial Port I/O port address is 2D8h and the interrupt address is IRQ10
- **IO=2C0h;  
IRQ=10, 11** Serial Port I/O port address is 2C0h and the interrupt address is IRQ10, 11
- **IO=2C8h;  
IRQ=10, 11** Serial Port I/O port address is 2C8h and the interrupt address is IRQ10, 11
- **IO=2D0h;  
IRQ=10, 11** Serial Port I/O port address is 2D0h and the interrupt address is IRQ10, 11
- **IO=2D8h;  
IRQ=10, 11** Serial Port I/O port address is 2D8h and the interrupt address is IRQ10, 11


#### → Select RS232/422/485 [RS232]

Use the **Select RS232/422/485** option to set the serial port communications mode.

- **RS232** Sets the serial port for RS-232 communications.
- **RS422/RS485** **DEFAULT** Sets the serial port for RS422/485 communications.

### 5.3.7 Super IO Configuration

Use the **Super IO Configuration** menu (**BIOS Menu 9**) contains the submenus for changing the FDD controllers, parallel ports and serial ports.



**BIOS Menu 9: Chipset**

#### 5.3.7.1 Floppy Disk Controller Configuration

→ **Floppy Disk Controller [Enabled]**

Use the **Floppy Disk Controller** option to enable or disable the floppy disk drive.

→ **Disabled**                            Disables the floppy disk controller.

→ **Enabled      DEFAULT**            Enables the floppy disk controller.

→ **Change Settings [Auto]**

Use the **Change Settings** option to set the serial port IO and interrupt addresses.

→ **Auto      DEFAULT**                Disables the floppy disk controller.

→ **IO=3F0h;  
IRQ=6;  
DMA=2**                                Serial Port I/O port address is 3F0h, the interrupt address is IRQ6, and the DMA is 2.

→ Device Mode [Read Write]

Use the **Device Mode** option to set the floppy disk controller mode.

- **Read Write** **DEFAULT** Sets device mode to Read/Write.
- **Write Protect** Sets the device mode to Write/Protect.

### 5.3.7.2 COM 1 Configuration

→ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- **Disabled** Disable the serial port
- **Enabled** **DEFAULT** Enable the serial port

→ Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.
- **IO=3F8h; IRQ=4** Serial Port I/O port address is 3F8h and the interrupt address is IRQ4
- **IO=3F8h; IRQ=3, 4, 5, 6, 7, 10, 11, 12** Serial Port I/O port address is 3F8h and the interrupt address is IRQ3, 4, 5, 6, 7, 10, 11, 12
- **IO=2F8h; IRQ=3, 4, 5, 6, 7, 10, 11, 12** Serial Port I/O port address is 2F8h and the interrupt address is IRQ3, 4, 5, 6, 7, 10, 11, 12

- ➔ **IO=3E8h;** Serial Port I/O port address is 3E8h and the interrupt address is IRQ3, 4, 5, 6, 7, 10, 11, 12  
IRQ=3, 4,  
5, 6, 7, 10,  
11, 12
- ➔ **IO=2E8h;** Serial Port I/O port address is 2E8h and the interrupt address is IRQ3, 4, 5, 6, 7, 10, 11, 12  
IRQ=3, 4,  
5, 6, 7, 10,  
11, 12

### 5.3.7.3 COM 2 Configuration

#### ➔ **Serial Port [Enabled]**

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled** Disable the serial port
- ➔ **Enabled** **DEFAULT** Enable the serial port

#### ➔ **Select Serial or IrDA [Serial Port]**

Use the **Select Serial or IrDA** option to set the COM 2 device mode.

- ➔ **Serial Port** **DEFAULT** Enables Serial Port mode.
- ➔ **IrDA** Enables IrDA mode.

#### ➔ **Change Settings [Auto]**

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- ➔ **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.
- ➔ **IO=2F8h;** Serial Port I/O port address is 2F8h and the interrupt address is IRQ3  
IRQ=3

- **IO=3F8h;** Serial Port I/O port address is 3F8h and the interrupt address is IRQ3, 4, 5, 6, 7, 10, 11, 12  
IRQ=3, 4,  
5, 6, 7, 10,  
11, 12
- **IO=2F8h;** Serial Port I/O port address is 2F8h and the interrupt address is IRQ3, 4, 5, 6, 7, 10, 11, 12  
IRQ=3, 4,  
5, 6, 7, 10,  
11, 12
- **IO=3E8h;** Serial Port I/O port address is 3E8h and the interrupt address is IRQ3, 4, 5, 6, 7, 10, 11, 12  
IRQ=3, 4,  
5, 6, 7, 10,  
11, 12
- **IO=2E8h;** Serial Port I/O port address is 2E8h and the interrupt address is IRQ3, 4, 5, 6, 7, 10, 11, 12  
IRQ=3, 4,  
5, 6, 7, 10,  
11, 12

### 5.3.7.4 Parallel Port Configuration

#### → **Parallel Port [Enabled]**

Use the **Parallel Port** option to enable or disable the parallel port.

- **Disabled** Disable the serial port
- **Enabled** **DEFAULT** Enable the serial port

#### → **Change Settings [Auto]**

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.

- IO=378h; Serial Port I/O port address is 378h and the interrupt address is IRQ5
  - IO=378h; Serial Port I/O port address is 378h and the interrupt address is IRQ5, 6, 7, 10, 11, 12
  - IO=278h; Serial Port I/O port address is 278h and the interrupt address is IRQ5, 6, 7, 10, 11, 12
  - IO=3BCh; Serial Port I/O port address is 3BCh and the interrupt address is IRQ5, 6, 7, 10, 11, 12

## → Device Mode [Printer Mode]

Use the **Device Mode** option to select the mode the parallel port operates in. Configuration options are listed below.

- Printer Mode
  - SPP Mode
  - EPP-1.9 and SPP Mode
  - EPP-1.7 and SPP Mode
  - ECP Mode
  - ECP and EPP 1.9 Mode
  - ECP and EPP 1.7 Mode

### **5.3.8 WinBond W83627EHG HardWare Monitor**

The **WinBond W83627EHG HardWare Monitor** menu (**BIOS Menu 10**) shows the operating temperature, fan speeds and system voltages.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Advanced

WinBond W83627EHG HardWare Monitor	
CPU Fan Speed	:N/A
Fan 2 Speed	:N/A
+12V	:+10.824 V
AVCC	:+0.160 V
3VCC	:+0.160 V
+3.3V	:+3.200 V
VSB	:+0.144 V
VBAT	:+0.144 V
Set Fan Duty Cycle	
CPU Fan Setting	255
Fan 2 Setting	255

Set Fan at fixed  
Duty-Cycle Min=0 Max=255  
Please input Dec number:

-----  
↔: Select Screen  
↑ ↓: Select Item  
EnterSelect  
+/-: Change Opt.  
F1: General Help  
F2: Previous Values  
F3: Optimized Defaults  
F4: Save & Exit  
ESC: Exit

Version 2.11.1210. Copyright (C) 2011 American Megatrends, Inc.

### BIOS Menu 10: F75387 HardWare Monitor

#### → CPU Fan Setting


Use the + or – key to change the **CPU Fan Setting** value. Enter a decimal number between 0 and 255.

#### → Fan 2 Setting

Use the + or – key to change the **Fan 2 Setting** value. Enter a decimal number between 0 and 255.

### 5.3.9 Serial Port Console Redirection

The **Serial Port Console Redirection** menu (**BIOS Menu 11**) allows the console redirection options to be configured. Console redirection allows users to maintain a system remotely by re-directing keyboard input and text output through the serial port.



#### BIOS Menu 11: Chipset

##### → **Console Redirection [Enabled]**

Use **Console Redirection** option to enable or disable the console redirection function.

- |                                  |   |
|----------------------------------|---|
| <b>→ Disabled</b> <b>DEFAULT</b> | Disabled the console redirection function |
| <b>→ Enabled</b>                 | Enabled the console redirection function  |

##### → **Terminal Type [ANSI]**

Use the **Terminal Type** option to specify the remote terminal type.

- ➔ **VT100** The target terminal type is VT100
  - ➔ **VT100+** The target terminal type is VT100+
  - ➔ **VT-UTF8** The target terminal type is VT-UTF8
  - ➔ **ANSI** **DEFAULT** The target terminal type is ANSI

→ Bits per second [115200]

Use the **Bits per second** option to specify the bits per second.

- 9600
  - 19200
  - 38400
  - 57600
  - 115200


## 5.4 Chipset

Use the **Chipset** menu (**BIOS Menu 12**) to access the Northbridge and Southbridge configuration menus




## **WARNING!**

Setting the wrong values for the Chipset BIOS selections in the Chipset BIOS menu may cause the system to malfunction.

**ICE-PV-N4551\_D5251 COM Express Type 2 Module****BIOS Menu 12: Chipset****5.4.1 Host Bridge Configuration**

Use the **Host Bridge Configuration** menu (**BIOS Menu 13**) to configure the Northbridge chipset.

**BIOS Menu 13: Host Bridge Chipset Configuration**

→ Share Memory Size [8 MB]

Use the **Share Memory Size** option to set the amount of system memory allocated to the integrated graphics processor when the system boots. The system memory allocated can then only be used as graphics memory, and is no longer available to applications or the operating system. Configuration options are listed below:

- Disabled
- 8 MB      **Default**


→ Initiate Graphics Adapter [PEG/PCI]

Use the **Initiate Graphics Adapter** option to select the graphics controller used as the primary boot device. Select either an integrated graphics controller (IGD) or a combination of PCI graphics controller, a PCI express (PEG) controller or an IGD. Configuration options are listed below:

- IGD
- PCI/IGD
- PCI/PEG
- PEG/IGD
- PEG/PCI      **DEFAULT**

### 5.4.2 South Bridge Configuration

Use the **South Bridge Configuration** menu (**BIOS Menu 14**) to configure the Southbridge chipset.



#### BIOS Menu 14:South Bridge Chipset Configuration

##### → **Restore on AC Power Loss [Last State]**

Use the **Restore on AC Power Loss** BIOS option to specify what state the system returns to if there is a sudden loss of power to the system.

- **Power Off** The system remains turned off
- **Power On** The system turns on
- **Last State DEFAULT** The system returns to its previous state. If it was on, it turns itself on. If it was off, it remains off.

##### → **HD Audio [Enabled]**

Use the **HD Audio** option to enable or disable the High Definition Audio controller.

- **Disabled** The onboard High Definition Audio controller is disabled

- **Enabled** **DEFAULT** The onboard High Definition Audio controller automatically detected and enabled


→ **Set Spread Spectrum Function [Disabled]**

The **Set Spread Spectrum Function** option can help to improve CPU EMI issues.

- **Disabled** **DEFAULT** The spread spectrum mode is disabled
- **Enabled** The spread spectrum mode is enabled

### 5.4.3 Intel IGD SWSCI OpRegion

Use the **Intel IGD SWSCI OpRegion** menu (**BIOS Menu 15**) to configure the video device connected to the system.



#### BIOS Menu 15: Intel IGD SWSCI OpRegion

→ **DVMT Mode Select [DVMT Mode]**

Use the **DVMT Mode Select** option to select the Intel Dynamic Video Memory Technology (DVMT) operating mode.

- **Fixed Mode** A fixed portion of graphics memory is reserved as graphics memory.

## ICE-PV-N4551\_D5251 COM Express Type 2 Module

- DVMT Mode **DEFAULT** Graphics memory is dynamically allocated according to the system and graphics needs.

→ DVMT/FIXED Memory [Maximum]

Use the **DVMT/FIXED Memory** option to specify the maximum amount of memory that can be allocated as graphics memory. Configuration options are listed below.

- 128 MB
- 256 MB
- Maximum      **Default**


→ IGD - Boot Type [CRT]

Use the **IGD - Boot Type** option to select the display device used by the system when it boots. Configuration options are listed below.

- VBIOS Default
- CRT            **DEFAULT**
- LFP
- CRT + LFP

## 5.5 Boot

Use the **Boot** menu (**BIOS Menu 16**) to configure system boot options.



### BIOS Menu 16: Boot

#### → Bootup NumLock State [On]

Use the **Bootup NumLock State** BIOS option to specify if the number lock setting must be modified during boot up.

→ **On**      **DEFAULT**      Allows the Number Lock on the keyboard to be enabled automatically when the computer system boots up. This allows the immediate use of the 10-key numeric keypad located on the right side of the keyboard. To confirm this, the Number Lock LED light on the keyboard is lit.

→ **Off**      Does not enable the keyboard Number Lock automatically. To use the 10-keys on the keyboard, press the Number Lock key located on the upper left-hand corner of the 10-key pad. The Number Lock LED on the keyboard lights up when the Number Lock is engaged.

→ Quiet Boot [Disabled]

Use the **Quiet Boot** BIOS option to select the screen display when the system boots.

→ **Disabled**    **DEFAULT**    Normal POST messages displayed

→ **Enabled**                           OEM Logo displayed instead of POST messages

→ Launch PXE OpROM [Disabled]


Use the **Launch PXE OpROM** option to enable or disable boot option for legacy network devices.

→ **Disabled**    **DEFAULT**    Ignore all PXE Option ROMs

→ **Enabled**                           Load PXE Option ROMs

## 5.6 Security

Use the **Security** menu (**BIOS Menu 17**) to set system and user passwords.



**BIOS Menu 17: Security**

#### → Administrator Password

Use the **Administrator Password** to set or change an administrator password.

#### → User Password

Use the **User Password** to set or change a user password.

#### → Set User Password

Use the **Set User Password** to set or change an HDD user password.




#### NOTE:

After an HDD password is set or changed, it is recommended that user restart the system.

## 5.7 Exit

Use the **Exit** menu (**BIOS Menu 18**) to load default BIOS values, optimal failsafe values and to save configuration changes.



BIOS Menu 18: Exit

→ **Save Changes and Reset**

Use the **Save Changes and Reset** option to save the changes made to the BIOS options and to exit the BIOS configuration setup program.

→ **Discard Changes and Reset**

Use the **Discard Changes and Reset** option to exit the system without saving the changes made to the BIOS configuration setup program.

→ **Restore Defaults**

Use the **Restore Defaults** option to load the optimal default values for each of the parameters on the Setup menus. **F3 key can be used for this operation.**

→ **Save as User Defaults**

Use the **Save as User Defaults** option to save the changes done so far as user defaults.

→ **Restore User Defaults**

Use the **Restore User Defaults** option to restore the user defaults to all the setup options.

Chapter

6

# Software Installation

---

## 6.1 Available Software Drivers



### NOTE:

The content of the CD may vary throughout the life cycle of the product and is subject to change without prior notice. Visit the IEI website or contact technical support for the latest updates.

The following drivers can be installed on the system:

- Chipset
- Graphic
- LAN
- Audio
- SATA
- iSMM
- Manual
- TPM
- ION


Installation instructions are given below.

## 6.2 Starting the Driver Program

To access the driver installation programs, please do the following.

**Step 1:** Insert the CD-ROM that came with the system into a CD-ROM drive attached to the system.


**Step 2:** The screen in **Figure 6-1** appears.



**Figure 6-1: Start Up Screen**

**Step 3:** Click **ICE-PV-N4551/D5251**.

**Step 4:** The list of drivers in **Figure 6-2** appears.



**Figure 6-2: Drivers**

**Step 5:** Install the necessary drivers from the list.

## Appendix

# A

# BIOS Options

---

Below is a list of BIOS configuration options in the BIOS chapter.

<b>BIOS Information .....</b>	<b>40</b>
<b>System Date [xx/xx/xx] .....</b>	<b>41</b>
<b>System Time [xx:xx:xx] .....</b>	<b>41</b>
<b>ACPI Sleep State [S1 (CPU Stop Clock)] .....</b>	<b>43</b>
<b>Hyper Threading [Enabled] .....</b>	<b>44</b>
<b>Intel® Virtualization Technology [Disabled].....</b>	<b>44</b>
<b>ATA Or IDE Configurations [Enhanced] .....</b>	<b>45</b>
<b>Configure SATA as [IDE].....</b>	<b>45</b>
<b>USB Devices.....</b>	<b>46</b>
<b>USB Function [Enabled].....</b>	<b>46</b>
<b>USB 2.0(EHCI) Support [Enabled] .....</b>	<b>46</b>
<b>Legacy USB Support [Enabled].....</b>	<b>47</b>
<b>PC Health Status .....</b>	<b>48</b>
<b>Temperature Source [Manual Fan].....</b>	<b>48</b>
<b>Serial Port [Enabled].....</b>	<b>49</b>
<b>Change Settings [Auto] .....</b>	<b>49</b>
<b>Serial Port [Enabled].....</b>	<b>50</b>
<b>Change Settings [Auto] .....</b>	<b>50</b>
<b>Serial Port [Enabled].....</b>	<b>51</b>
<b>Change Settings [Auto] .....</b>	<b>51</b>
<b>Serial Port [Enabled].....</b>	<b>52</b>
<b>Change Settings [Auto] .....</b>	<b>52</b>
<b>Select RS232/422/485 [RS232] .....</b>	<b>52</b>
<b>Floppy Disk Controller [Enabled].....</b>	<b>53</b>
<b>Change Settings [Auto] .....</b>	<b>53</b>
<b>Device Mode [Read Write].....</b>	<b>54</b>
<b>Serial Port [Enabled].....</b>	<b>54</b>
<b>Change Settings [Auto] .....</b>	<b>54</b>
<b>Serial Port [Enabled].....</b>	<b>55</b>
<b>Select Serial or IrDA [Serial Port].....</b>	<b>55</b>
<b>Change Settings [Auto] .....</b>	<b>55</b>
<b>Parallel Port [Enabled].....</b>	<b>56</b>
<b>Change Settings [Auto] .....</b>	<b>56</b>

<b>Device Mode [Printer Mode].....</b>	<b>57</b>
<b>CPU Fan Setting .....</b>	<b>58</b>
<b>Fan 2 Setting .....</b>	<b>58</b>
<b>Console Redirection [Enabled].....</b>	<b>59</b>
<b>Terminal Type [ANSI].....</b>	<b>59</b>
<b>Bits per second [115200].....</b>	<b>60</b>
<b>Share Memory Size [8 MB].....</b>	<b>62</b>
<b>Initiate Graphics Adapter [PEG/PCI] .....</b>	<b>62</b>
<b>Restore on AC Power Loss [Last State] .....</b>	<b>63</b>
<b>HD Audio [Enabled] .....</b>	<b>63</b>
<b>Set Spread Spectrum Function [Disabled].....</b>	<b>64</b>
<b>DVMT Mode Select [DVMT Mode].....</b>	<b>64</b>
<b>DVMT/FIXED Memory [Maximum] .....</b>	<b>65</b>
<b>IGD - Boot Type [CRT] .....</b>	<b>65</b>
<b>Bootup NumLock State [On].....</b>	<b>66</b>
<b>Quiet Boot [Disabled] .....</b>	<b>67</b>
<b>Launch PXE OpROM [Disabled] .....</b>	<b>67</b>
<b>Administrator Password .....</b>	<b>68</b>
<b>User Password .....</b>	<b>68</b>
<b>Set User Password .....</b>	<b>68</b>
<b>Save Changes and Reset .....</b>	<b>69</b>
<b>Discard Changes and Reset .....</b>	<b>69</b>
<b>Restore Defaults .....</b>	<b>69</b>
<b>Save as User Defaults .....</b>	<b>69</b>
<b>Restore User Defaults .....</b>	<b>69</b>

Appendix

B

# Terminology

---

<b>AC '97</b>	Audio Codec 97 (AC'97) refers to a codec standard developed by Intel® in 1997.
<b>ACPI</b>	Advanced Configuration and Power Interface (ACPI) is an OS-directed configuration, power management, and thermal management interface.
<b>AHCI</b>	Advanced Host Controller Interface (AHCI) is a SATA Host controller register-level interface.
<b>ATA</b>	The Advanced Technology Attachment (ATA) interface connects storage devices including hard disks and CD-ROM drives to a computer.
<b>ARMD</b>	An ATAPI Removable Media Device (ARMD) is any ATAPI device that supports removable media, besides CD and DVD drives.
<b>ASKIR</b>	Amplitude Shift Keyed Infrared (ASKIR) is a form of modulation that represents a digital signal by varying the amplitude ("volume") of the signal. A low amplitude signal represents a binary 0, while a high amplitude signal represents a binary 1.
<b>BIOS</b>	The Basic Input/Output System (BIOS) is firmware that is first run when the computer is turned on and can be configured by the end user
<b>CODEC</b>	The Compressor-Decompressor (CODEC) encodes and decodes digital audio data on the system.
<b>CompactFlash®</b>	CompactFlash® is a solid-state storage device. CompactFlash® devices use flash memory in a standard size enclosure. Type II is thicker than Type I, but a Type II slot can support both types.
<b>CMOS</b>	Complimentary metal-oxide-conductor is an integrated circuit used in chips like static RAM and microprocessors.
<b>COM</b>	COM refers to serial ports. Serial ports offer serial communication to expansion devices. The serial port on a personal computer is usually a male DB-9 connector.
<b>DAC</b>	The Digital-to-Analog Converter (DAC) converts digital signals to analog signals.
<b>DDR</b>	Double Data Rate refers to a data bus transferring data on both the rising and falling edges of the clock signal.

## ICE-PV-N4551\_D5251 COM Express Type 2 Module

<b>DMA</b>	Direct Memory Access (DMA) enables some peripheral devices to bypass the system processor and communicate directly with the system memory.
<b>DIMM</b>	Dual Inline Memory Modules are a type of RAM that offer a 64-bit data bus and have separate electrical contacts on each side of the module.
<b>DIO</b>	The digital inputs and digital outputs are general control signals that control the on/off circuit of external devices or TTL devices. Data can be read or written to the selected address to enable the DIO functions.
<b>EHCI</b>	The Enhanced Host Controller Interface (EHCI) specification is a register-level interface description for USB 2.0 Host Controllers.
<b>EIDE</b>	Enhanced IDE (EIDE) is a newer IDE interface standard that has data transfer rates between 4.0 MB/s and 16.6 MB/s.
<b>EIST</b>	Enhanced Intel® SpeedStep Technology (EIST) allows users to modify the power consumption levels and processor performance through application software. The application software changes the bus-to-core frequency ratio and the processor core voltage.
<b>FSB</b>	The Front Side Bus (FSB) is the bi-directional communication channel between the processor and the Northbridge chipset.
<b>GbE</b>	Gigabit Ethernet (GbE) is an Ethernet version that transfers data at 1.0 Gb/s and complies with the IEEE 802.3-2005 standard.
<b>GPIO</b>	General purpose input
<b>HDD</b>	Hard disk drive (HDD) is a type of magnetic, non-volatile computer storage device that stores digitally encoded data.
<b>ICH</b>	The Input/Ouput Control Hub (ICH) is an Intel® Southbridge chipset.
<b>IrDA</b>	Infrared Data Association (IrDA) specifies infrared data transmission protocols used to enable electronic devices to wirelessly communicate with each other.
<b>L1 Cache</b>	The Level 1 Cache (L1 Cache) is a small memory cache built into the system processor.
<b>L2 Cache</b>	The Level 2 Cache (L2 Cache) is an external processor memory cache.

<b>LCD</b>	Liquid crystal display (LCD) is a flat, low-power display device that consists of two polarizing plates with a liquid crystal panel in between.
<b>LVDS</b>	Low-voltage differential signaling (LVDS) is a dual-wire, high-speed differential electrical signaling system commonly used to connect LCD displays to a computer.
<b>POST</b>	The Power-on Self Test (POST) is the pre-boot actions the system performs when the system is turned-on.
<b>RAM</b>	Random Access Memory (RAM) is volatile memory that loses data when power is lost. RAM has very fast data transfer rates compared to other storage like hard drives.
<b>SATA</b>	Serial ATA (SATA) is a serial communications bus designed for data transfers between storage devices and the computer chipsets. The SATA bus has transfer speeds up to 1.5 Gb/s and the SATA II bus has data transfer speeds of up to 3.0 Gb/s.
<b>S.M.A.R.T</b>	Self Monitoring Analysis and Reporting Technology (S.M.A.R.T) refers to automatic status checking technology implemented on hard disk drives.
<b>UART</b>	Universal Asynchronous Receiver-transmitter (UART) is responsible for asynchronous communications on the system and manages the system's serial communication (COM) ports.
<b>UHCI</b>	The Universal Host Controller Interface (UHCI) specification is a register-level interface description for USB 1.1 Host Controllers.
<b>USB</b>	The Universal Serial Bus (USB) is an external bus standard for interfacing devices. USB 1.1 supports 12 Mb/s data transfer rates and USB 2.0 supports 480 Mb/s data transfer rates.
<b>VGA</b>	The Video Graphics Array (VGA) is a graphics display system developed by IBM.

## Appendix

C

# Watchdog Timer

---

**NOTE:**

The following discussion applies to DOS environment. IEI support is contacted or the IEI website visited for specific drivers for more sophisticated operating systems, e.g., Windows and Linux.

The Watchdog Timer is provided to ensure that standalone systems can always recover from catastrophic conditions that cause the CPU to crash. This condition may have occurred by external EMIs or a software bug. When the CPU stops working correctly, Watchdog Timer either performs a hardware reset (cold boot) or a Non-Maskable Interrupt (NMI) to bring the system back to a known state.

A BIOS function call (INT 15H) is used to control the Watchdog Timer.

INT 15H:

<b>AH – 6FH Sub-function:</b>	
AL – 2:	Sets the Watchdog Timer's period.
BL:	Time-out value (Its unit-second is dependent on the item "Watchdog Timer unit select" in CMOS setup).

**Table C-1: AH-6FH Sub-function**

Call sub-function 2 to set the time-out period of Watchdog Timer first. If the time-out value is not zero, the Watchdog Timer starts counting down. When the timer value reaches zero, the system resets. To ensure that this reset condition does not occur; calling sub-function 2 must periodically refresh the Watchdog Timer. However, the watchdog timer is disabled if the time-out value is set to zero.

A tolerance of at least 10% must be maintained to avoid unknown routines within the operating system (DOS), such as disk I/O that can be very time-consuming.

**NOTE:**

When exiting a program it is necessary to disable the Watchdog Timer, otherwise the system resets.

---

**EXAMPLE PROGRAM:**

---

; INITIAL TIMER PERIOD COUNTER

;

**W\_LOOP:**

;

MOV AX, 6F02H ;setting the time-out value  
MOV BL, 30 ;time-out value is 48 seconds  
INT 15H

;

**; ADD THE APPLICATION PROGRAM HERE**

;

CMP EXIT\_AP, 1 ;is the application over?  
JNE W\_LOOP ;No, restart the application

MOV AX, 6F02H ;disable Watchdog Timer  
MOV BL, 0 ;  
INT 15H

;

**; EXIT ;**

Appendix

D

# Hazardous Materials Disclosure

---

## D.1 Hazardous Materials Disclosure Table for IPB Products Certified as RoHS Compliant Under 2002/95/EC Without Mercury

The details provided in this appendix are to ensure that the product is compliant with the Peoples Republic of China (China) RoHS standards. The table below acknowledges the presences of small quantities of certain materials in the product, and is applicable to China RoHS only.

A label will be placed on each product to indicate the estimated "Environmentally Friendly Use Period" (EFUP). This is an estimate of the number of years that these substances would "not leak out or undergo abrupt change." This product may contain replaceable sub-assemblies/components which have a shorter EFUP such as batteries and lamps. These components will be separately marked.

Please refer to the table on the next page.

Part Name	Toxic or Hazardous Substances and Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Housing	X	O	O	O	O	X
Display	X	O	O	O	O	X
Printed Circuit Board	X	O	O	O	O	X
Metal Fasteners	X	O	O	O	O	O
Cable Assembly	X	O	O	O	O	X
Fan Assembly	X	O	O	O	O	X
Power Supply Assemblies	X	O	O	O	O	X
Battery	O	O	O	O	O	O

O: This toxic or hazardous substance is contained in all of the homogeneous materials for the part is below the limit requirement in SJ/T11363-2006

X: This toxic or hazardous substance is contained in at least one of the homogeneous materials for this part is above the limit requirement in SJ/T11363-2006

此附件旨在确保本产品符合中国 RoHS 标准。以下表格标示此产品中某有毒物质的含量符合中国 RoHS 标准规定的限量要求。

本产品上会附有“环境友好使用期限”的标签，此期限是估算这些物质“不会有泄漏或突变”的年限。本产品可能包含有较短的环境友好使用期限的可替换元件，像是电池或灯管，这些元件将会单独标示出来。

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯 醚 (PBDE)
壳体	X	O	O	O	O	X
显示	X	O	O	O	O	X
印刷电路板	X	O	O	O	O	X
金属螺帽	X	O	O	O	O	O
电缆组装	X	O	O	O	O	X
风扇组装	X	O	O	O	O	X
电力供应组装	X	O	O	O	O	X
电池	O	O	O	O	O	O

O: 表示该有毒有害物质在该部件所有物质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。  
X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T11363-2006 标准规定的限量要求。