




IEI Technology Corp.

MODEL:  
**IMB-Q770**



microATX Motherboard Supports 22nm LGA1155 Intel® Core™ i7/i5/i3 CPU with Intel® Q77, DDR3, Three Independent Displays via Dual HDMI/DVI-I, Dual Intel® PCIe GbE, USB 3.0, SATA 6Gb/s, Ten Serial Ports, HD Audio and RoHS

## User Manual

Rev. 1.00 – 30 August, 2012



# Revision

---

Date	Version	Changes
30 August, 2012	1.00	Initial release

# Copyright

## COPYRIGHT NOTICE

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

## TRADEMARKS

All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

# Table of Contents

<b>1 INTRODUCTION.....</b>	<b>1</b>
1.1 INTRODUCTION.....	2
1.2 BENEFITS .....	3
1.3 FEATURES.....	3
1.4 CONNECTORS .....	4
1.5 DIMENSIONS.....	5
1.6 DATA FLOW .....	6
1.7 TECHNICAL SPECIFICATIONS .....	7
<b>2 PACKING LIST .....</b>	<b>10</b>
2.1 ANTI-STATIC PRECAUTIONS .....	11
2.2 UNPACKING PRECAUTIONS.....	11
2.3 PACKING LIST.....	12
2.4 OPTIONAL ITEMS .....	13
<b>3 CONNECTORS .....</b>	<b>15</b>
3.1 PERIPHERAL INTERFACE CONNECTORS.....	16
3.1.1 <i>IMB-Q770 Layout</i> .....	16
3.1.2 <i>Peripheral Interface Connectors</i> .....	17
3.1.3 <i>External Interface Panel Connectors</i> .....	18
3.2 INTERNAL PERIPHERAL CONNECTORS .....	18
3.2.1 <i>ATX Power Connector</i> .....	18
3.2.2 <i>Battery Connector</i> .....	20
3.2.3 <i>CPU Power Connector</i> .....	20
3.2.4 <i>DDR3 DIMM Slots</i> .....	21
3.2.5 <i>Debug Port Connector</i> .....	22
3.2.6 <i>Digital I/O Connector</i> .....	23
3.2.7 <i>Fan Connector (CPU)</i> .....	24
3.2.8 <i>Fan Connector (System)</i> .....	25
3.2.9 <i>Fan Connector (PCH)</i> .....	26
3.2.10 <i>Front Panel Audio Connector</i> .....	27

3.2.11 Front Panel Connector.....	28
3.2.12 FW Programming Connector.....	29
3.2.13 Infrared Interface Connector.....	29
3.2.14 Keyboard/Mouse Connector .....	30
3.2.15 PCIe Power Connector.....	31
3.2.16 PCI Slot.....	32
3.2.17 PCIe x16 Slot .....	33
3.2.18 PCIe x4 Slot .....	34
3.2.19 PCIe x1 Slot .....	34
3.2.20 SATA 3Gb/s Drive Connectors.....	35
3.2.21 SATA 6Gb/s Drive Connectors.....	36
3.2.22 Serial Port Connector, RS-422/485.....	36
3.2.23 Serial Port Connectors, RS-232.....	37
3.2.24 SMBus Connector .....	39
3.2.25 SPI ROM Connector.....	40
3.2.26 TPM Connector.....	40
3.2.27 USB Connectors.....	42
3.3 EXTERNAL PERIPHERAL INTERFACE CONNECTOR PANEL .....	43
3.3.1 Audio Connector .....	43
3.3.2 DVI Connector .....	44
3.3.3 Ethernet and USB Connector.....	45
3.3.4 HDMI Connector .....	47
3.3.5 Serial Port Connector.....	47
<b>4 INSTALLATION .....</b>	<b>49</b>
4.1 ANTI-STATIC PRECAUTIONS .....	50
4.2 INSTALLATION CONSIDERATIONS.....	50
4.2.1 Socket LGA1155 CPU Installation .....	52
4.2.2 Socket LGA1155 Cooling Kit Installation.....	55
4.2.3 DIMM Installation .....	57
4.3 JUMPER SETTINGS .....	58
4.3.1 AT/ATX Power Select Jumper.....	58
4.3.2 Clear CMOS Jumper.....	59
4.4 INTERNAL PERIPHERAL DEVICE CONNECTIONS .....	60
4.4.1 SATA Drive Connection .....	60

4.5 EXTERNAL PERIPHERAL INTERFACE CONNECTION .....	62
4.5.1 <i>Audio Connection</i> .....	62
4.5.2 <i>DVI Display Device Connection</i> .....	63
4.5.3 <i>HDMI Connection</i> .....	64
4.5.4 <i>LAN Connection</i> .....	65
4.5.5 <i>Serial Device Connection</i> .....	66
4.5.6 <i>USB Connection</i> .....	67
4.6 INTEL® AMT SETUP PROCEDURE .....	68
<b>5 BIOS .....</b>	<b>70</b>
5.1 INTRODUCTION.....	71
5.1.1 <i>Starting Setup</i> .....	71
5.1.2 <i>Using Setup</i> .....	71
5.1.3 <i>Getting Help</i> .....	72
5.1.4 <i>Unable to Reboot after Configuration Changes</i> .....	72
5.1.5 <i>BIOS Menu Bar</i> .....	72
5.2 MAIN.....	73
5.3 ADVANCED .....	74
5.3.1 <i>ACPI Configuration</i> .....	75
5.3.2 <i>RTC Wake Settings</i> .....	76
5.3.3 <i>Trusted Computing</i> .....	77
5.3.4 <i>CPU Configuration</i> .....	79
5.3.5 <i>SATA Configuration</i> .....	81
5.3.6 <i>Intel(R) Rapid Start Technology</i> .....	82
5.3.7 <i>Intel TXT(LT) Configuration</i> .....	82
5.3.8 <i>AMT Configuration</i> .....	83
5.3.9 <i>USB Configuration</i> .....	84
5.3.10 <i>F81216 Second Super IO Configuration</i> .....	85
5.3.10.1 <i>Serial Port n Configuration</i> .....	86
5.3.10.2 <i>Serial Port 7 Configuration</i> .....	87
5.3.10.3 <i>Serial Port 8 Configuration</i> .....	88
5.3.10.4 <i>Serial Port 9 Configuration</i> .....	89
5.3.10.5 <i>Serial Port 10 Configuration</i> .....	90
5.3.11 <i>F81866 Super IO Configuration</i> .....	91
5.3.11.1 <i>Serial Port n Configuration</i> .....	91

<i>5.3.12 F81866 H/W Monitor</i> .....	97
5.3.12.1 Smart Fan Mode Configuration .....	98
<i>5.3.13 Serial Port Console Redirection</i> .....	100
5.3.13.1 Console Redirection Settings .....	102
<i>5.3.14 IEI Feature</i> .....	104
<i>5.4 CHIPSET</i> .....	105
<i>5.4.1 PCH-IO Configuration</i> .....	106
5.4.1.1 PCH Azalia Configuration .....	107
<i>5.4.2 System Agent (SA) Configuration</i> .....	108
5.4.2.1 Graphics Configuration.....	109
5.4.2.2 Memory Configuration .....	111
<i>5.5 BOOT</i> .....	112
<i>5.6 SECURITY</i> .....	114
<i>5.7 EXIT</i> .....	115
<b>6 SOFTWARE DRIVERS</b> .....	<b>117</b>
<i>6.1 AVAILABLE SOFTWARE DRIVERS</i> .....	118
<i>6.2 SOFTWARE INSTALLATION</i> .....	118
<i>6.3 CHIPSET DRIVER INSTALLATION</i> .....	120
<i>6.4 GRAPHICS DRIVER INSTALLATION</i> .....	123
<i>6.5 LAN DRIVER INSTALLATION</i> .....	126
<i>6.6 AUDIO DRIVER INSTALLATION</i> .....	130
<i>6.7 INTEL® RAPID STORAGE TECHNOLOGY DRIVER INSTALLATION</i> .....	132
<i>6.8 USB 3.0 DRIVER INSTALLATION</i> .....	135
<i>6.9 INTEL® AMT DRIVER INSTALLATION</i> .....	138
<b>A BIOS OPTIONS</b> .....	<b>141</b>
<b>B ONE KEY RECOVERY</b> .....	<b>145</b>
<i>B.1 ONE KEY RECOVERY INTRODUCTION</i> .....	146
<i>B.1.1 System Requirement</i> .....	147
<i>B.1.2 Supported Operating System</i> .....	148
<i>B.2 SETUP PROCEDURE FOR WINDOWS</i> .....	149
<i>B.2.1 Hardware and BIOS Setup</i> .....	150
<i>B.2.2 Create Partitions</i> .....	150
<i>B.2.3 Install Operating System, Drivers and Applications</i> .....	154

<i>B.2.4 Building the Recovery Partition</i> .....	155
<i>B.2.5 Create Factory Default Image</i> .....	157
<b>B.3 AUTO RECOVERY SETUP PROCEDURE</b> .....	162
<b>B.4 SETUP PROCEDURE FOR LINUX</b> .....	166
<b>B.5 RECOVERY TOOL FUNCTIONS</b> .....	170
<i>B.5.1 Factory Restore</i> .....	171
<i>B.5.2 Backup System</i> .....	172
<i>B.5.3 Restore Your Last Backup</i> .....	173
<i>B.5.4 Manual</i> .....	174
<b>B.6 RESTORE SYSTEMS FROM A LINUX SERVER THROUGH LAN</b> .....	175
<i>B.6.1 Configure DHCP Server Settings</i> .....	176
<i>B.6.2 Configure TFTP Settings</i> .....	177
<i>B.6.3 Configure One Key Recovery Server Settings</i> .....	178
<i>B.6.4 Start the DHCP, TFTP and HTTP</i> .....	179
<i>B.6.5 Create Shared Directory</i> .....	179
<i>B.6.6 Setup a Client System for Auto Recovery</i> .....	180
<b>B.7 OTHER INFORMATION</b> .....	183
<i>B.7.1 Using AHCI Mode or ALi M5283 / VIA VT6421A Controller</i> .....	183
<i>B.7.2 System Memory Requirement</i> .....	185
<b>C TERMINOLOGY</b> .....	186
<b>D WATCHDOG TIMER</b> .....	190
<b>E HAZARDOUS MATERIALS DISCLOSURE</b> .....	193
E.1 HAZARDOUS MATERIALS DISCLOSURE TABLE FOR IPB PRODUCTS CERTIFIED AS RoHS COMPLIANT UNDER 2002/95/EC WITHOUT MERCURY .....	194

# List of Figures

Figure 1-1: IMB-Q770.....	2
Figure 1-2: Connectors .....	4
Figure 1-3: IMB-Q770 Dimensions (mm) .....	5
Figure 1-4: Data Flow Diagram.....	6
Figure 3-1: Connectors and Jumpers.....	16
Figure 3-2: ATX Power Connector Pinout Location.....	19
Figure 3-3: Battery Connector Locations.....	20
Figure 3-4: CPU Power Connector Location.....	21
Figure 3-5: DDR3 DIMM Slot Locations .....	22
Figure 3-6: Debug Port Connector Location.....	22
Figure 3-7: Digital I/O Connector Location .....	23
Figure 3-8: CPU Fan Connector Location .....	24
Figure 3-9: System Fan Connector Location .....	25
Figure 3-10: PCH Fan Connector Location .....	26
Figure 3-11: Front Panel Audio Connector Location .....	27
Figure 3-12: Front Panel Connector Location .....	28
Figure 3-13: FW Programming Connector Location .....	29
Figure 3-14: Infrared Connector Location.....	30
Figure 3-15: Keyboard/Mouse Connector Location .....	31
Figure 3-16: PCIe Power Location .....	32
Figure 3-17: PCI Slot Locations .....	33
Figure 3-18: PCIe x16 Slot Location .....	33
Figure 3-19: PCIe x4 Slot Locations .....	34
Figure 3-20: PCIe x1 Slot Locations .....	35
Figure 3-21: SATA 3Gb/s Drive Connector Location .....	35
Figure 3-22: SATA 6Gb/s Drive Connector Location .....	36
Figure 3-23: RS-422/485 Connector Location .....	37
Figure 3-24: Serial Port Connector Location .....	38
Figure 3-25: SMBus Connector Location .....	39
Figure 3-26: SPI Connector Location .....	40

Figure 3-27: TPM Connector Location.....	41
Figure 3-28: USB Connector Pinout Locations .....	42
Figure 3-29: External Peripheral Interface Connector .....	43
Figure 3-30: Audio Connector .....	44
Figure 3-31: Ethernet Connector.....	45
Figure 3-32: Serial Port Connector Pinouts.....	48
Figure 4-1: Disengage the CPU Socket Load Lever.....	52
Figure 4-2: Remove Protective Cover.....	53
Figure 4-3: Insert the Socket LGA1155 CPU.....	54
Figure 4-4: Close the Socket LGA1155.....	54
Figure 4-5: Cooling Kits (CF-1156A-RS, CF-1156B-RS, CF-1156C-RS, CF-1156D-RS).....	55
Figure 4-6: Cooling Kit Support Bracket .....	56
Figure 4-7: DIMM Installation.....	57
Figure 4-8: AT/ATX Power Select Jumper Location.....	59
Figure 4-9: Clear BIOS Jumper Location .....	60
Figure 4-10: SATA Drive Cable Connection.....	61
Figure 4-11: SATA Power Drive Connection.....	62
Figure 4-12: Audio Connector .....	63
Figure 4-13: DVI Connector .....	64
Figure 4-14: HDMI Connection .....	65
Figure 4-15: LAN Connection .....	66
Figure 4-16: Serial Device Connector.....	67
Figure 4-17: USB Connector.....	68
Figure 6-1: Introduction Screen .....	119
Figure 6-2: Available Drivers .....	119
Figure 6-3: Chipset Driver Welcome Screen.....	120
Figure 6-4: Chipset Driver License Agreement .....	121
Figure 6-5: Chipset Driver Read Me File .....	121
Figure 6-6: Chipset Driver Setup Operations .....	122
Figure 6-7: Chipset Driver Installation Finish Screen.....	123
Figure 6-8: Graphics Driver Welcome Screen .....	124
Figure 6-9: Graphics Driver License Agreement.....	124
Figure 6-10: Graphics Driver Setup Operations .....	125
Figure 6-11: Graphics Driver Installation Finish Screen .....	125
Figure 6-12: Windows Control Panel.....	126

Figure 6-13: System Control Panel .....	126
Figure 6-14: Device Manager List .....	127
Figure 6-15: Update Driver Software Window .....	128
Figure 6-16: Locate Driver Files .....	128
Figure 6-17: LAN Driver Installation .....	129
Figure 6-18: LAN Driver Installation Complete .....	129
Figure 6-19: InstallShield Wizard Welcome Screen .....	130
Figure 6-20: Audio Driver Software Configuration.....	131
Figure 6-21: Restart the Computer .....	131
Figure 6-22: SATA RAID Driver Welcome Screen .....	132
Figure 6-23: SATA RAID Driver License Agreement.....	133
Figure 6-24: SATA RAID Driver Read Me File .....	133
Figure 6-25: SATA RAID Driver Setup Operations .....	134
Figure 6-26: SATA RAID Driver Installation Finish Screen .....	134
Figure 6-27: USB 3.0 Driver Welcome Screen .....	135
Figure 6-28: USB 3.0 Driver License Agreement.....	136
Figure 6-29: USB 3.0 Driver Read Me File .....	136
Figure 6-30: USB 3.0 Driver Setup Operations .....	137
Figure 6-31: USB 3.0 Driver Installation Finish Screen .....	137
Figure 6-32: Intel® ME Driver Welcome Screen .....	139
Figure 6-33: Intel® ME Driver License Agreement .....	139
Figure 6-34: Intel® ME Driver Setup Operations .....	140
Figure 6-35: Intel® ME Driver Installation Finish Screen .....	140
Figure B-1: IEI One Key Recovery Tool Menu .....	146
Figure B-2: Launching the Recovery Tool .....	151
Figure B-3: Recovery Tool Setup Menu .....	151
Figure B-4: Command Prompt .....	152
Figure B-5: Partition Creation Commands.....	153
Figure B-6: Launching the Recovery Tool .....	155
Figure B-7: Manual Recovery Environment for Windows .....	155
Figure B-8: Building the Recovery Partition .....	156
Figure B-9: Press Any Key to Continue .....	156
Figure B-10: Press F3 to Boot into Recovery Mode.....	157
Figure B-11: Recovery Tool Menu .....	157
Figure B-12: About Symantec Ghost Window .....	158

Figure B-13: Symantec Ghost Path .....	158
Figure B-14: Select a Local Source Drive .....	159
Figure B-15: Select a Source Partition from Basic Drive .....	159
Figure B-16: File Name to Copy Image to .....	160
Figure B-17: Compress Image.....	160
Figure B-18: Image Creation Confirmation .....	161
Figure B-19: Image Creation Complete .....	161
Figure B-20: Image Creation Complete .....	161
Figure B-21: Press Any Key to Continue .....	162
Figure B-22: Auto Recovery Utility .....	163
Figure B-23: Launching the Recovery Tool.....	163
Figure B-24: Auto Recovery Environment for Windows .....	163
Figure B-25: Building the Auto Recovery Partition.....	164
Figure B-26: Factory Default Image Confirmation .....	164
Figure B-27: Image Creation Complete .....	165
Figure B-28: Press any key to continue .....	165
Figure B-29: Partitions for Linux.....	167
Figure B-30: Manual Recovery Environment for Linux .....	168
Figure B-31: Access menu.lst in Linux (Text Mode).....	169
Figure B-32: Recovery Tool Menu .....	169
Figure B-33: Recovery Tool Main Menu .....	170
Figure B-34: Restore Factory Default.....	171
Figure B-35: Recovery Complete Window .....	172
Figure B-36: Backup System.....	172
Figure B-37: System Backup Complete Window .....	173
Figure B-38: Restore Backup .....	173
Figure B-39: Restore System Backup Complete Window .....	174
Figure B-40: Symantec Ghost Window .....	174

# List of Tables

Table 1-1: IMB-Q770 Specifications.....	9
Table 2-1: Packing List.....	13
Table 2-2: Optional Items .....	14
Table 3-1: Peripheral Interface Connectors .....	18
Table 3-2: Rear Panel Connectors .....	18
Table 3-3: ATX Power Connector Pinouts.....	19
Table 3-4: CPU Power Connector Pinouts .....	21
Table 3-5: Debug Port Connector Pinouts .....	23
Table 3-6: Digital I/O Connector Pinouts.....	24
Table 3-7: CPU Fan Connector Pinouts .....	25
Table 3-8: System Fan Connector Pinouts (SYS_FAN1) .....	25
Table 3-9: System Fan Connector Pinouts (SYS_FAN2) .....	26
Table 3-10: PCH Fan Connector Pinouts.....	26
Table 3-11: Front Panel Audio Connector Pinouts .....	27
Table 3-12: Front Panel Connector Pinouts.....	28
Table 3-13: FW Programming Connector Pinouts .....	29
Table 3-14: Infrared Connector Pinouts .....	30
Table 3-15: Keyboard/Mouse Connector Pinouts .....	31
Table 3-16: PCIe Power Pinouts.....	32
Table 3-17: RS-422/485Connector Pinouts .....	37
Table 3-18: Serial Port Connector Pinouts .....	38
Table 3-19: SMBus Connector Pinouts .....	39
Table 3-20: SPI Connector Pinouts.....	40
Table 3-21: TPM Connector Pinouts .....	41
Table 3-22: USB Port Connector Pinouts.....	42
Table 3-23: DVI Connector Pinouts.....	44
Table 3-24: Connector LEDs.....	45
Table 3-25: LAN and USB Connector Pinouts (LAN_USB1).....	46
Table 3-26: LAN and USB Connector Pinouts (LAN_USB2).....	46
Table 3-27: USB Connector Pinouts (R_USB1) .....	47

<b>Table 3-28: HDMI Connector Pinouts .....</b>	<b>47</b>
<b>Table 3-29: Serial Port Connector Pinouts .....</b>	<b>48</b>
<b>Table 4-1: Jumpers .....</b>	<b>58</b>
<b>Table 4-2: AT/ATX Power Select Jumper Settings .....</b>	<b>59</b>
<b>Table 4-3: Clear BIOS Jumper Settings.....</b>	<b>59</b>
<b>Table 5-1: BIOS Navigation Keys .....</b>	<b>72</b>

# BIOS Menus

---

BIOS Menu 1: Main .....	73
BIOS Menu 2: Advanced .....	75
BIOS Menu 3: ACPI Configuration .....	75
BIOS Menu 4: RTC Wake Settings .....	76
BIOS Menu 5: Trusted Computing .....	78
BIOS Menu 6: CPU Configuration .....	79
BIOS Menu 7: SATA Configuration .....	81
BIOS Menu 8: Intel(R) Rapid Start Technology .....	82
BIOS Menu 9: Intel TXT(LT) Configuration.....	83
BIOS Menu 10: AMT Configuration.....	83
BIOS Menu 11: USB Configuration .....	84
BIOS Menu 12: Secondary Super IO Configuration .....	86
BIOS Menu 13: Serial Port n Configuration Menu.....	86
BIOS Menu 14: Super IO Configuration.....	91
BIOS Menu 15: Serial Port n Configuration Menu.....	91
BIOS Menu 16: Hardware Health Configuration .....	97
BIOS Menu 17: FAN 1 Configuration .....	99
BIOS Menu 18: Serial Port Console Redirection .....	101
BIOS Menu 19: Console Redirection Settings.....	102
BIOS Menu 20: IEI Feature .....	104
BIOS Menu 21: Chipset .....	105
BIOS Menu 22:PCH-IO Configuration .....	106
BIOS Menu 23:PCH-IO Configuration .....	107
BIOS Menu 24: System Agent (SA) Configuration .....	109
BIOS Menu 25: Graphics Configuration .....	109
BIOS Menu 26: Graphics Configuration .....	111
BIOS Menu 27: Memory Configuration.....	112
BIOS Menu 28: Boot .....	112
BIOS Menu 29: Security .....	114
BIOS Menu 30:Exit.....	115

---

**BIOS Menu 31: IEI Feature.....166**


Chapter

1

# Introduction

---

## 1.1 Introduction



**Figure 1-1: IMB-Q770**

The IMB-Q770 is an ATX motherboard. It accepts a socket LGA1155 Intel® Core™ i7/i5/i3 quad/dual core processor and supports four 240-pin 1600/1333MHz dual-channel DDR3 SDRAM unbuffered DIMMs (system max. 32GB).

The integrated Intel® Q77 system Chipset supports two GbE LAN: one through the Intel® 82579 PHY with Intel® AMT 8.0 support and the other through the Intel® 82583V PCIe controller.

The IMB-Q770 includes two HDMI connectors and one DVI-I connector. Expansion and I/O include one PCI slot, one PCIe x16 slot, one PCIe x4 slot, one PCIe x1 slot, four USB 3.0 ports on the rear panel, two USB 2.0 on the rear panel, four USB 2.0 by pin header, four SATA 3Gb/s connectors, two SATA 6Gb/s connectors. Serial device connectivity is provided by eight internal RS-232 connectors, one external RS-232 connector and one internal RS-232/422/485 connector.

## 1.2 Benefits

Some of the IMB-Q770 motherboard benefits include:

- Powerful graphics with multiple monitors
- Staying connected with both wired LAN connections
- Speedy running of multiple programs and applications

## 1.3 Features

Some of the IMB-Q770 motherboard features are listed below:

- LGA1155 Intel® Core™ i7/i5/i3 processor supported
- Dual-channel DDR3 1600/1333MHz supports up to 32GB
- Intel® PCIe GbE with Intel® AMT 8.0 supported
- Supports three displays with two displays in combination of HDMI, DVI and VGA
- Supports PCI-Express generation 3.0 at 8GT/s I/O bandwidth
- USB 3.0 and SATA 6Gb/s supported
- Supports much scalable serial ports
- IEI One Key Recovery solution allows you to create rapid OS backup and recovery

## 1.4 Connectors

The connectors on the IMB-Q770 are shown in the figure below.




Figure 1-2: Connectors

## 1.5 Dimensions

The main dimensions of the IMB-Q770 are shown in the diagram below.





Figure 1-3: IMB-Q770 Dimensions (mm)

## 1.6 Data Flow

**Figure 1-4** shows the data flow between the system chipset, the CPU and other components installed on the motherboard.



**Figure 1-4: Data Flow Diagram**

## 1.7 Technical Specifications

IMB-Q770 technical specifications are listed below.

Specification/Model	IMB-Q770
<b>Form Factor</b>	Micro-ATX
<b>CPU</b>	LGA1155 socket supports Intel® Core™ i7/i5/i3 quad/dual core processor
<b>System Chipset</b>	Intel® Q77
<b>Graphics Engine</b>	Intel® HD Graphics Gen 7 supports DX11 and OpenCL 1.1 Full MPEG2, VC1, AVC Decode
<b>Display Output</b>	Dual HDMI integrated in the Intel® Q77 DVI-I integrated in the Intel® Q77
<b>Memory</b>	Four 240-pin 1600/1333MHz dual-channel DDR3 SDRAM unbuffered DIMMs supported (system max. 32GB)
<b>Audio</b>	Realtek ALC662 HD audio codec (Line-in, Line-out, Mic)
<b>BIOS</b>	UEFI BIOS
<b>Digital I/O</b>	24-bit Digital I/O (12-bit input, 12-bit output)
<b>Ethernet</b>	Intel® 82583V PCIe controller Intel® 82579 PHY with Intel® AMT 8.0 supported
<b>Super I/O</b>	Fintek F81866
<b>Watchdog Timer</b>	Software programmable supports 1~255 sec. system reset
<b>Expansion</b>	
<b>PCI</b>	One PCI slot
<b>PCIe</b>	One PCIe x16 slot One PCIe x4 slot One PCIe x1 slot
<b>I/O Interface Connectors</b>	
<b>Audio Connectors</b>	Three external audio jacks (Line-in, Line-out, Mic)

Specification/Model	IMB-Q770
<b>Display port</b>	One DVI-I port Two HDMI ports
<b>Ethernet</b>	Two RJ-45 GbE ports
<b>Keyboard/Mouse</b>	One 6-pin wafer for PS/2 KB/MS
<b>TPM</b>	One 20-pin header
<b>Front Panel</b>	1 x Front panel connector (power LED, HDD LED, speaker, power button, reset button)
<b>Front Audio</b>	One 10-pin header
<b>SMBUS</b>	One 4 pin wafer
<b>I2C</b>	One 4 pin wafer
<b>IR</b>	One 5 pin header
<b>Fan</b>	One 4-pin CPU fan connector Two 3-pin system fan connectors
<b>Serial Ports</b>	One external RS-232 serial port Eight RS-232 via internal two 40-pin box headers One RS-422/485 via internal 4-pin wafer
<b>USB ports</b>	Four external USB 3.0 ports on rear IO Two external USB 2.0 ports on rear IO Four internal USB 2.0 ports by pin header
<b>Serial ATA</b>	Two SATA 6Gb/s connectors Four SATA 3Gb/s connectors
<b>Environmental and Power Specifications</b>	
<b>Power Supply</b>	ATX power supply
<b>Power Consumption</b>	3.3V@0.31A, 5V@2.91A, 12V@0.51A, 12V@2.12A, -12V@0.10A (Intel® Core™ i3 3200 3.2GHZ CPU with four 1333MHz 1GB DDR3 memory)
<b>Operating Temperature</b>	-10°C ~ 60°C
<b>Humidity</b>	5% ~ 95% (non-condensing)

## IMB-Q770 Micro-ATX Motherboard

Specification/Model	IMB-Q770
<b>Physical Specifications</b>	
Dimensions	244 mm x 244 mm
Weight GW/NW	1200 g / 700 g

Table 1-1: IMB-Q770 Specifications

Chapter

2

# Packing List

---

## 2.1 Anti-static Precautions



### WARNING!

Static electricity can destroy certain electronics. Make sure to follow the ESD precautions to prevent damage to the product, and injury to the user.

Make sure to adhere to the following guidelines:

- **Wear an anti-static wristband:** Wearing an anti-static wristband can prevent electrostatic discharge.
- **Self-grounding:** Touch a grounded conductor every few minutes to discharge any excess static buildup.
- **Use an anti-static pad:** When configuring any circuit board, place it on an anti-static mat.
- **Only handle the edges of the PCB:** Don't touch the surface of the motherboard. Hold the motherboard by the edges when handling.

## 2.2 Unpacking Precautions

When the IMB-Q770 is unpacked, please do the following:

- Follow the antistatic guidelines above.
- Make sure the packing box is facing upwards when opening.
- Make sure all the packing list items are present.

## 2.3 Packing List



### NOTE:

If any of the components listed in the checklist below are missing, do not proceed with the installation. Contact the IEI reseller or vendor the IMB-Q770 was purchased from or contact an IEI sales representative directly by sending an email to [sales@iei.com.tw](mailto:sales@iei.com.tw).

The IMB-Q770 is shipped with the following components:

Quantity	Item and Part Number	Image
1	IMB-Q770 motherboard	
1	DVI-I to VGA adapter (P/N: 33Z00-000031-RS)	
4	SATA cable (P/N: 32801-000703-200-RS)	
1	I/O shielding (P/N: 45014-0042C0-00-RS)	
1	Mini jumper pack (2.54mm)	
1	Utility CD	

## IMB-Q770 Micro-ATX Motherboard

Quantity	Item and Part Number	Image
1	One Key Recovery CD	
1	Quick Installation Guide	

**Table 2-1: Packing List**

## 2.4 Optional Items

The following are optional components which may be separately purchased:

Item and Part Number	Image
Dual-port USB cable with bracket <b>(P/N: 19800-003100-100-RS)</b>	
Quad-port RS-232 cable without bracket (40/40/40/40cm) <b>(P/N: 32205-001203-100-RS)</b>	
RS-422/485 cable, 200mm <b>(P/N: 32205-003800-100-RS)</b>	
SATA power cable <b>(P/N: 32102-000100-200-RS)</b>	
PS/2 KB/MS Y-cable with bracket, 220mm <b>(P/N: 19800-000075-RS)</b>	
High performance LGA1155/LGA1156 cooler kit, 1U chassis compatible, 73W <b>(P/N: CF-1156A-RS)</b>	

Item and Part Number	Image
High performance LGA1155/LGA1156 cooler kit, 95W <b>(P/N: CF-1156B-RS)</b>	
LGA1155/LGA1156 cooler kit, 1U chassis compatible, 45W <b>(P/N: CF-1156C-RS)</b>	
LGA1155/LGA1156 cooler kit, 1U chassis compatible, 65W <b>(P/N: CF-1156D-RS)</b>	
20-pin Infineon TPM module, SW management tool, firmware v3.17 <b>(P/N: TPM-IN01-R11)</b>	

**Table 2-2: Optional Items**

Chapter

3

# Connectors

---

### 3.1 Peripheral Interface Connectors

This chapter details all the jumpers and connectors.

#### 3.1.1 IMB-Q770 Layout

The figures below show all the connectors and jumpers.




Figure 3-1: Connectors and Jumpers

### 3.1.2 Peripheral Interface Connectors

The table below lists all the connectors on the board.

Connector	Type	Label
ATX power connector	24-pin ATX	ATX1
Battery connector	battery holder	BAT1
CPU power connector	4-pin Molex	CPU12V1
DDR3 DIMM slots	DDR3 DIMM slot	CHA_DIMM1 CHA_DIMM2 CHB_DIMM1 CHB_DIMM2
Debug port connector	4-pin header	CN2, CN3
Digital I/O connector	26-pin header	DIO1
Fan connector (CPU)	4-pin wafer	CPU_FAN1
Fan connectors (system)	4-pin wafer	SYS_FAN1
Fan connector (system)	3-pin wafer	SYS_FAN2
Fan connector (PCH)	3-pin wafer	PCH_FAN1
Front panel audio connector	10-pin header	FP_AUDIO1
Front panel connector	14-pin header	F_PANEL1
FW programming connector	8-pin header	CN1
Infrared interface connector	5-pin header	IR1
Keyboard/mouse connector	6-pin wafer	KB_MS_CN2
PCIe power connector	4-pin Molex	PCIE_POWER1
PCI slot	PCI slot	PCI1
PCIe x16 slot	PCIe x16 slot	PCIEX16
PCIe x4 slot	PCIe x4 slot	PCIEX4
PCIe x1 slot	PCIe x1 slot	PCIEX1
SATA 3Gb/s drive connectors	14-pin SATA connector	SATA34, SATA56

Connector	Type	Label
SATA 6Gb/s drive connectors	7-pin SATA connector	SATA1, SATA2
Serial port connector, RS-422/485	4-pin wafer	COM2
Serial port connectors, RS-232	40-pin box header	COM3-6, COM7-10
SMBus connector	4-pin wafer	SMBUS_1
SPI ROM connector	6-pin header	JSP1
TPM connector	20-pin header	TPM1
USB connectors	8-pin header	USB3, USB4

**Table 3-1: Peripheral Interface Connectors**

### 3.1.3 External Interface Panel Connectors

The table below lists the connectors on the external I/O panel.

Connector	Type	Label
Audio connector	Audio jack	AUDIO_CV1
DVI and serial port connector	24-pin female, DB-9 male	DVI1_DB9
Ethernet and USB 3.0 ports	RJ-45, USB 3.0	LAN_USB1, LAN_USB2
HDMI ports	HDMI port	HDMI1,HDMI2
USB 2.0 ports	USB 2.0	R_USB1

**Table 3-2: Rear Panel Connectors**

## 3.2 Internal Peripheral Connectors

The section describes all of the connectors on the IMB-Q770.

### 3.2.1 ATX Power Connector


CN Label: ATX1

CN Type: 24-pin ATX

CN Location: See **Figure 3-2**

CN Pinouts: See **Table 3-3**

The ATX power connector connects to an ATX power supply.



**Figure 3-2: ATX Power Connector Pinout Location**

Pin	Description	Pin	Description
1	+3.3V	2	+3.3V
3	GND	4	+5V
5	GND	6	+5V
7	GND	8	PWRGD_PS
9	5VSB	10	+12V
11	+12V	12	+3.3V
13	+3.3V	14	-12V
15	GND	16	IO_PSON#
17	GND	18	GND
19	GND	20	NC
21	+5V	22	+5V
23	+5V	24	GND

**Table 3-3: ATX Power Connector Pinouts**


### 3.2.2 Battery Connector

CN Label: BAT1

CN Type: Battery holder

CN Location: See **Figure 3-3**

This is connected to the system battery. The battery provides power to the system clock to retain the time when power is turned off.



**Figure 3-3: Battery Connector Locations**

### 3.2.3 CPU Power Connector


CN Label: CPU12V1

CN Type: 4-pin Molex

CN Location: See **Figure 3-4**

CN Pinouts: See **Table 3-4**

The CPU power input connector provides power to the CPU.



**Figure 3-4: CPU Power Connector Location**

Pin	Description	Pin	Description
1	GND	2	GND
3	VREG_12V	4	VREG_12V

**Table 3-4: CPU Power Connector Pinouts**

### 3.2.4 DDR3 DIMM Slots

CN Label: CHA\_DIMM1, CHA\_DIMM2, CHB\_DIMM1, CHB\_DIMM2

CN Type: DDR3 DIMM slot

CN Location: See **Figure 3-5**

The DIMM slots are for DDR3 DIMM memory modules.




Figure 3-5: DDR3 DIMM Slot Locations

### 3.2.5 Debug Port Connector

CN Label: **CN2,CN3**  
CN Type: 4-pin header  
CN Location: See **Figure 3-6**  
CN Pinouts: See **Table 3-5**

The debug port connector is for system debug.




Figure 3-6: Debug Port Connector Location

## IMB-Q770 Micro-ATX Motherboard

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	+3.3V	2	GND
3	CSDA_1/2	4	CSCL_1/2

**Table 3-5: Debug Port Connector Pinouts****3.2.6 Digital I/O Connector**


CN Label: DIO1

CN Type: 26-pin header

CN Location: See **Figure 3-7**CN Pinouts: See **Table 3-6**

The digital I/O connector provides programmable input and output for external devices.

The digital I/O provides 12-bit output and 12-bit input.

**Figure 3-7: Digital I/O Connector Location**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	GND	2	+5V
3	D_IN0	4	D_OUT0
5	D_IN1	6	D_OUT1
7	D_IN2	8	D_OUT2
9	D_IN3	10	D_OUT3

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
11	D_8IN0	12	D_8OUT0
13	D_8IN1	14	D_8OUT1
15	D_8IN2	16	D_8OUT2
17	D_8IN3	18	D_8OUT3
19	D_8IN4	20	D_8OUT4
21	D_8IN5	22	D_8OUT5
23	D_8IN6	24	D_8OUT6
25	D_8IN7	26	D_8OUT7

**Table 3-6: Digital I/O Connector Pinouts**

### 3.2.7 Fan Connector (CPU)


CN Label: CPU\_FAN1

CN Type: 4-pin wafer

CN Location: See **Figure 3-8**

CN Pinouts: See **Table 3-7**

The fan connector attaches to a CPU cooling fan.

**Figure 3-8: CPU Fan Connector Location**

## IMB-Q770 Micro-ATX Motherboard

Pin	Description	Pin	Description
1	GND	2	+12 V
3	FANIO1	4	FANOUT1

**Table 3-7: CPU Fan Connector Pinouts**

### 3.2.8 Fan Connector (System)


CN Label: SYS\_FAN1, SYS\_FAN2

CN Type: 4-pin wafer and 3-pin wafer

CN Location: See **Figure 3-9**

CN Pinouts: See **Table 3-8** and **Table 3-9**

The fan connector attaches to a cooling fan.

**Figure 3-9: System Fan Connector Location**

Pin	Description	Pin	Description
1	GND	2	+12 V
3	FANIO3	4	FANOUT3

**Table 3-8: System Fan Connector Pinouts (SYS\_FAN1)**

Pin	Description	Pin	Description
1	NC	2	+12 V
3	GND		

**Table 3-9: System Fan Connector Pinouts (SYS\_FAN2)**

### 3.2.9 Fan Connector (PCH)


CN Label: PCH\_FAN1

CN Type: 3-pin wafer

CN Location: See **Figure 3-10**

CN Pinouts: See **Table 3-10**

The fan connector attaches to a PCH cooling fan.

**Figure 3-10: PCH Fan Connector Location**

Pin	Description	Pin	Description
1	FANIO2	2	FANOUT2
3	GND		

**Table 3-10: PCH Fan Connector Pinouts**

### 3.2.10 Front Panel Audio Connector


CN Label: FP\_AUDIO1

CN Type: 10-pin header

CN Location: See **Figure 3-11**

CN Pinouts: See **Table 3-11**

This connector connects to speakers, a microphone and an audio input.



**Figure 3-11: Front Panel Audio Connector Location**

Pin	Description	Pin	Description
1	MIC2_L	2	GND_AUDIO
3	MIC2_R	4	FP_AUD_DETECT
5	LINE2-R	6	GND_AUDIO
7	F_SENSE	8	NC
9	LINE2_L	10	GND_AUDIO

**Table 3-11: Front Panel Audio Connector Pinouts**

### 3.2.11 Front Panel Connector


CN Label: F\_PANEL1

CN Type: 14-pin header

CN Location: See **Figure 3-12**

CN Pinouts: See **Table 3-12**

The front panel connector connects to the indicator LEDs and buttons on the computer's front panel.



**Figure 3-12: Front Panel Connector Location**

FUNCTION	PIN	DESCRIPTION	FUNCTION	PIN	DESCRIPTION
Power LED	1	ACPILED	Speaker	2	BEEP_PWR
	3	NC		4	NC
	5	GND		6	NC
Power Button	7	PWRBTN_SW#_C		8	PC_BEEP
	9	GND	Reset	10	NC
HDD LED	11	IDELED		12	EXTRST#
	13	IDELED#		14	GND

**Table 3-12: Front Panel Connector Pinouts**

### 3.2.12 FW Programming Connector


CN Label: CN1

CN Type: 8-pin header

CN Location: See **Figure 3-13**

CN Pinouts: See **Table 3-13**

The FW Programming connector is used for programming the firmware.



**Figure 3-13: FW Programming Connector Location**

Pin	Description	Pin	Description
1	+3.3V	2	TDO
3	TDI	4	NC
5	NC	6	TMS
7	GND	8	TCK

**Table 3-13: FW Programming Connector Pinouts**

### 3.2.13 Infrared Interface Connector


CN Label: IR1

CN Type: 5-pin header

CN Location: See **Figure 3-14**

CN Pinouts: See **Table 3-14**

The infrared connector attaches to an infrared receiver for use with remote controls.



**Figure 3-14: Infrared Connector Location**

Pin	Description
1	+5V
2	NC
3	IR_RX
4	GND
5	IR_TX

**Table 3-14: Infrared Connector Pinouts**

### 3.2.14 Keyboard/Mouse Connector

CN Label: KB\_MS\_CN2

CN Type: 6-pin wafer

CN Location: See **Figure 3-15**

CN Pinouts: See **Table 3-15**

The keyboard/mouse connector connects to a PS/2 Y-cable that can be connected to a PS/2 keyboard and mouse.



**Figure 3-15: Keyboard/Mouse Connector Location**

Pin	Description
1	+5V_KBMS
2	MSDATA
3	MSCLK
4	KBDATA
5	KBCLK
6	GND

**Table 3-15: Keyboard/Mouse Connector Pinouts**

### 3.2.15 PCIe Power Connector

CN Label: PCIE\_POWER1

CN Type: 4-pin Molex

CN Location: See **Figure 3-16**

CN Pinouts: See **Table 3-16**

PCIe power connector provides extra power to the PCIe x16 card.




Figure 3-16: PCIe Power Location

Pin	Description
1	+12 V
2	GND
3	GND
4	+5 V

Table 3-16: PCIe Power Pinouts


### 3.2.16 PCI Slot

CN Label: PCI1

CN Type: PCI Slot

CN Location: See **Figure 3-17**

The PCI slot enables a PCI expansion module to be connected to the board.



**Figure 3-17: PCI Slot Locations**


### 3.2.17 PCIe x16 Slot

CN Label: PCIEX16

CN Type: PCIe x16 slot

CN Location: See **Figure 3-18**

The PCIe x16 slot is for PCIe x16 expansion cards.




**Figure 3-18: PCIe x16 Slot Location**

### 3.2.18 PCIe x4 Slot

CN Label: PCIEX4  
CN Type: PCIe x4 slot  
CN Location: See **Figure 3-19**

The PCIe x4 slot is for PCIe x4 expansion cards.




**Figure 3-19: PCIe x4 Slot Locations**

### 3.2.19 PCIe x1 Slot

CN Label: PCIEX1  
CN Type: PCIe x1 slot  
CN Location: See **Figure 3-20**

The PCIe x1 slot is for PCIe x1 expansion cards.

## IMB-Q770 Micro-ATX Motherboard



**Figure 3-20: PCIe x1 Slot Locations**


### 3.2.20 SATA 3Gb/s Drive Connectors

CN Label: SATA34, SATA56

CN Type: 14-pin SATA connector

CN Location: See **Figure 3-21**

The SATA drive connectors can be connected to SATA drives and support up to 3Gb/s data transfer rate.



**Figure 3-21: SATA 3Gb/s Drive Connector Location**


### 3.2.21 SATA 6Gb/s Drive Connectors

CN Label: SATA1, SATA2

CN Type: 7-pin SATA drive connector

CN Location: See **Figure 3-22**

The SATA drive connectors can be connected to SATA drives and support up to 6Gb/s data transfer rate.



**Figure 3-22: SATA 6Gb/s Drive Connector Location**

### 3.2.22 Serial Port Connector, RS-422/485

CN Label: COM2

CN Type: 4-pin wafer

CN Location: See **Figure 3-23**

CN Pinouts: See **Table 3-17**

This connector provides RS-422 or RS-485 communications.



Figure 3-23: RS-422/485 Connector Location

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	RXD485#	2	RXD485
3	TXD485	4	TXD485#

Table 3-17: RS-422/485Connector Pinouts

### 3.2.23 Serial Port Connectors , RS-232

CN Label: COM3-6, COM7-10

CN Type: 40-pin box header

CN Location: See **Figure 3-24**

CN Pinouts: See **Table 3-18**

Each of these connectors provides RS-232 connections.




Figure 3-24: Serial Port Connector Location

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	NDCD3/7#	6	NDSR3/7#
2	NRXD3/7	7	NRTS3/7#
3	NTXD3/7	8	NCTS3/7#
4	NDTR3/7#	9	NRI3/7#
5	GND	10	GND
11	NDCD4/8#	12	NDSR4/8#
13	NRXD4/8	14	NRTS4/8#
15	NTXD4/8	16	NCTS4/8#
17	NDTR4/8#	18	NRI4/8#
19	GND	20	GND
21	NDCD5/9#	22	NDSR5/9#
23	NRXD5/9	24	NRTS5/9#
25	NTXD5/9	26	NCTS5/9#
27	NDTR5/9#	28	NRI5/9#
29	GND	30	GND
31	NDCD6/10#	32	NDSR6/10#
33	NRXD6/10	34	NRTS6/10#
35	NTXD6/10	36	NCTS6/10#
37	NDTR6/10#	38	NRI6/10#
39	GND	40	GND

Table 3-18: Serial Port Connector Pinouts

### 3.2.24 SMBus Connector


CN Label: SMBUS\_1

CN Type: 4-pin wafer

CN Location: See **Figure 3-25**

CN Pinouts: See **Table 3-19**

The SMBus (System Management Bus) connector provides low-speed system management communications.



**Figure 3-25: SMBus Connector Location**


Pin	Description
1	+5V_DUAL
2	SMBCLK_RESUME
3	SMBDATA_RESUME
4	GND

**Table 3-19: SMBus Connector Pinouts**

### 3.2.25 SPIROM Connector

- CN Label: JSPII  
CN Type: 8-pin header  
CN Location: See **Figure 3-26**  
CN Pinouts: See **Table 3-20**

The SPI connector is used to flash the BIOS.



**Figure 3-26: SPI Connector Location**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	+SPI_VCC	2	SPI_CS0#_CN
3	SPI_SO0_CN	4	SPI_CLK0_CN
5	SPI_SIO_CN	6	GND

**Table 3-20: SPI Connector Pinouts**

### 3.2.26 TPM Connector

- CN Label: TPMI


## IMB-Q770 Micro-ATX Motherboard

CN Type: 20-pin header

CN Location: See **Figure 3-27**

CN Pinouts: See **Table 3-21**

The TPM connector connects to a TPM module.



**Figure 3-27: TPM Connector Location**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	TPMPCLK	2	GND
3	LPC_FRAME#	4	NC
5	BUF_PCIRST#	6	+5V
7	LPC_AD3	8	LPC_AD2
9	+3.3V	10	LPC_AD1
11	LPC_AD0	12	GND
13	SMBCLK_RESUME	14	SMBDATA_RESUME
15	+3.3V	16	SERIRQ
17	GND	18	+3.3V
19	LPCPD_N	20	LDRQ0#

**Table 3-21: TPM Connector Pinouts**

### 3.2.27 USB Connectors


CN Label: USB3, USB4

CN Type: 8-pin header

CN Location: See **Figure 3-28**

CN Pinouts: See **Table 3-22**

The USB connectors connect to USB devices. Each pin header provides two USB ports.



**Figure 3-28: USB Connector Pinout Locations**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	+USB_PWR5/2	2	GND
3	USB20_C_N4/8	4	USB20_C_P5/9
5	USB20_C_P4/8	6	USB20_C_N5/9
7	GND	8	+USB_PWR5/2

**Table 3-22: USB Port Connector Pinouts**

### 3.3 External Peripheral Interface Connector Panel

The figure below shows the external peripheral interface connector (EPIC) panel. The EPIC panel consists of the following:




Figure 3-29: External Peripheral Interface Connector

#### 3.3.1 Audio Connector


CN Label: AUDIO\_CV1

CN Type: Audio jack

CN Location: See [Figure 3-29](#)

The audio jacks connect to external audio devices.

- **Line In port (Light Blue):** Connects a CD-ROM, DVD player, or other audio devices.
- **Line Out port (Lime):** Connects to a headphone or a speaker. With multi-channel configurations, this port can also connect to front speakers.
- **Microphone (Pink):** Connects a microphone.



**Figure 3-30: Audio Connector**

### 3.3.2 DVI Connector

CN Label: DVII

CN Type: 24-pin Female

CN Location: See **Figure 3-29**

CN Pinouts: See **Table 3-23**

The DVI (Digital Visual Interface) port connects to a monitor that supports DVI video input.


PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	DVI_TMDS_C_DATA2#	2	DVI_TMDS_C_DATA2
3	GND	4	NC
5	NC	6	DVI_DDC_SCLK
7	DVI_DDC_SDATA	8	CRT_VSYNC
9	DVI_TMDS_C_DATA1#	10	DVI_TMDS_C_DATA1
11	GND	12	NC
13	NC	14	+5V_DVI
15	GND	16	DVI_HPD
17	DVI_TMDS_C_DATA0#	18	DVI_TMDS_C_DATA0
19	GND	20	NC
21	NC	22	GND
23	DVI_TMDS_C_CLK	24	DVI_TMDS_C_CLK#

**Table 3-23: DVI Connector Pinouts**

### 3.3.3 Ethernet and USB Connector

- CN Label: LAN\_USB1, LAN\_USB2, R\_USB1
- CN Type: RJ-45, USB 3.0 and USB 2.0 connectors
- CN Location: See **Figure 3-29**
- CN Pinouts: See **Table 3-25 , Table 3-26 and Table 3-27**

The LAN connector connects to a local network.



**Figure 3-31: Ethernet Connector**

LED	Description	LED	Description
A	on: linked blinking: data is being sent/received	B	off: 10 Mb/s green: 100 Mb/s orange: 1000 Mb/s

**Table 3-24: Connector LEDs**

The USB connector can be connected to a USB device.

PIN	DESCRIPTION	PIN	DESCRIPTION
U1	+USB3_PWR1	U10	+USB3_PWR1
U2	USB20_C_N0	U11	USB20_C_N1
U3	USB20_C_P0	U12	USB20_C_P1
U4	GND	U13	GND
U5	USB3_RX1_DN	U14	USB3_RX2_DN
U6	USB3_RX1_DP	U15	USB3_RX2_DP
U7	GND	U16	GND
U8	USB3_TX1_DN_C	U17	USB3_TX2_DN_C
U9	USB3_TX1_DP_C	U18	USB3_TX2_DP_C
R1	+1.9V_LAN1	L1	L1_1000#
R2	TRD1P0	L2	L1_100#

PIN	DESCRIPTION	PIN	DESCRIPTION
R3	TRD1N0	L3	L1_LINK_ACT#
R4	TRD1P1	L4	+3.3V_LAN1
R5	TRD1N1		
R6	TRD1P2		
R7	TRD1N2		
R8	TRD1P3		
R9	TRD1N3		
R10	GND		

**Table 3-25: LAN and USB Connector Pinouts (LAN\_USB1)**

PIN	DESCRIPTION	PIN	DESCRIPTION
U1	+USB3_PWR2	U10	+USB3_PWR2
U2	USB20_C_N2	U11	USB20_C_N3
U3	USB20_C_P2	U12	USB20_C_P3
U4	GND	U13	GND
U5	USB3_RX3_DN	U14	USB3_RX4_DN
U6	USB3_RX3_DP	U15	USB3_RX4_DP
U7	GND	U16	GND
U8	USB3_TX3_DN_C	U17	USB3_TX4_DN_C
U9	USB3_TX3_DP_C	U18	USB3_TX4_DP_C
R1	+1.05V_LAN2	L1	L2_1000#
R2	TRD2P0	L2	L2_100#
R3	TRD2N0	L3	L2_LINK_ACT#
R4	TRD2P1	L4	+3.3V_LAN
R5	TRD2N1		
R6	TRD2P2		
R7	TRD2N2		
R8	TRD2P3		
R9	TRD2N3		
R10	GND		

**Table 3-26: LAN and USB Connector Pinouts (LAN\_USB2)**

## IMB-Q770 Micro-ATX Motherboard

PIN	DESCRIPTION	PIN	DESCRIPTION
1	+USB_PWR1	2	USB20_C_P12
3	USB20_C_N12	4	GND
5	+USB_PWR1	6	USB20_C_P13
7	USB20_C_N13	8	GND

**Table 3-27: USB Connector Pinouts (R\_USB1)**

## 3.3.4 HDMI Connector

CN Label: **HDMI1, HDMI2**

CN Type: HDMI type A connector

CN Location: See **Figure 3-29**CN Pinouts: See **Table 3-28**

The HDMI (High-Definition Multimedia Interface) connector connects to digital audio or video sources.

Pin	Description	Pin	Description
1	HDMI_DATA2-1/2_L	2	GND
3	HDMI_DATA2#-1/2_L	4	HDMI_DATA1-1/2_L
5	GND	6	HDMI_DATA1#-1/2_L
7	HDMI_DATA0-1/2_L	8	GND
9	HDMI_DATA0#-1/2_L	10	HDMI_CLK-1/2_L
11	GND	12	HDMI_CLK#-1/2_L
13	NC	14	NC
15	HDMI_SCL-1/2	16	HDMI_SDA-1/2
17	GND	18	VCC5
19	HDMI_HPD-1/2		

**Table 3-28: HDMI Connector Pinouts**

## 3.3.5 Serial Port Connector

CN Label: DB9

CN Type: DB-9 connector


CN Location: See **Figure 3-29**

CN Pinouts: See **Table 3-29**

The serial port connects to a RS-232 serial communications device.

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	NDCD1#	2	NRXD1
3	NTXD1	4	NDTR1#
5	GND	6	NDSR1#
7	NRTS1#	8	NCTS1#
9	NRI1#		

**Table 3-29: Serial Port Connector Pinouts**



**Figure 3-32: Serial Port Connector Pinouts**

Chapter

4

# Installation

---

## 4.1 Anti-s static Precautions



### WARNING:

Failure to take ESD precautions during the installation of the IMB-Q770 may result in permanent damage to the IMB-Q770 and severe injury to the user.

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the IMB-Q770. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the IMB-Q770 or any other electrical component is handled, the following anti-static precautions are strictly adhered to.

- ***Wear an anti-static wristband:*** - Wearing a simple anti-static wristband can help to prevent ESD from damaging the board.
- ***Self-grounding:*** - Before handling the board touch any grounded conducting material. During the time the board is handled, frequently touch any conducting materials that are connected to the ground.
- ***Use an anti-static pad:*** When configuring the IMB-Q770, place it on an anti-static pad. This reduces the possibility of ESD damaging the IMB-Q770.
- ***Only handle the edges of the PCB:*** - When handling the PCB, hold the PCB by the edges.

## 4.2 Installation Considerations



### NOTE:

The following installation notices and installation considerations should be read and understood before installation. All installation notices must be strictly adhered to. Failing to adhere to these precautions may lead to severe damage and injury to the person performing the installation.

**WARNING:**

The installation instructions described in this manual should be carefully followed in order to prevent damage to the components and injury to the user.

Before and during the installation please **DO** the following:

- Read the user manual:
  - The user manual provides a complete description of the IMB-Q770 installation instructions and configuration options.
- Wear an electrostatic discharge cuff (ESD):
  - Electronic components are easily damaged by ESD. Wearing an ESD cuff removes ESD from the body and helps prevent ESD damage.
- Place the IMB-Q770 on an antistatic pad:
  - When installing or configuring the motherboard, place it on an antistatic pad. This helps to prevent potential ESD damage.
- Turn all power to the IMB-Q770 off:
  - When working with the IMB-Q770, make sure that it is disconnected from all power supplies and that no electricity is being fed into the system.

Before and during the installation of the IMB-Q770 **DO NOT**:

- Remove any of the stickers on the PCB board. These stickers are required for warranty validation.
- Use the product before verifying all the cables and power connectors are properly connected.
- Allow screws to come in contact with the PCB circuit, connector pins, or its components.

#### 4.2.1 Socket LGA1155 CPU Installation




##### WARNING:

CPU's are expensive and sensitive components. When installing the CPU please be careful not to damage it in anyway. Make sure the CPU is installed properly and ensure the correct cooling kit is properly installed.

DO NOT touch the pins at the bottom of the CPU. When handling the CPU, only hold it on the sides.


To install the CPU, follow the steps below.

**Step 1:** **Disengage the load lever** by pressing the lever down and slightly outward to clear the retention tab. Fully open the lever. See **Figure 4-1**.



**Figure 4-1: Disengage the CPU Socket Load Lever**

**Step 2:** **Open the socket and remove the protective cover.** The black protective cover can be removed by pulling up on the tab labeled "Remove". See **Figure 4-2**.




**Figure 4-2: Remove Protective Cover**

- Step 3:** **Inspect the CPU socket.** Make sure there are no bent pins and make sure the socket contacts are free of foreign material. If any debris is found, remove it with compressed air.
- Step 4:** **Orientate the CPU properly.** The contact array should be facing the CPU socket.
- Step 5:** **Correctly position the CPU.** Match the Pin 1 mark with the cut edge on the CPU socket.
- Step 6:** **Align the CPU pins.** Locate pin 1 and the two orientation notches on the CPU. Carefully match the two orientation notches on the CPU with the socket alignment keys.
- Step 7:** **Insert the CPU.** Gently insert the CPU into the socket. If the CPU pins are properly aligned, the CPU should slide into the CPU socket smoothly. See **Figure 4-3.**



**Figure 4-3: Insert the Socket LGA1155 CPU**

**Step 8: Close the CPU socket.** Close the load plate and pull the load lever back a little to have the load plate be able to secure to the knob. Engage the load lever by pushing it back to its original position (**Figure 4-4**). There will be some resistance, but will not require extreme pressure.



**Figure 4-4: Close the Socket LGA1155**

**Step 9: Connect the 12 V power to the board.** Connect the 12 V power from the power supply to the board.

#### 4.2.2 Socket LGA1155 Cooling Kit Installation



##### WARNING:

DO NOT attempt to install a push-pin cooling fan.

The pre-installed support bracket prevents the board from bending and is ONLY compatible with captive screw type cooling fans.



**Figure 4-5: Cooling Kits (CF-1156A-RS, CF-1156B-RS, CF-1156C-RS, CF-1156D-RS)**

The cooling kit can be bought from IEI. The cooling kit has a heatsink and fan.




##### WARNING:

Do not wipe off (accidentally or otherwise) the pre-sprayed layer of thermal paste on the bottom of the heat sink. The thermal paste between the CPU and the heat sink is important for optimum heat dissipation.

To install the cooling kit, follow the instructions below.

**Step 1:** A cooling kit bracket is pre-installed on the rear of the motherboard. See **Figure 4-6.**




**Figure 4-6: Cooling Kit Support Bracket**

- Step 2:** **Place the cooling kit onto the socket LGA1155 CPU.** Make sure the CPU cable can be properly routed when the cooling kit is installed.
- Step 3:** **Mount the cooling kit.** Gently place the cooling kit on top of the CPU. Make sure the four threaded screws on the corners of the cooling kit properly pass through the holes of the cooling kit bracket.
- Step 4:** **Secure the cooling kit** by fastening the four retention screws of the cooling kit.
- Step 5:** **Connect the fan cable.** Connect the cooling kit fan cable to the fan connector on the IMB-Q770. Carefully route the cable and avoid heat generating chips and fan blades.

#### 4.2.3 DIMM Installation

To install a DIMM, please follow the steps below and refer to **Figure 4-7**.



**Figure 4-7: DIMM Installation**


- Step 1: Open the DIMM socket handles.** Open the two handles outwards as far as they can. See **Figure 4-7**.
- Step 2: Align the DIMM with the socket.** Align the DIMM so the notch on the memory lines up with the notch on the memory socket. See **Figure 4-7**.
- Step 3: Insert the DIMM.** Once aligned, press down until the DIMM is properly seated. Clip the two handles into place. See **Figure 4-7**.
- Step 4: Removing a DIMM.** To remove a DIMM, push both handles outward. The memory module is ejected by a mechanism in the socket.

## 4.3 Jumper Settings



### NOTE:

A jumper is a metal bridge used to close an electrical circuit. It consists of two or three metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To CLOSE/SHORT a jumper means connecting the pins of the jumper with the plastic clip and to OPEN a jumper means removing the plastic clip from a jumper.



The hardware jumpers must be set before installation. Jumpers are shown in **Table 4-1**.

Description	Label	Type
AT/ATX power select	JATX_AT1	2-pin header
Clear CMOS jumper	J_CMOS2	3-pin header

**Table 4-1: Jumpers**

### 4.3.1 AT/ATX Power Select Jumper

Jumper Label: J\_ATX\_AT1

Jumper Type: 2-pin header

Jumper Settings: See **Table 4-2**

Jumper Location: See **Figure 4-8**

The AT/ATX power select jumper specifies the systems power mode as AT or ATX.

Setting	Description
Closed	ATX Mode (Default)
Open	AT Mode

## IMB-Q770 Micro-ATX Motherboard

Setting	Description
---------	-------------

**Table 4-2: AT/ATX Power Select Jumper Settings****Figure 4-8: AT/ATX Power Select Jumper Location****4.3.2 Clear CMOS Jumper**

Jumper Label: J\_CMOS2


Jumper Type: 3-pin header

Jumper Settings: See **Table 4-3**Jumper Location: See **Figure 4-9**

To reset the BIOS, move the jumper to the "Clear BIOS" position for 3 seconds or more, and then move back to the default position.

Setting	Description
1-2	Keep CMOS Setup (Default)
2-3	Clear CMOS Setup

**Table 4-3: Clear BIOS Jumper Settings**



**Figure 4-9: Clear BIOS Jumper Location**

## 4.4 Internal Peripheral Device Connections


This section outlines the installation of peripheral devices to the onboard connectors.

### 4.4.1 SATA Drive Connection

The IMB-Q770 is shipped with four SATA drive cables. To connect the SATA drives to the connectors, please follow the steps below.

**Step 1: Locate the connectors.** The locations of the SATA drive connectors are shown in [Chapter 3](#).


**Step 2: Insert the cable connector.** Press the clip on the connector at the end of the SATA cable and insert the cable connector into the on-board SATA drive connector. See [Figure 4-10](#).



**Figure 4-10: SATA Drive Cable Connection**

**Step 3: Connect the cable to the SATA disk.** Connect the connector on the other end of the cable to the connector at the back of the SATA drive. See **Figure 4-11**.

**Step 4: Connect the SATA power cable (optional).** Connect the SATA power connector to the back of the SATA drive. See **Figure 4-11**.



**Figure 4-11: SATA Power Drive Connection**

The SATA power cable can be bought from IEI. See Optional Items in Section 2.4.

## 4.5 External Peripheral Interface Connection

This section describes connecting devices to the external connectors on the IMB-Q770.

### 4.5.1 Audio Connection

The audio jacks on the external audio connector enable the IMB-Q770 to be connected to a stereo sound setup. Each jack supports both input and output. When connecting a device, the High Definition Audio utility will automatically detect input or output. The light blue (top) audio jack does not support input from a microphone. To install the audio devices, follow the steps below.


**Step 1: Identify the audio plugs.** The plugs on your home theater system or speakers may not match the colors on the rear panel.

**Step 2: Plug the audio plugs into the audio jacks.** Plug the audio plugs into the audio jacks. If the plugs on your speakers are different, an adapter will need to be used to plug them into the audio jacks.

**Line In port (Light Blue):** Connects a CD-ROM, DVD player, or other audio devices.

**Line Out port (Lime):** Connects to a headphone or a speaker.

**Microphone (Pink):** Connects a microphone.



**Figure 4-12: Audio Connector**

**Step 3: Check audio clarity.** Check that the sound is coming through the right speakers by adjusting the balance front to rear and left to right.


#### 4.5.2 DVI Display Device Connection

The IMB-Q770 has a single female DVI-D connector on the external peripheral interface panel. The DVI-D connector is connected to a digital display device. To connect a digital display device to the IMB-Q770, please follow the instructions below.

**Step 1: Locate the DVI-D connector.** The location of the DVI-D connector is shown in another chapter.

**Step 2: Align the DVI-D connector.** Align the male DVI-D connector on the digital display device cable with the female DVI-D connector on the external peripheral interface.

**Step 3: Insert the DVI-D connector** Once the connectors are properly aligned with the male connector, insert the male connector from the digital display device into the female connector on the IMB-Q770. See Figure 4-13.



**Figure 4-13: DVI Connector**

**Secure the connector.** Secure the DVI-D connector from the digital display device to the external interface by tightening the two retention screws on either side of the connector.


#### 4.5.3 HDMI Connection

The HDMI connector transmits a digital signal to compatible HDMI display devices such as a TV or computer screen. To connect the HDMI cable to the IMB-Q770, follow the steps below.

**Step 1: Locate the HDMI connector.** The location is shown in a previous section.

**Step 2: Align the connector.** Align the HDMI connector with the HDMI port. Make sure the orientation of the connector is correct

**Step 3: Insert the HDMI connector.** Gently insert the HDMI connector. The connector should engage with a gentle push. If the connector does not insert easily, check again that the connector is aligned correctly, and that the connector is being inserted with the right way up.




**Figure 4-14: HDMI Connection**

#### 4.5.4 LAN Connection

There are two external RJ-45 LAN connectors. The RJ-45 connectors enable connection to an external network. To connect a LAN cable with an RJ-45 connector, please follow the instructions below.

**Step 1: Locate the RJ-45 connectors.** The locations of the USB connectors are shown in [Chapter 4](#).

**Step 2: Align the connectors.** Align the RJ-45 connector on the LAN cable with one of the RJ-45 connectors on the IMB-Q770. See [Figure 4-15](#).



**Figure 4-15: LAN Connection**


**Step 3: Insert the LAN cable RJ-45 connector.** Once aligned, gently insert the LAN cable RJ-45 connector into the on-board RJ-45 connector.

#### 4.5.5 Serial Device Connection

The IMB-Q770 has a single female DB-9 connector on the external peripheral interface panel for a serial device. Follow the steps below to connect a serial device to the IMB-Q770.

**Step 1: Locate the DB-9 connector.** The location of the DB-9 connector is shown in **Chapter 3**.

**Step 2: Insert the serial connector.** Insert the DB-9 connector of a serial device into the DB-9 connector on the external peripheral interface. See **Figure 4-16**.



**Figure 4-16: Serial Device Connector**


**Step 3: Secure the connector.** Secure the serial device connector to the external interface by tightening the two retention screws on either side of the connector.

#### 4.5.6 USB Connection

The external USB Series "A" receptacle connectors provide easier and quicker access to external USB devices. Follow the steps below to connect USB devices to the IMB-Q770.

**Step 1: Locate the USB Series "A" receptacle connectors.** The location of the USB Series "A" receptacle connectors are shown in **Chapter 3**.

**Step 2: Insert a USB Series "A" plug.** Insert the USB Series "A" plug of a device into the USB Series "A" receptacle on the external peripheral interface. See **Figure 4-17.**



**Figure 4-17: USB Connector**

#### 4.6 Intel® AMT Setup Procedure

The IMB-Q770 is featured with the Intel® Active Management Technology (AMT). To enable the Intel® AMT function, follow the steps below.

- Step 1:** Make sure the memory socket is installed with one DDR3 DIMM.
- Step 2:** Connect an Ethernet cable to the RJ-45 connector which supports AMT.
- Step 3:** The AMI BIOS options regarding the Intel® ME or Intel® AMT must be enabled,
- Step 4:** Properly install the Intel® Management Engine Components drivers from the iAMT Driver & Utility directory in the driver CD. See **Section 6.9**.
- Step 5:** Configure the Intel® Management Engine BIOS extension (MEBx). To get into the Intel® MEBx settings, press **<Ctrl+P>** after a single beep during boot-up process. Enter the Intel® current ME password as it requires (the Intel® default password is **admin**).

**NOTE:**

To change the password, enter a new password following the strong password rule (containing at least one upper case letter, one lower case letter, one digit and one special character, and be at least eight characters).

Chapter

5

# BIOS

---

## 5.1 Introduction

The BIOS is programmed onto the BIOS chip. The BIOS setup program allows changes to certain system settings. This chapter outlines the options that can be changed.

### 5.1.1 Starting Setup

The UEFI BIOS is activated when the computer is turned on. The setup program can be activated in one of two ways.

1. Press the **DELETE** or **F2** key as soon as the system is turned on or
2. Press the **DELETE** or **F2** key when the “**Press Del to enter SETUP**” message appears on the screen.

If the message disappears before the **DELETE** or **F2** key is pressed, restart the computer and try again.

### 5.1.2 Using Setup

Use the arrow keys to highlight items, press **ENTER** to select, use the **PageUp** and **PageDown** keys to change entries, press **F1** for help and press **Esc** to quit. Navigation keys are shown in.

Key	Function
Up arrow	Move to the item above
Down arrow	Move to the item below
Left arrow	Move to the item on the left hand side
Right arrow	Move to the item on the right hand side
+	Increase the numeric value or make changes
-	Decrease the numeric value or make changes
Page up	Move to the next page
Page down	Move to the previous page

Key	Function
Esc	Main Menu – Quit and do not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
F1	General help, only for Status Page Setup Menu and Option Page Setup Menu
F9	Load optimized defaults
F10	Save changes and Exit BIOS

**Table 5-1: BIOS Navigation Keys**

### 5.1.3 Getting Help

When **F1** is pressed a small help window describing the appropriate keys to use and the possible selections for the highlighted item appears. To exit the Help Window press **Esc** or the **F1** key again.

### 5.1.4 Unable to Reboot after Configuration Changes

If the computer cannot boot after changes to the system configuration is made, CMOS defaults. Use the jumper described in Chapter 4.

### 5.1.5 BIOS Menu Bar

The **menu bar** on top of the BIOS screen has the following main items:

- Main – Changes the basic system configuration.
- Advanced – Changes the advanced system settings.
- Chipset – Changes the chipset settings.
- Boot – Changes the system boot configuration.
- Security – Sets User and Supervisor Passwords.
- Save & Exit – Selects exit options and loads default settings

The following sections completely describe the configuration options found in the menu items at the top of the BIOS screen and listed above.

## 5.2 Main

The **Main** BIOS menu (**BIOS Menu 1**) appears when the **BIOS Setup** program is entered.

The **Main** menu gives an overview of the basic system information.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.										
Main	Advanced	Chipset	Boot	Security	Save & Exit					
<b>BIOS Information</b>					Set the Date. Use Tab to switch between Date elements.					
BIOS Vendor	American Megatrends									
Core Version	4.6.5.3									
Compliance	UEFI 2.3; PI 1.2									
Project Version	SA45AR11.ROM									
Build Date	08/28/2012 14:07:08									
<b>Processor Information</b>										
Name	IvyBridge									
Brand String	Genuine Intel(R)CPU									
Frequency	240 MHz									
Processor ID	306a5									
Stepping	K0/M0									
Number of Processors	2Core(s) / 4Thread(s)									
Microcode Revision	7									
GT Info	GT2 (900 MHz)									
IGFX VBIOS Version	2137									
Memory RC Version	1.5.0.0									
Total Memory	1024 MB (DDR3 1333)									
Memory Frequency	1333 MHz									
<b>PCH Information</b>										
Name	PantherPoint									
Stepping	04/C1									
TXT Capability of Platform/PCH	Unsupported									
LAN PHY Revision	C0									
ME FW Version	8.0.4.1441									
ME Firmware SKU	5MB									
<b>SPI Clock Frequency</b>										
DOFR Support	Supported									
Read Status Clock Frequency	33 MHz									
Write Status Clock Frequency	33 MHz									
Fast Read Status Clock Frequency	33 MHz									
System Date	[Wed 08/29/2012]									
System Time	[19:43:27]									
Access Level	Administrator									
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.										
<b>BIOS Menu 1: Main</b>										

The Main menu lists the following system details:

- BIOS Information
- Processor Information
- Memory Information
- PCH Information
- SPI Clock Frequency

The Main menu has two user configurable fields:

➔ System Date [xx/xx/xx]

Use the **System Date** option to set the system date. Manually enter the day, month and year.

➔ System Time [xx:xx:xx]

Use the **System Time** option to set the system time. Manually enter the hours, minutes and seconds.

### 5.3 Advanced

Use the **Advanced** menu (**BIOS Menu 2**) to configure the CPU and peripheral devices through the following sub-menus:




#### WARNING!


Setting the wrong values in the sections below may cause the system to malfunction. Make sure that the settings made are compatible with the hardware.

---

## IMB-Q770 Micro-ATX Motherboard

**BIOS Menu 2: Advanced****5.3.1 ACPI Configuration**

The **ACPI Configuration** menu (**BIOS Menu 3**) configures the Advanced Configuration and Power Interface (ACPI) options.

**BIOS Menu 3: ACPI Configuration**


→ ACPI Sleep State [S1 (CPU Stop Clock)]

Use the **ACPI Sleep State** option to specify the sleep state the system enters when it is not being used.

- **S1 (CPU Stop DEFAULT Clock)** The system enters S1 (POS) sleep state. The system appears off. The CPU is stopped; RAM is refreshed; the system is running in a low power mode.
- **S3 (Suspend to RAM)** The caches are flushed and the CPU is powered off. Power to the RAM is maintained. The computer returns slower to a working state, but more power is saved.

### 5.3.2 RTC Wake Settings

The **RTC Wake Settings** menu (**BIOS Menu 4**) configures RTC wake event.



#### BIOS Menu 4: RTC Wake Settings

→ Wake system with Fixed Time [Disabled]

Use the **Wake system with Fixed Time** option to enable or disable the system wake on alarm event.

→ **Disabled**    **DEFAULT**    The real time clock (RTC) cannot generate a wake event

→ **Enabled**    If selected, the **Wake up every day** option appears allowing you to enable to disable the system to wake every day at the specified time. Besides, the following options appear with values that can be selected:

    Wake up date

    Wake up hour

    Wake up minute

    Wake up second

After setting the alarm, the computer turns itself on from a suspend state when the alarm goes off.

### 5.3.3 Trusted Computing

Use the **Trusted Computing** menu (**BIOS Menu 5**) to configure settings related to the Trusted Computing Group (TCG) Trusted Platform Module (TPM).

Aptio Setup Utility - Copyright (c) 2011 American Megatrends, Inc.

Advanced

Configuration	
Security Device Support	[Disable]
Current Status Information	
NO Security Device Found	

Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available.

---

↔: Select Screen  
↑ ↓: Select Item  
Enter:Select  
F1 General Help  
F2 Previous Values  
F3 Optimized  
Defaults  
F4 Save  
ESC Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

### BIOS Menu 5: Trusted Computing


- Security Device Support [Disable]

Use the **Security Device Support** option to configure support for the TPM.

- **Disable** DEFAULT TPM support is disabled.
- **Enable** TPM support is enabled.

### 5.3.4 CPU Configuration

Use the **CPU Configuration** menu (**BIOS Menu 6**) to view detailed CPU specifications and configure the CPU.



#### BIOS Menu 6: CPU Configuration

The CPU Configuration menu (**BIOS Menu 6**) lists the following CPU details:

- Processor Type: Lists the brand name of the CPU being used.
- CPU Signature: Lists the CPU signature value.
- Microcode Patch: Lists the microcode patch being used.
- Max CPU Speed: Lists the maximum CPU processing speed.
- Min CPU Speed: Lists the minimum CPU processing speed.
- CPU Speed: Lists the CPU processing speed.
- Processor Core: Lists the number of the processor cores.
- Intel HT Technology: Indicates if Intel HT Technology is supported by the CPU.

- Intel VT-x Technology: Indicates if Intel VT-x Technology is supported by the CPU.
  - Intel SMX Technology: Indicates if Intel SMX Technology is supported by the CPU.
  - 64-bit: Indicates if 64-bit is supported by the CPU.
  - L1 Data Cache: Lists the amount of data storage space on the L1 cache.
  - L1 Code Cache: Lists the amount of code storage space on the L1 cache.
  - L2 Cache: Lists the amount of storage space on the L2 cache.
  - L3 Cache: Lists the amount of storage space on the L3 cache.

→ Hyper-Threading [Enabled]

Use the Hyper-Threading option to enable or disable the CPU hyper threading function.

- ➔ **Disabled** Disables the use of hyper threading technology
- ➔ **Enabled** **DEFAULT** Enables the use of hyper threading technology


→ Intel Virtualization Technology [Disabled]

Use the **Intel Virtualization Technology** option to enable or disable virtualization on the system. When combined with third party software, Intel Virtualization technology allows several OSs to run on the same system at the same time.

- ➔ **Disabled**      **DEFAULT**      Disables Intel Virtualization Technology.
- ➔ **Enabled**      Enables Intel Virtualization Technology.

### 5.3.5 SATA Configuration

Use the **SATA Configuration** menu (**BIOS Menu 7**) to change and/or set the configuration of the SATA devices installed in the system.



#### BIOS Menu 7: SATA Configuration

##### → SATA Controller [Enabled]

Use the **SATA Controller** option to enable or disable the SATA device.

→ **Disabled** Disables the SATA device.

→ **Enabled** **DEFAULT** Enables the SATA device.

##### → SATA Mode Selection [IDE]

Use the **SATA Mode Selection** option to configure SATA devices as normal IDE devices.


→ **IDE** **DEFAULT** Configures SATA devices as normal IDE device.

→ **AHCI** Configures SATA devices as AHCI device.

→ **RAID** Configures SATA devices as RAID device.

### 5.3.6 Intel(R) Rapid Start Technology

Use the **Intel(R) Rapid Start Technology** menu (**BIOS Menu 8**) to configure Intel® Rapid Start Technology support.



#### BIOS Menu 8: Intel(R) Rapid Start Technology

→ Intel(R) Rapid Start Technology [Disabled]

Use **Intel(R) Rapid Start Technology** option to configure Intel® Rapid Start Technology function.

→ **Disabled**    **DEFAULT**    Intel® Rapid Start Technology is disabled

### 5.3.7 Intel TXT(LT) Configuration

Use the **Intel TXT(LT) Configuration** menu (**BIOS Menu 9**) to configure Intel® Trusted Execution Technology support.

## IMB-Q770 Micro-ATX Motherboard

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Advanced		
----------	--	--

Intel Trusted Execution Technology Configuration

Intel TXT support only can be enabled/disabled if SMX is enabled. VT and VT-d support must also be enabled prior to TXT.

Secure Mode Extensons (SMX)	Disabled	----- ←→: Select Screen ↑↓: Select Item EnterSelect + - Change Opt. F1 General Help F2 Previous Values F3 Optimized Defaults F4 Save & Exit ESC Exit
Intel TXT(LT) Support	[Disabled]	

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

**BIOS Menu 9: Intel TXT(LT) Configuration**

## 5.3.8 AMT Configuration

The **AMT Configuration** menu (**BIOS Menu 10**) allows the advanced power management options to be configured.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

Advanced		
----------	--	--

Intel AMT	[Enabled]	Enable/Disable Intel (R) Active Management Technology BIOS Extension. Note: iAMT H/W is always enabled. This option just controls the BIOS extension execution. If enabled, this requires additional firmware in the SPI device.
Unconfigure AMT/ME	[Disabled]	

-----  
 ←→: Select Screen  
 ↑↓: Select Item  
 EnterSelect  
 F1 General Help  
 F2 Previous Values  
 F3 Optimized Defaults  
 F4 Save  
 ESC Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

**BIOS Menu 10: AMT Configuration**

→ Intel AMT [Enabled]

Use **Intel AMT** option to enable or disable the Intel® AMT function.

→ **Disabled** Intel® AMT is disabled

→ **Enabled** **DEFAULT** Intel® AMT is enabled

→ Unconfigure AMT/ME [Disabled]


Use the **Unconfigure AMT/ME** option to perform AMT/ME unconfigure without password operation.

→ **Disabled** **DEFAULT** Not perform AMT/ME unconfigure

→ **Enabled** To perform AMT/ME unconfigure

### 5.3.9 USB Configuration

Use the **USB Configuration** menu (**BIOS Menu 11**) to read USB configuration information and configure the USB settings.



**BIOS Menu 11: USB Configuration**

## IMB-Q770 Micro-ATX Motherboard

## → USB Devices

The **USB Devices Enabled** field lists the USB devices that are enabled on the system

## → Legacy USB Support [Enabled]

Use the **Legacy USB Support** BIOS option to enable USB mouse and USB keyboard support. Normally if this option is not enabled, any attached USB mouse or USB keyboard does not become available until a USB compatible operating system is fully booted with all USB drivers loaded. When this option is enabled, any attached USB mouse or USB keyboard can control the system even when there is no USB driver loaded onto the system.

- **Enabled**      **DEFAULT**      Legacy USB support enabled
- **Disabled**      Legacy USB support disabled
- **Auto**      Legacy USB support disabled if no USB devices are connected

## 5.3.10 F81216 Second Super IO Configuration

The **F81216 Second Super IO Configuration (BIOS Menu 12)** displays IO chip type and the submenus for configuring the external SATA ports 7, 8, 9, and 10.

Aptio Setup Utility - Copyright (c) 2011 American Megatrends, Inc.

Advanced

F81216 Second Super IO Configuration	
F81216 Second Super IO Chip	F81216 SecondIO
> Serial Port 7 Configuration	
> Serial Port 8 Configuration	
> Serial Port 9 Configuration	
> Serial Port 10 Configuration	

Set Parameters of Serial Port 7 (COMG)

---

←→: Select Screen  
↑↓: Select Item  
EnterSelect  
+/-: Change Opt.  
F1: General Help  
F2: Previous Values  
F3: Optimized Defaults  
F4: Save & Exit  
ESC: Exit

Version 2.11.1210. Copyright (C) 2011 American Megatrends, Inc.

**BIOS Menu 12: Secondary Super IO Configuration**

### 5.3.10.1 Serial Port n Configuration

Use the **Serial Port n Configuration** menu (**BIOS Menu 13**) to configure the serial port n.

Aptio Setup Utility - Copyright (c) 2009 American Megatrends, Inc.

Advanced

Serial Port 7 Configuration	
Serial Port	[Enabled]
Device Settings	IO=2B0h; IRQ=11
Change Settings	[Auto]
Device Mode	[Serial Port Functi...]

Enable or Disable Serial Port (COM)

---

←→: Select Screen  
↑↓: Select Item  
EnterSelect  
F1 General Help  
F2 Previous Values  
F3 Optimized  
Defaults  
F4 Save  
ESC Exit

Version 2.00.1201. Copyright (C) 2009 American Megatrends, Inc.

**BIOS Menu 13: Serial Port n Configuration Menu**

### 5.3.10.2 Serial Port 7 Configuration

#### → Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

→ **Disabled** Disable the serial port

→ **Enabled** **DEFAULT** Enable the serial port

#### → Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

→ **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.

→ **IO=2B0h;**  
**IRQ=11** Serial Port I/O port address is 2B0h and the interrupt address is IRQ11

→ **IO=2B0h;**  
**IRQ=10, 11** Serial Port I/O port address is 2B0h and the interrupt address is IRQ10, 11

→ **IO=2B8h;**  
**IRQ=10, 11** Serial Port I/O port address is 2B8h and the interrupt address is IRQ10, 11

→ **IO=2C0h;**  
**IRQ=10, 11** Serial Port I/O port address is 2C0h and the interrupt address is IRQ10, 11

→ **IO=2C8h;**  
**IRQ=10, 11** Serial Port I/O port address is 2C8h and the interrupt address is IRQ10, 11

#### → Device Mode [Normal]

Use the **Device Mode** option to change the serial port mode.

→ **Serial Port** **DEFAULT** Enables the serial port to function in serial port function mode.

- ➔ **IR Mode, Pulse 1.6us, Full Duplex** Enables the serial port to function in IR mode, pulse 1.6 us at full duplex.
- ➔ **IR Mode, Pulse 1.6us, Half Duplex** Enables the serial port to function in IR mode, pulse 1.6 us at half duplex.
- ➔ **IR Mode, Pulse 3/16 Bit Time, Full Duplex** Enables the serial port to function in IR mode, pulse 3/16 bit time at full duplex.
- ➔ **IR Mode, Pulse 3/16 Bit Time, Half Duplex** Enables the serial port to function in IR mode, pulse 3/16 bit time at half duplex.

### 5.3.10.3 Serial Port 8 Configuration

#### ➔ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled** Disable the serial port
- ➔ **Enabled    DEFAULT** Enable the serial port

#### ➔ Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- ➔ **Auto    DEFAULT** The serial port IO port address and interrupt address are automatically detected.
- ➔ **IO=2B8h;  
IRQ=11** Serial Port I/O port address is 2B8h and the interrupt address is IRQ11
- ➔ **IO=2B0h;  
IRQ=10, 11** Serial Port I/O port address is 2B0h and the interrupt address is IRQ10, 11
- ➔ **IO=2B8h;  
IRQ=10, 11** Serial Port I/O port address is 2B8h and the interrupt address is IRQ10, 11

- ➔ IO=2C0h;  
IRQ=10, 11      Serial Port I/O port address is 2C0h and the interrupt address is IRQ10, 11
- ➔ IO=2C8h;  
IRQ=10, 11      Serial Port I/O port address is 2C8h and the interrupt address is IRQ10, 11

#### 5.3.10.4 Serial Port 9 Configuration

- ➔ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled**      Disable the serial port
- ➔ **Enabled**      **DEFAULT**      Enable the serial port

- ➔ Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- ➔ **Auto**      **DEFAULT**      The serial port IO port address and interrupt address are automatically detected.
- ➔ IO=2C0h;  
IRQ=11      Serial Port I/O port address is 2C0h and the interrupt address is IRQ11
- ➔ IO=2B0h;  
IRQ=10, 11      Serial Port I/O port address is 2B0h and the interrupt address is IRQ10, 11
- ➔ IO=2B8h;  
IRQ=10, 11      Serial Port I/O port address is 2B8h and the interrupt address is IRQ10, 11
- ➔ IO=2C0h;  
IRQ=10, 11      Serial Port I/O port address is 2C0h and the interrupt address is IRQ10, 11
- ➔ IO=2C8h;  
IRQ=10, 11      Serial Port I/O port address is 2C8h and the interrupt address is IRQ10, 11

### 5.3.10.5 Serial Port 10 Configuration

#### → Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

→ **Disabled** Disable the serial port

→ **Enabled** **DEFAULT** Enable the serial port

#### → Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

→ **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.

→ **IO=2C8h;**  
**IRQ=11** Serial Port I/O port address is 2C8h and the interrupt address is IRQ11

→ **IO=2B0h;**  
**IRQ=10, 11** Serial Port I/O port address is 2B0h and the interrupt address is IRQ10, 11


→ **IO=2B8h;**  
**IRQ=10, 11** Serial Port I/O port address is 2B8h and the interrupt address is IRQ10, 11

→ **IO=2C0h;**  
**IRQ=10, 11** Serial Port I/O port address is 2C0h and the interrupt address is IRQ10, 11

→ **IO=2C8h;**  
**IRQ=10, 11** Serial Port I/O port address is 2C8h and the interrupt address is IRQ10, 11

### 5.3.11 F81866 Super IO Configuration


Use the **F81866 Super IO Configuration** menu (**BIOS Menu 14**) to set or change the configurations for the serial ports.



**BIOS Menu 14: Super IO Configuration**

#### 5.3.11.1 Serial Port n Configuration

Use the **Serial Port n Configuration** menu (**BIOS Menu 15**) to configure the serial port n.



**BIOS Menu 15: Serial Port n Configuration Menu**

### 5.3.11.1.1 Serial Port 1 Configuration

#### → Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

→ **Disabled** Disable the serial port

→ **Enabled** **DEFAULT** Enable the serial port

#### → Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

→ **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.

→ **IO=3F8h;** Serial Port I/O port address is 3F8h and the interrupt address is IRQ4

→ **IO=3E8h;** Serial Port I/O port address is 3E8h and the interrupt address is IRQ3, 4

→ **IO=2F8h;** Serial Port I/O port address is 2F8h and the interrupt address is IRQ3, 4

### 5.3.11.1.2 Serial Port 2 Configuration

#### → Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

→ **Disabled** Disable the serial port

→ **Enabled** **DEFAULT** Enable the serial port

#### → Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- ➔ **Auto**      **DEFAULT**      The serial port IO port address and interrupt address are automatically detected.
- ➔ **IO=2F8h;  
IRQ=3**      Serial Port I/O port address is 2F8h and the interrupt address is IRQ3
- ➔ **IO=3F8h;  
IRQ=3, 4**      Serial Port I/O port address is 3F8h and the interrupt address is IRQ3, 4
- ➔ **IO=2F8h;  
IRQ=3, 4**      Serial Port I/O port address is 2F8h and the interrupt address is IRQ3, 4

#### 5.3.11.1.3 Serial Port 3 Configuration

##### ➔ **Serial Port [Enabled]**

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled**      Disable the serial port
- ➔ **Enabled**      **DEFAULT**      Enable the serial port

##### ➔ **Change Settings [Auto]**

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- ➔ **Auto**      **DEFAULT**      The serial port IO port address and interrupt address are automatically detected.
- ➔ **IO=2D0h;  
IRQ=10**      Serial Port I/O port address is 2D0h and the interrupt address is IRQ10
- ➔ **IO=2D0h;  
IRQ=10, 11**      Serial Port I/O port address is 2D0h and the interrupt address is IRQ10, 11
- ➔ **IO=2D8h;  
IRQ=10, 11**      Serial Port I/O port address is 2D8h and the interrupt address is IRQ10, 11
- ➔ **IO=2E0h;  
IRQ=10, 11**      Serial Port I/O port address is 2E0h and the interrupt address is IRQ10, 11

- ➔ **IO=2E8h;** Serial Port I/O port address is 2E8h and the interrupt address is IRQ10, 11
- IRQ=10, 11**

#### 5.3.11.1.4 Serial Port 4 Configuration

- ➔ **Serial Port [Enabled]**

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled** Disable the serial port
- ➔ **Enabled    DEFAULT** Enable the serial port

- ➔ **Change Settings [Auto]**

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- ➔ **Auto    DEFAULT** The serial port IO port address and interrupt address are automatically detected.
- ➔ **IO=2D8h;  
IRQ=10** Serial Port I/O port address is 2D8h and the interrupt address is IRQ10
- ➔ **IO=2D0h;  
IRQ=10, 11** Serial Port I/O port address is 2D0h and the interrupt address is IRQ10, 11
- ➔ **IO=2D8h;  
IRQ=10, 11** Serial Port I/O port address is 2D8h and the interrupt address is IRQ10, 11
- ➔ **IO=2E0h;  
IRQ=10, 11** Serial Port I/O port address is 2E0h and the interrupt address is IRQ10, 11
- ➔ **IO=2E8h;  
IRQ=10, 11** Serial Port I/O port address is 2E8h and the interrupt address is IRQ10, 11

### 5.3.11.1.5 Serial Port 5 Configuration

#### → Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

→ **Disabled** Disable the serial port

→ **Enabled** **DEFAULT** Enable the serial port

#### → Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

→ **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.

→ **IO=2E0h;**  
**IRQ=10** Serial Port I/O port address is 2E0h and the interrupt address is IRQ10

→ **IO=2D0h;**  
**IRQ=10, 11** Serial Port I/O port address is 2D0h and the interrupt address is IRQ10, 11

→ **IO=2D8h;**  
**IRQ=10, 11** Serial Port I/O port address is 2D8h and the interrupt address is IRQ10, 11

→ **IO=2E0h;**  
**IRQ=10, 11** Serial Port I/O port address is 2E0h and the interrupt address is IRQ10, 11

→ **IO=2E8h;**  
**IRQ=10, 11** Serial Port I/O port address is 2E8h and the interrupt address is IRQ10, 11

### 5.3.11.1.6 Serial Port 6 Configuration

#### → Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

→ **Disabled** Disable the serial port

→ **Enabled** **DEFAULT** Enable the serial port

→ **Change Settings [Auto]**

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

→ **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.

→ **IO=2E8h;  
IRQ=10** Serial Port I/O port address is 2E8h and the interrupt address is IRQ10

→ **IO=2D0h;  
IRQ=10, 11** Serial Port I/O port address is 2D0h and the interrupt address is IRQ10, 11


→ **IO=2D8h;  
IRQ=10, 11** Serial Port I/O port address is 2D8h and the interrupt address is IRQ10, 11

→ **IO=2E0h;  
IRQ=10, 11** Serial Port I/O port address is 2E0h and the interrupt address is IRQ10, 11

→ **IO=2E8h;  
IRQ=10, 11** Serial Port I/O port address is 2E8h and the interrupt address is IRQ10, 11

### 5.3.12 F81866 H/W Monitor

The **F8186 H/W Monitor** menu (**BIOS Menu 16**) shows the operating temperature, fan speeds and system voltages.



#### BIOS Menu 16: Hardware Health Configuration

##### ➔ PC Health Status

The following system parameters and values are shown. The system parameters that are monitored are:

- System Temperatures:
  - CPU Temperature
  - SYS Temperature
  - CPH Temperature
- Fan Speeds:
  - CPU\_FAN1 Speed
  - SYS\_FAN1 Speed
  - SYS\_FAN2 Speed
- Voltages:

- VCC3V
- +CPU\_VCCIO
- +5V
- +12V
- +1.5V\_DDR3
- VSB5V
- VSB3V
- VBAT

➔ Smart Fan Function [Enabled]


Use the **Smart Fan Function** option to enable or disable the smart fan function.

- ➔ **Disabled** Disables the smart fan function.
- ➔ **Enabled** **DEFAULT** Enables the smart fan function.

#### 5.3.12.1 Smart Fan Mode Configuration

Use the **Smart Fan Mode Configuration** submenu (**BIOS Menu 17**) to configure the smart fan temperature and speed settings.

## IMB-Q770 Micro-ATX Motherboard

**BIOS Menu 17: FAN 1 Configuration**

- CPU\_FAN1 Smart Fan Control [Auto Duty-Cycle Mode]

Use the **CPU\_FAN1 Smart Fan Control** option to configure the CPU Smart Fan.

- **Manual Duty Mode** The fan spins at the speed set in Manual by Duty Cycle settings
- **Auto Duty-Cycle DEFAULT Mode** The fan adjusts its speed using Auto by Duty-Cycle settings

- CPU Temperature n

Use the + or – key to change the fan **CPU Temperature n** value. Enter a decimal number between 1 and 100.

- PCH\_FAN1 Smart Fan Control [Auto Duty-Cycle Mode]

Use the **PCH\_FAN1 Smart Fan Control** option to configure the PCH Smart Fan.

- **Manual Duty Mode** The fan spins at the speed set in Manual by Duty Cycle settings

- ➔ **Auto Duty-Cycle DEFAULT** The fan adjusts its speed using Auto by Duty-Cycle settings

- ➔ **PCH Temperature n**

Use the + or – key to change the fan **PCH Temperature n** value. Enter a decimal number between 1 and 100.

- ➔ **SYS\_FAN1 Smart Fan Control [Auto Duty-Cycle Mode]**

Use the **SYS\_FAN1 Smart Fan Control** option to configure the System Smart Fan.

- ➔ **Manual Duty Mode** The fan spins at the speed set in Manual by Duty Cycle settings

- ➔ **Auto Duty-Cycle DEFAULT** The fan adjusts its speed using Auto by Duty-Cycle settings

- ➔ **SYS Temperature n**

Use the + or – key to change the fan **SYS Temperature n** value. Enter a decimal number between 1 and 100.

### 5.3.13 Serial Port Console Redirection

The **Serial Port Console Redirection** menu (**BIOS Menu 18**) allows the console redirection options to be configured. Console redirection allows users to maintain a system remotely by re-directing keyboard input and text output through the serial port.

## IMB-Q770 Micro-ATX Motherboard

Aptio Setup Utility - Copyright (c) 2011 American Megatrends, Inc.

**Advanced**

COM1	Console Redirection [Disabled]	Console Redirection Enable or Disable
> Console Redirection Settings		
COM2	Console Redirection [Disabled]	
> Console Redirection Settings		
COM3	Console Redirection [Disabled]	
> Console Redirection Settings		
COM4	Console Redirection [Disabled]	
> Console Redirection Settings		
COM5	Console Redirection [Disabled]	
> Console Redirection Settings		
COM6	Console Redirection [Disabled]	
> Console Redirection Settings		
COM7	Console Redirection [Disabled]	
> Console Redirection Settings		
COM8	Console Redirection [Disabled]	
> Console Redirection Settings		
COM9	Console Redirection [Disabled]	
> Console Redirection Settings		
COM10	Console Redirection [Disabled]	
> Console Redirection Settings		
COMA(Pci Bus0, Dev0,Func0) (Disabled)		
Console Redirection Port is Disabled		

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

←→: Select Screen  
 ↑↓: Select Item  
 Enter: Select  
 F1 General Help  
 F2 Previous Values  
 F3 Optimized  
 Defaults  
 F4 Save  
 ESC Exit

**BIOS Menu 18: Serial Port Console Redirection**


→ Console Redirection [Disabled]

Use **Console Redirection** option to enable or disable the console redirection function.

- ➔ **Disabled**      **DEFAULT**      Disabled the console redirection function
- ➔ **Enabled**      Enabled the console redirection function

### 5.3.13.1 Console Redirection Settings

The **Console Redirection Settings** menu (**BIOS Menu 19**) allows the console redirection options to be configured. The option is active when Console Redirection option is enabled.



#### BIOS Menu 19: Console Redirection Settings

- ➔ Terminal Type [ANSI]

Use the **Terminal Type** option to specify the remote terminal type.

- ➔ **VT100**      The target terminal type is VT100
- ➔ **VT100+**      The target terminal type is VT100+
- ➔ **VT-UTF8**      The target terminal type is VT-UTF8
- ➔ **ANSI**      **DEFAULT**      The target terminal type is ANSI

## IMB-Q770 Micro-ATX Motherboard

## → Bits per second [115200]

Use the **Bits per second** option to specify the serial port transmission speed. The speed must match the other side. Long or noisy lines may require lower speeds.

- **9600** Sets the serial port transmission speed at 9600.
- **19200** Sets the serial port transmission speed at 19200.
- **38400** Sets the serial port transmission speed at 38400.
- **57600** Sets the serial port transmission speed at 57600.
- **115200** **DEFAULT** Sets the serial port transmission speed at 115200.

## → Data Bits [8]

Use the **Data Bits** option to specify the number of data bits.

- **7** Sets the data bits at 7.
- **8** **DEFAULT** Sets the data bits at 8.

## → Parity [None]

Use the **Parity** option to specify the parity bit that can be sent with the data bits for detecting the transmission errors.

- **None** **DEFAULT** No parity bit is sent with the data bits.
- **Even** The parity bit is 0 if the number of ones in the data bits is even.
- **Odd** The parity bit is 0 if the number of ones in the data bits is odd.
- **Mark** The parity bit is always 1. This option does not provide error detection.
- **Space** The parity bit is always 0. This option does not provide error detection.


→ Stop Bits [1]

Use the **Stop Bits** option to specify the number of stop bits used to indicate the end of a serial data packet. Communication with slow devices may require more than 1 stop bit.

- 1      **DEFAULT**      Sets the number of stop bits at 1.
- 2      Sets the number of stop bits at 2.

### 5.3.14 IEI Feature

Use the **IEI Feature** menu (**BIOS Menu 20**) to configure One Key Recovery function.



#### BIOS Menu 20: IEI Feature

→ Auto Recovery Function [Disabled]

Use the **Auto Recovery Function** BIOS option to enable or disable the auto recovery function of the IEI One Key Recovery.

- **Disabled**      **DEFAULT**      Auto recovery function disabled
- **Enabled**      Auto recovery function enabled


## 5.4 Chipset

Use the **Chipset** menu (**BIOS Menu 21**) to access the PCH-IO and System Agent (SA) configuration menus.



### WARNING!


Setting the wrong values for the Chipset BIOS selections in the Chipset BIOS menu may cause the system to malfunction.



**BIOS Menu 21: Chipset**

### 5.4.1 PCH-IO Configuration

Use the **PCH-IO Configuration** menu (**BIOS Menu 22**) to configure the PCH chipset.



#### BIOS Menu 22:PCH-IO Configuration

##### → Restore on AC Power Loss [Last State]

Use the **Restore on AC Power Loss** BIOS option to specify what state the system returns to if there is a sudden loss of power to the system.

- **Power Off** The system remains turned off
- **Power On** The system turns on
- **Last State** **DEFAULT** The system returns to its previous state. If it was on, it turns itself on. If it was off, it remains off.


##### → Power Saving Function(ERP) [Dis abled]

Use the **Power Saving Function** BIOS option to enable or disable the power saving function.

- ➔ **Disabled**      **DEFAULT**      Power saving function is disabled.
- ➔ **Enabled**      Power saving function is enabled. It will reduce power consumption when the system is off.

#### 5.4.1.1 PCH Azalia Configuration

Use the **PCH Azalia Configuration** submenu (**BIOS Menu 23**) to configure the PCH Azalia device.



#### BIOS Menu 23:PCH-IO Configuration

- ➔ **Azalia [Enabled]**

Use the **Azalia** option to enable or disable the High Definition Audio controller.

- ➔ **Disabled**      The onboard High Definition Audio controller is disabled
- ➔ **Enabled**      **DEFAULT**      The onboard High Definition Audio controller automatically detected and enabled

→ Azalia internal HDMI Codec [Enabled]

Use the **Azalia internal HDMI Codec** option to enable or disable the internal HDMI codec for High Definition Audio.

- **Disabled** Disable internal HDMI codec for High Definition Audio
- **Enabled** **DEFAULT** Enable internal HDMI codec for High Definition Audio

→ Azalia HDMI1 Codec [Enabled]

Use the **Azalia HDMI1 Codec** option to enable or disable the HDMI 1 for High Definition Audio.

- **Disabled** Disable HDMI 1 for High Definition Audio
- **Enabled** **DEFAULT** Enable HDMI 1 for High Definition Audio

→ Azalia HDMI2 Codec [Enabled]


Use the **Azalia HDMI2 Codec** option to enable or disable the HDMI 2 for High Definition Audio.

- **Disabled** Disable HDMI 2 for High Definition Audio
- **Enabled** **DEFAULT** Enable HDMI 2 for High Definition Audio


#### 5.4.2 System Agent (SA) Configuration

Use the **System Agent (SA) Configuration** menu (**BIOS Menu 24**) to configure the graphics setting and memory setting.

## IMB-Q770 Micro-ATX Motherboard

**BIOS Menu 24: System Agent (SA) Configuration****5.4.2.1 Graphics Configuration**

Use the **Graphics Configuration** menu (**BIOS Menu 25**) to configure the video device connected to the system.

**BIOS Menu 25: Graphics Configuration**

→ Primary Display [Auto]

Use the **Primary Display** option to select the primary graphics controller the system uses.

The following options are available:

- Auto **Default**
- IGFX
- PEG
- PCI

→ DVMT Pre-Allocated [256MB]

Use the **DVMT Pre-Allocated** option to set the amount of system memory allocated to the integrated graphics processor when the system boots. The system memory allocated can then only be used as graphics memory, and is no longer available to applications or the operating system. Configuration options are listed below:

- 32M
- 64M
- 128M
- 256M **Default**
- 512M

→ DVMT Total Gfx Mem [MAX]


Use the **DVMT Total Gfx Mem** option to select DVMT5.0 total graphic memory size used by the internal graphic device. The following options are available:

- 128M
- 256M
- MAX **Default**

#### 5.4.2.1.1 LCD Control

Use the **LCD Control** menu (**BIOS Menu 26**) to configure the video device connected to the system.

## IMB-Q770 Micro-ATX Motherboard

**BIOS Menu 26: Graphics Configuration**

- Primary IGFX Boot Display [VBIOS Default]

Use the **Primary IGFX Boot Display** option to select the primary graphics controller the system uses. The following options are available:

- VBIOS Default      **Default**
- DVI
- HDMI1
- HDMI2

#### 5.4.2.2 Memory Configuration

Use the **Memory Configuration** submenu (**BIOS Menu 27**) to view memory information.

Aptio Setup Utility - Copyright (c) 2011 American Megatrends, Inc.	
Chipset	
Memory Information	
Total Memory	2048 MB (DDR3 1333)
DIMM#0	Not Present
DIMM#1	2048 MB (DDR3 1333)
DIMM#2	Not Present
DIMM#3	Not Present
<hr/> ←→: Select Screen ↑↓: Select Item EnterSelect +/-: Change Opt. F1 General Help F2 Previous Values F3 Optimized Defaults F4 Save & Exit ESC Exit	
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.	

**BIOS Menu 27: Memory Configuration**

## 5.5 Boot

Use the **Boot** menu (**BIOS Menu 28**) to configure system boot options.

Aptio Setup Utility - Copyright (c) 2011 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
<hr/>					Select the keyboard NumLock state
Boot Configuration					
Bootup NumLock State	[On]				
Quiet Boot	[Enabled]				
Option ROM Messages	[Force BIOS]				
Launch PXE OpROM	[Disabled]				
UEFI Boot	[Disabled]				
<hr/>					←→: Select Screen ↑↓: Select Item EnterSelect F1 General Help F2 Previous Values F3 Optimized Defaults F4 Save ESC Exit
Boot Option Priorities					
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.					

**BIOS Menu 28: Boot**

## IMB-Q770 Micro-ATX Motherboard

## → Bootup NumLock State [On]

Use the **Bootup NumLock State** BIOS option to specify if the number lock setting must be modified during boot up.

→ **On**      **DEFAULT**      Allows the Number Lock on the keyboard to be enabled automatically when the computer system boots up. This allows the immediate use of the 10-key numeric keypad located on the right side of the keyboard. To confirm this, the Number Lock LED light on the keyboard is lit.

→ **Off**      Does not enable the keyboard Number Lock automatically. To use the 10-keys on the keyboard, press the Number Lock key located on the upper left-hand corner of the 10-key pad. The Number Lock LED on the keyboard lights up when the Number Lock is engaged.

## → Quiet Boot [Enabled]

Use the **Quiet Boot** BIOS option to select the screen display when the system boots.

→ **Disabled**      Normal POST messages displayed

→ **Enabled**      **DEFAULT**      OEM Logo displayed instead of POST messages

## → Option ROM Messages [Force BIOS]

Use the **Option ROM Messages** option to set the Option ROM display mode.

→ **Force BIOS**      **DEFAULT**      Sets display mode to force BIOS.

→ **Keep Current**      Sets display mode to current.

→ Launch PXE OpROM [Disabled]

Use the **Launch PXE OpROM** option to enable or disable boot option for legacy network devices.

→ **Disabled**    **DEFAULT**    Ignore all PXE Option ROMs

→ **Enabled**              Load PXE Option ROMs.

→ UEFI Boot [Disabled]

Use the **UEFI Boot** option to enable or disable to boot from the UEFI devices.


→ **Auto**              If the first boot HDD is GPT then enable UEFI boot options, otherwise disable,

→ **Enabled**              Boot from UEFI devices is enabled.

→ **Disabled**    **DEFAULT**    Boot from UEFI devices is disabled.

## 5.6 Security

Use the **Security** menu (**BIOS Menu 29**) to set system and user passwords.



**BIOS Menu 29: Security**

→ Administrator Password


Use the **Administrator Password** to set or change a administrator password.

→ User Password

Use the **User Password** to set or change a user password.

## 5.7 Exit

Use the **Exit** menu (**BIOS Menu 30**) to load default BIOS values, optimal failsafe values and to save configuration changes.



### BIOS Menu 30:Exit

→ Save Changes and Reset

Use the **Save Changes and Reset** option to save the changes made to the BIOS options and to exit the BIOS configuration setup program.

→ Discard Changes and Reset

Use the **Discard Changes and Reset** option to exit the system without saving the changes made to the BIOS configuration setup program.

→ Restore Defaults

Use the **Restore Defaults** option to load the optimal default values for each of the parameters on the Setup menus. **F3 key can be used for this operation.**

→ Save as User Defaults

Use the **Save as User Defaults** option to save the changes done so far as user defaults.

→ Restore User Defaults

Use the **Restore User Defaults** option to restore the user defaults to all the setup options.

Chapter

6

# Software Drivers

---

## 6.1 Available Software Drivers



### NOTE:

The content of the CD may vary throughout the life cycle of the product and is subject to change without prior notice. Visit the IEI website or contact technical support for the latest updates.

The following drivers can be installed on the system:

- Chipset
- Graphics
- LAN
- Audio
- SATA (Intel® Rapid Storage Technology)
- USB 3.0
- Intel® AMT

Installation instructions are given below.

## 6.2 Software Installation

All the drivers for the IMB-Q770 are on the CD that came with the system. To install the drivers, please follow the steps below.

**Step 1:** Insert the CD into a CD drive connected to the system.



### NOTE:


If the installation program doesn't start automatically:

Click "Start->My Computer->CD Drive->autorun.exe"

**Step 2:** The driver main menu appears (Figure 6-1).

## IMB-Q770 Micro-ATX Motherboard


iEi® Technology Corp.



**Figure 6-1: Introduction Screen**

**Step 3:** Click IMB-Q770.

**Step 4:** A new screen with a list of available drivers appears (Figure 6-2).



**Figure 6-2: Available Drivers**

**Step 5:** Install all of the necessary drivers in this menu.

## 6.3 Chipset Driver Installation

To install the chipset driver, please do the following.

**Step 1:** Access the driver list. (See **Section 6.2**)

**Step 2:** Click “**Chipset**”.

**Step 3:** Locate the setup file and double click on it.

**Step 4:** The **Welcome Screen** in Figure 6-3 appears.

**Step 5:** Click **Next** to continue.



**Figure 6-3: Chipset Driver Welcome Screen**

**Step 6:** The license agreement in Figure 6-4 appears.

**Step 7:** Read the **License Agreement**.


**Step 8:** Click **Yes** to continue.



**Figure 6-4: Chipset Driver License Agreement**

**Step 9:** The **Read Me** file in Figure 6-5 appears.

**Step 10:** Click **Next** to continue.



**Figure 6-5: Chipset Driver Read Me File**

Step 11: **Setup Operations** are performed as shown in Figure 6-6.

Step 12: Once the **Setup Operations** are complete, click **Next** to continue.




Figure 6-6: Chipset Driver Setup Operations

Step 13: The **Finish** screen in Figure 6-7 appears.

Step 14: Select “Yes, I want to restart this computer now” and click **Finish**.



**Figure 6-7: Chipset Driver Installation Finish Screen**

## 6.4 Graphics Driver Installation

To install the Graphics driver, please do the following.


**Step 1:** Access the driver list. (See **Section 6.2**)

**Step 2:** Click “**Graphics**” and select the folder which corresponds to the operating system.

**Step 3:** Double click the setup file.

**Step 4:** The **Welcome Screen** in Figure 6-8 appears.

**Step 5:** Click **Next** to continue.



**Figure 6-8: Graphics Driver Welcome Screen**

**Step 6:** The **License Agreement** in Figure 6-9 appears.

**Step 7:** Click **Yes** to accept the agreement and continue.



**Figure 6-9: Graphics Driver License Agreement**

**Step 8:** **Setup Operations** are performed as shown in Figure 6-10.

Step 9: Once the **Setup Operations** are complete, click **Next** to continue.




Figure 6-10: Graphics Driver Setup Operations

Step 10: The **Finish** screen in Figure 6-11 appears.

Step 11: Select “**Yes, I want to restart this computer now**” and click **Finish**.





Figure 6-11: Graphics Driver Installation Finish Screen

## 6.5 LAN Driver Installation


**Step 1:** Right-click the Computer button from the start menu and select **Properties**.  
**(Figure 6-12).**



**Figure 6-12: Windows Control Panel**

**Step 2:** The system control panel window in **Figure 6-13** appears.

**Step 3:** Click the Device Manager link (**Figure 6-13**).




**Figure 6-13: System Control Panel**

Step 4: A list of system hardware devices appears (**Figure 6-14**).


Step 5: Right-click the Ethernet Controller that has question marks next to it (this means Windows does not recognize the device).

Step 6: Select **Update Driver Software**.



**Figure 6-14: Device Manager List**


Step 7: The Update Driver Software Window appears (**Figure 6-15**).



**Figure 6-15: Update Driver Software Window**

**Step 8:** Select “Browse my computer for driver software” and click **NEXT** to continue.

**Step 9:** Click Browse to select “X:\3-LAN” directory in the **Locate File** window, where “X:\” is the system CD drive. (**Figure 6-16**).




**Figure 6-16: Locate Driver Files**

**Step 10:** Click **NEXT** to continue.


**Step 11:** Driver Installation is performed as shown in **Figure 6-17**.

## IMB-Q770 Micro-ATX Motherboard



**Figure 6-17: LAN Driver Installation**

Step 12: The **Finish** screen in **Figure 6-18** appears. Click **Close** to exit.



**Figure 6-18: LAN Driver Installation Complete**

## 6.6 Audio Driver Installation

To install the audio driver, please do the following.


**Step 1:** Access the driver list. (See **Section 6.2**)

**Step 2:** Click “**Audio**” and select the folder which corresponds to the operating system.

**Step 3:** Double click the setup file.

**Step 4:** The **InstallShield Wizard** is prepared to guide the user through the rest of the process.

**Step 5:** Once initialized, the **InstallShield Wizard** welcome screen appears (**Figure 6-19**).




**Figure 6-19: InstallShield Wizard Welcome Screen**

**Step 6:** Click **NEXT** to continue the installation.


**Step 7:** InstallShield starts to install the new software as shown in **Figure 6-20**.

## IMB-Q770 Micro-ATX Motherboard



**Figure 6-20: Audio Driver Software Configuration**

**Step 8:** After the driver installation process is complete, a confirmation screen appears (Figure 6-21).



**Figure 6-21: Restart the Computer**

**Step 9:** The confirmation screen offers the option of restarting the computer now or later.

For the settings to take effect, the computer must be restarted. Click **FINISH** to restart the computer.

## 6.7 Intel® Rapid Storage Technology Driver Installation

To install the Intel® Rapid Storage Technology driver, please do the following.

**Step 1:** Access the driver list. (See **Section 6.2**)

**Step 2:** Click “**SATA**”.

**Step 3:** Locate the setup file and double click on it.

**Step 4:** The **Welcome Screen** in **Figure 6-22** appears.

**Step 5:** Click **Next** to continue.



**Figure 6-22: SATA RAID Driver Welcome Screen**

**Step 6:** The license agreement in **Figure 6-23** appears.

**Step 7:** Read the **License Agreement**.

**Step 8:** Click **Yes** to continue.


## IMB-Q770 Micro-ATX Motherboard



**Figure 6-23: SATA RAID Driver License Agreement**

**Step 9:** The **Read Me** file in **Figure 6-24** appears.


**Step 10:** Click **Next** to continue.



**Figure 6-24: SATA RAID Driver Read Me File**

**Step 11:** **Setup Operations** are performed as shown in **Figure 6-25**.

**Step 12:** Once the **Setup Operations** are complete, click **Next** to continue.



**Figure 6-25: SATA RAID Driver Setup Operations**

**Step 13:** The **Finish** screen in **Figure 6-26** appears.

**Step 14:** Select “**Yes, I want to restart this computer now**” and click **Finish**.



**Figure 6-26: SATA RAID Driver Installation Finish Screen**

## 6.8 USB 3.0 Driver Installation



### **WARNING:**

Do not run this driver's installer (Setup.exe) from a USB storage device (ie. external USB hard drive or USB thumb drive). For proper installation, please copy driver files to a local hard drive folder and run from there.

To install the touch panel software driver, please follow the steps below.

**Step 1:** Access the driver list. (See **Section 6.2**)

**Step 2:** Click “**USB 3.0**”.

**Step 3:** Locate the setup file and double click on it.

**Step 4:** The **Welcome Screen** in **Figure 6-27** appears.

**Step 5:** Click **Next** to continue.



**Figure 6-27: USB 3.0 Driver Welcome Screen**

**Step 6:** The license agreement in **Figure 6-28** appears.

Step 7: Read the License Agreement.

Step 8: Click Yes to continue.



Figure 6-28: USB 3.0 Driver License Agreement

Step 9: The Read Me file in Figure 6-29 appears.

Step 10: Click Next to continue.




Figure 6-29: USB 3.0 Driver Read Me File

## IMB-Q770 Micro-ATX Motherboard

Step 11: **Setup Operations** are performed as shown in **Figure 6-30**.

Step 12: Once the **Setup Operations** are complete, click **Next** to continue.



**Figure 6-30: USB 3.0 Driver Setup Operations**

Step 13: The **Finish** screen in **Figure 6-31** appears.

Step 14: Select “Yes, I want to restart this computer now” and click **Finish**.



**Figure 6-31: USB 3.0 Driver Installation Finish Screen**

## 6.9 Intel® AMT Driver Installation

The package of the Intel® AMT components includes

- Intel® Management Engine Interface (Intel® ME Interface)
- Intel® Dynamic Application Loader
- Intel® Identity Protection Technology (Intel® IPT)
- Serial Over LAN (SOL)
- Intel® Manageability Engine Firmware Recovery Agent
- Intel® Management and Security Status
- Local Management Service (LMS)
- User Notification Service (UNS)

To install these Intel® AMT components, please do the following.

**Step 1:** Access the driver list. (See **Section 6.2**)


**Step 2:** Click “**iAMT**”.

**Step 3:** Locate the setup file and double click it.

**Step 4:** When the setup files are completely extracted the **Welcome Screen in Figure 6-32** appears.

**Step 5:** Click **Next** to continue.

## IMB-Q770 Micro-ATX Motherboard




**Figure 6-32: Intel® ME Driver Welcome Screen**

**Step 6:** The license agreement in **Figure 6-33** appears.

**Step 7:** Read the **License Agreement**.


**Step 8:** Click **Yes** to continue.



**Figure 6-33: Intel® ME Driver License Agreement**

**Step 9:** **Setup Operations** are performed as shown in **Figure 6-34**.


**Step 10:** Once the **Setup Operations** are complete, click **Next** to continue.



**Figure 6-34: Intel® ME Driver Setup Operations**

**Step 11:** The **Finish** screen in **Figure 6-35** appears.

**Step 12:** Select “**Yes, I want to restart this computer now**” and click **Finish**.



**Figure 6-35: Intel® ME Driver Installation Finish Screen**

## Appendix

## A

# BIOS Options

---

Below is a list of BIOS configuration options in the BIOS chapter.

→ System Date [xx/xx/xx] .....	74
→ System Time [xx:xx:xx] .....	74
→ ACPI Sleep State [S1 (CPU Stop Clock)] .....	76
→ Wake system with Fixed Time [Disabled].....	76
→ Security Device Support [Disable] .....	78
→ Hyper-Threading [Enabled].....	80
→ Intel Virtualization Technology [Disabled] .....	80
→ SATA Controller [Enabled].....	81
→ SATA Mode Selection [IDE] .....	81
→ Intel(R) Rapid Start Technology [Disabled].....	82
→ Intel AMT [Enabled] .....	84
→ Unconfigure AMT/ME [Disabled] .....	84
→ USB Devices .....	85
→ Legacy USB Support [Enabled].....	85
→ Serial Port [Enabled].....	87
→ Change Settings [Auto] .....	87
→ Device Mode [Normal] .....	87
→ Serial Port [Enabled].....	88
→ Change Settings [Auto] .....	88
→ Serial Port [Enabled].....	89
→ Change Settings [Auto] .....	89
→ Serial Port [Enabled].....	90
→ Change Settings [Auto] .....	90
→ Serial Port [Enabled].....	92
→ Change Settings [Auto] .....	92
→ Serial Port [Enabled].....	92
→ Change Settings [Auto] .....	92
→ Serial Port [Enabled].....	93
→ Change Settings [Auto] .....	93
→ Serial Port [Enabled].....	94
→ Change Settings [Auto] .....	94
→ Serial Port [Enabled].....	95
→ Change Settings [Auto] .....	95

→ Serial Port [Enabled].....	95
→ Change Settings [Auto] .....	96
→ PC Health Status .....	97
→ Smart Fan Function [Enabled].....	98
→ CPU_FAN1 Smart Fan Control [Auto Duty-Cycle Mode] .....	99
→ CPU Temperature n .....	99
→ PCH_FAN1 Smart Fan Control [Auto Duty-Cycle Mode] .....	99
→ PCH Temperature n .....	100
→ SYS_FAN1 Smart Fan Control [Auto Duty-Cycle Mode].....	100
→ SYS Temperature n.....	100
→ Console Redirection [Disabled].....	101
→ Terminal Type [ANSI].....	102
→ Bits per second [115200].....	103
→ Data Bits [8] .....	103
→ Parity [None].....	103
→ Stop Bits [1] .....	104
→ Auto Recovery Function [Disabled].....	104
→ Restore on AC Power Loss [Last State] .....	106
→ Power Saving Function(ERP) [Disabled].....	106
→ Azalia [Enabled] .....	107
→ Azalia internal HDMI Codec [Enabled].....	108
→ Azalia HDMI1 Codec [Enabled].....	108
→ Azalia HDMI2 Codec [Enabled].....	108
→ Primary Display [Auto] .....	110
→ DVMT Pre-Allocated [256MB].....	110
→ DVMT Total Gfx Mem [MAX].....	110
→ Primary IGFX Boot Display [VBIOS Default] .....	111
→ Bootup NumLock State [On].....	113
→ Quiet Boot [Enabled] .....	113
→ Option ROM Messages [Force BIOS].....	113
→ Launch PXE OpROM [Disabled] .....	114
→ UEFI Boot [Disabled] .....	114
→ Administrator Password .....	115
→ User Password .....	115
→ Save Changes and Reset .....	115

→ Discard Changes and Reset .....	115
→ Restore Defaults .....	116
→ Save as User Defaults .....	116
→ Restore User Defaults .....	116

Appendix

B

# One Key Recovery

---

## B.1 One Key Recovery Introduction


The IEI one key recovery is an easy-to-use front end for the Norton Ghost system backup and recovery tool. This tool provides quick and easy shortcuts for creating a backup and reverting to that backup or reverting to the factory default settings.



### NOTE:

The latest One Key Recovery software provides an auto recovery function that allows a system running Microsoft Windows OS to automatically restore from the factory default image after encountering a Blue Screen of Death (BSOD) or a hang for around 10 minutes. Please refer to Section B.3 for the detailed setup procedure.

The IEI One Key Recovery tool menu is shown below.



**Figure B-1: IEI One Key Recovery Tool Menu**

Prior to using the IEI One Key Recovery tool (as shown in **Figure B-1**) to backup or restore Windows system, five setup procedures are required.

1. Hardware and BIOS setup (see **Section B.2.1**)
2. Create partitions (see **Section B.2.2**)
3. Install operating system, drivers and system applications (see **Section B.2.3**)
4. Build the recovery partition (see **Section B.2.4**)
5. Create factory default image (see **Section B.2.5**)

After completing the five initial setup procedures as described above, users can access the recovery tool by pressing <F3> while booting up the system. The detailed information of each function is described in **Section B.5**.

**NOTE:**

The initial setup procedures for Linux system are described in Section B.3.

#### B.1.1 System Requirement

**NOTE:**

The recovery CD can only be used with IEI products. The software will fail to run and a warning message will appear when used on non-IEI hardware.



To create the system backup, the main storage device must be split into two partitions (three partitions for Linux). The first partition will be for the operating system, while the second partition will be invisible to the operating system and contain the backup made by the one key recovery software.

The partition created for recovery images must be big enough to contain both the factory default image and the user backup image. The size must be calculated before creating the partitions. Please take the following table as a reference when calculating the size of the partition.

	OS	OS Image after Ghost	Compression Ratio
Windows® 7	7 GB	5 GB	70%
Windows® XPE	776 MB	560 MB	70%
Windows® CE 6.0	36 MB	28 MB	77%

**NOTE:**

Specialized tools are required to change the partition size if the operating system is already installed.

### B.1.2 Supported Operating System

The recovery CD is compatible with both Microsoft Windows and Linux operating systems (OS). The supported OS versions are listed below.

- Microsoft Windows
  - Windows XP (Service Pack 2 or 3 required)
  - Windows Vista
  - Windows 7
  - Windows CE 5.0
  - Windows CE 6.0
  - Windows XP Embedded
- Linux
  - Fedora Core 12 (Constantine)
  - Fedora Core 11 (Leonidas)
  - Fedora Core 10 (Cambridge)
  - Fedora Core 8 (Werewolf)
  - Fedora Core 7 (Moonshine)

- RedHat RHEL-5.4
- RedHat 9 (Ghirke)
- Ubuntu 8.10 (Intrepid)
- Ubuntu 7.10 (Gutsy)
- Ubuntu 6.10 (Edgy)
- Debian 5.0 (Lenny)
- Debian 4.0 (Etch)
- SuSe 11.2
- SuSe 10.3

**NOTE:**

Installing unsupported OS versions may cause the recovery tool to fail.

## B.2 Setup Procedure for Windows

Prior to using the recovery tool to backup or restore, a few setup procedures are required.

**Step 1:** Hardware and BIOS setup (see **Section B.2.1**)

**Step 2:** Create partitions (see **Section B.2.2**)

**Step 3:** Install operating system, drivers and system applications (see **Section B.2.3**)

**Step 4:** Build the recovery partition (see **Section B.2.4**) or build the auto recovery partition (see **Section B.3**)

**Step 5:** Create factory default image (see **Section B.2.5**)

The detailed descriptions are described in the following sections.

**NOTE:**

The setup procedures described below are for Microsoft Windows operating system users. For Linux, most of the setup procedures are the same except for several steps described in Section B.3.

---


### B.2.1 Hardware and BIOS Setup

- Step 1:** Make sure the system is powered off and unplugged.
- Step 2:** Install a hard drive or SSD in the system. An unformatted and unpartitioned disk is recommended.
- Step 3:** Connect an optical disk drive to the system and insert the recovery CD.
- Step 4:** Turn on the system.
- Step 5:** Press the <DELETE> key as soon as the system is turned on to enter the BIOS.
- Step 6:** Select the connected optical disk drive as the 1<sup>st</sup> boot device. (**Boot → Boot Device Priority → 1<sup>st</sup> Boot Device**).
- Step 7:** Save changes and restart the computer. Continue to the next section for instructions on partitioning the internal storage.

### B.2.2 Create Partitions


To create the system backup, the main storage device must be split into two partitions (three partitions for Linux). The first partition will be for the operating system, while the second partition will be invisible to the operating system and contain the backup made by the one key recovery software.

- Step 1:** Put the recovery CD in the optical drive of the system.
- Step 2:** **Boot the system from recovery CD.** When prompted, press any key to boot from the recovery CD. It will take a while to launch the recovery tool. Please be patient!




**Figure B-2: Launching the Recovery Tool**

Step 3: The recovery tool setup menu is shown as below.



**Figure B-3: Recovery Tool Setup Menu**

Step 4: Press <6> then <Enter>.



**Figure B-4: Command Prompt**

**Step 5:** The command prompt window appears. Type the following commands (marked in red) to create two partitions. One is for the OS installation; the other is for saving recovery files and images which will be an invisible partition.

(Press <Enter> after entering each line below)

```
system32>diskpart
DISKPART>list vol
DISKPART>sel disk 0
DISKPART>create part pri size= __
DISKPART>assign letter=N
DISKPART>create part pri size= __
DISKPART>assign letter=F
DISKPART>exit
system32>format N: /fs:ntfs /q /y
system32>format F: /fs:ntfs /q /v:Recovery /y
system32>exit
```

## IMB-Q770 Micro-ATX Motherboard

```
X:\I386\SYSTEM32\cmd.exe
X:\I386\SYSTEM32>diskpart → Starts the Microsoft disk partitioning tool.
Microsoft DiskPart version 5.2.3790.1830
Copyright <C> 1999-2001 Microsoft Corporation.
On computer: MININT-JVC

DISKPART> list vol → Show partition information
Volume ### Ltr Label Fs Type Size Status Info
Volume 0 X CD_ROM CDFS DUD-ROM 405 MB Healthy Boot
Volume 1 D FAT32 Removeable 3854 MB Healthy

DISKPART> sel disk 0 → Select a disk
Disk 0 is now the selected disk.

DISKPART> create part pri size=2000 → Create partition 1 and assign a size.
This partition is for OS installation.
DiskPart succeeded in creating the specified partition.

DISKPART> assign letter=N → Assign partition 1 a code name (N).
DiskPart successfully assigned the drive letter or mount point.

DISKPART> create part pri size=1800 → Create partition 2 and assign a size.
This partition is for recovery images.
DiskPart succeeded in creating the specified partition.

DISKPART> assign letter=F → Assign partition 2 a code name (F).
DiskPart successfully assigned the drive letter or mount point.

DISKPART> exit → Exit diskpart

X:\I386\SYSTEM32>format n: /fs:ntfs /q /y → Format partition 1 (N) as NTFS format.
The type of the file system is RAW.
The new file system is NTFS.
QuickFormatting 2000M
Creating file system structures.
Format complete.
2048254 KB total disk space.
2035620 KB are available.

X:\I386\SYSTEM32>format f: /fs:ntfs /q /v:Recovery /y → Format partition 2 (F) as NTFS format and
The type of the file system is RAW.                                name it as "Recovery".
The new file system is NTFS.
QuickFormatting 1804M
Creating file system structures.
Format complete.
1847474 KB total disk space.
1835860 KB are available.

X:\I386\SYSTEM32>exit → Exit Windows PE
```

Figure B-5: Partition Creation Commands

**NOTE:**

Use the following commands to check if the partitions were created successfully.

```
X:\I386\SYSTEM32>diskpart
Microsoft DiskPart version 5.2.3790.1830
Copyright <C> 1999-2001 Microsoft Corporation.
On computer: MININT-JUC
DISKPART> sel disk 0
Disk 0 is now the selected disk.
DISKPART> list part
  Partition ###  Type          Size    Offset
  Partition 1   Primary       2000 MB  32 KB
  Partition 2   Primary       1804 MB  2000 MB
DISKPART> exit
```

---

**Step 6:** Press any key to exit the recovery tool and automatically reboot the system.

Please continue to the following procedure: Build the Recovery Partition.

### B.2.3 Install Operating System, Drivers and Applications

Install the operating system onto the unlabelled partition. The partition labeled "Recovery" is for use by the system recovery tool and should not be used for installing the operating system or any applications.

**NOTE:**

The operating system installation program may offer to reformat the chosen partition. DO NOT format the partition again. The partition has already been formatted and is ready for installing the new operating system.

---


To install the operating system, insert the operating system installation CD into the optical drive. Restart the computer and follow the installation instructions.

#### B.2.4 Building the Recovery Partition

**Step 1:** Put the recover CD in the optical drive.


**Step 2:** Start the system.

**Step 3:** **Boot the system from the recovery CD.** When prompted, press any key to boot from the recovery CD. It will take a while to launch the recovery tool. Please be patient!




**Figure B-6: Launching the Recovery Tool**

**Step 4:** When the recovery tool setup menu appears, press <2> then <Enter>.




**Figure B-7: Manual Recovery Environment for Windows**

**Step 5:** The Symantec Ghost window appears and starts configuring the system to build a recovery partition. In this process the partition created for recovery files in **Section B.2.2** is hidden and the recovery tool is saved in this partition.



**Figure B-8: Building the Recovery Partition**

**Step 6:** After completing the system configuration, press any key in the following window to reboot the system.



**Figure B-9: Press Any Key to Continue**

**Step 7:** Eject the recovery CD.

### B.2.5 Create Factory Default Image




#### NOTE:

Before creating the factory default image, please configure the system to a factory default environment, including driver and application installations.


To create a factory default image, please follow the steps below.

**Step 1:** Turn on the system. When the following screen displays (**Figure B-10**), press the <F3> key to access the recovery tool. The message will display for 10 seconds, please press F3 before the system boots into the operating system.



**Figure B-10: Press F3 to Boot into Recovery Mode**

**Step 2:** The recovery tool menu appears. Type <4> and press <Enter>. (**Figure B-11**)



**Figure B-11: Recovery Tool Menu**

**Step 3:** The About Symantec Ghost window appears. Click **OK** button to continue.




Figure B-12: About Symantec Ghost Window

Step 4: Use mouse to navigate to the option shown below (**Figure B-13**).




Figure B-13: Symantec Ghost Path

Step 5: Select the local source drive (Drive 1) as shown in **Figure B-14**. Then click OK.




Figure B-14: Select a Local Source Drive

Step 6: Select a source partition (Part 1) from basic drive as shown in **Figure B-15**.

Then click OK.




Figure B-15: Select a Source Partition from Basic Drive

Step 7: Select 1.2: [Recovery] NTFS drive and enter a file name called **iei**

(**Figure B-16**). Click **Save**. The factory default image will then be saved in the selected recovery drive and named **IEI.GHO**.



### WARNING:

The file name of the factory default image must be **iei.GHO**.




Figure B-16: File Name to Copy Image to

Step 8: When the Compress Image screen in **Figure B-17** prompts, click **High** to make the image file smaller.




Figure B-17: Compress Image

Step 9: The Proceed with partition image creation window appears, click **Yes** to continue.




Figure B-18: Image Creation Confirmation

Step 10: The Symantec Ghost starts to create the factory default image (**Figure B-19**).




Figure B-19: Image Creation Complete

Step 11: When the image creation completes, a screen prompts as shown in **Figure B-20**.

Click **Continue** and close the Ghost window to exit the program.





Figure B-20: Image Creation Complete

Step 12: The recovery tool main menu window is shown as below. Press any key to reboot the system.



The screenshot shows a Windows Command Prompt window titled 'cmd X:\Windows\System32\cmd.exe'. The menu options are:

- 1. Factory Restore
- 2. Backup system
- 3. Restore your last backup.
- 4. Manual
- 5. Quit

Below the menu, the text reads: 'Please type the number to select and then press Enter:4'. At the bottom, it says 'Done!' and 'Press any key to continue . . . -'.

Figure B-21: Press Any Key to Continue

### B.3 Auto Recovery Setup Procedure

The auto recovery function allows a system to automatically restore from the factory default image after encountering a Blue Screen of Death (BSoD) or a hang for around 10 minutes. To use the auto recovery function, follow the steps described in the following sections.



#### CAUTION:

The setup procedure may include a step to create a factory default image. It is suggested to configure the system to a factory default environment before the configuration, including driver and application installations.

---


**Step 1:** Follow the steps described in **Section B.2.1 ~ Section B.2.3** to setup BIOS, create partitions and install operating system.

**Step 2:** Install the auto recovery utility into the system by double clicking the **Utility/AUTORECOVERY-SETUP.exe** in the One Key Recovery CD. This utility MUST be installed in the system, otherwise, the system will automatically restore from the factory default image every ten (10) minutes.




**Figure B-22: Auto Recovery Utility**

**Step 3:** Reboot the system from the recovery CD. When prompted, press any key to boot from the recovery CD. It will take a while to launch the recovery tool. Please be patient!




**Figure B-23: Launching the Recovery Tool**

**Step 4:** When the recovery tool setup menu appears, press <4> then <Enter>.



**Figure B-24: Auto Recovery Environment for Windows**

**Step 5:** The Symantec Ghost window appears and starts configuring the system to build an auto recovery partition. In this process the partition created for recovery files in **Section B.2.2** is hidden and the auto recovery tool is saved in this partition.



**Figure B-25: Building the Auto Recovery Partition**

**Step 6:** After completing the system configuration, the following message prompts to confirm whether to create a factory default image. Type **Y** to have the system create a factory default image automatically. Type **N** within 6 seconds to skip this process (The default option is YES). It is suggested to choose YES for this option.



**Figure B-26: Factory Default Image Confirmation**

## IMB-Q770 Micro-ATX Motherboard

Step 7: The Symantec Ghost starts to create the factory default image (**Figure B-27**).




Figure B-27: Image Creation Complete

Step 8: After completing the system configuration, press any key in the following window to restart the system.





Figure B-28: Press any key to continue

Step 9: Eject the One Key Recovery CD and restart the system.

Step 10: Press the <DELETE> key as soon as the system is turned on to enter the BIOS.

Step 11: Enable the Auto Recovery Function option (**Advanced → iEi Feature → Auto Recovery Function**).

**BIOS Menu 31: IEI Feature**

**Step 12:** Save changes and restart the system. If the system encounters a Blue Screen of Death (BSOD) or a hang for around 10 minutes, it will automatically restore from the factory default image.

**CAUTION:**

The auto recovery function can only apply on a Microsoft Windows system running the following OS versions:

- Windows XP
- Windows Vista
- Windows 7

## B.4 Setup Procedure for Linux

The initial setup procedure for Linux system is mostly the same with the procedure for Microsoft Windows. Please follow the steps below to setup recovery tool for Linux OS.

Step 1: **Hardware and BIOS setup.** Refer to **Section B.2.1.**

Step 2: **Install Linux operating system.** Make sure to install GRUB (v0.97 or earlier) MBR type and Ext3 partition type. Leave enough space on the hard drive to create the recover partition later.



**NOTE:**

If the Linux OS is not installed with GRUB (v0.97 or earlier) and Ext3, the Symantec Ghost may not function properly.


While installing Linux OS, please create two partitions:

- Partition 1: /
- Partition 2: **SWAP**



**NOTE:**

Please reserve enough space for partition 3 for saving recovery images.



**Figure B-29: Partitions for Linux**

Step 3: **Create a recovery partition.** Insert the recovery CD into the optical disk drive.


Follow **Step 1 ~ Step 3** described in **Section B.2.2.** Then type the following commands (marked in red) to create a partition for recovery images.

**system32>diskpart**

**DISKPART>list vol**

```
DISKPART>sel disk 0  
DISKPART>create part pri size= ____  
DISKPART>assign letter=N  
DISKPART>exit  
system32>format N: /fs:ntfs /q /v:Recovery /y  
system32>exit
```

**Step 4:** **Build the recovery partition.** Press any key to boot from the recovery CD. It will take a while to launch the recovery tool. Please be patient. When the recovery tool setup menu appears, type <3> and press <Enter> (**Figure B-30**). The Symantec Ghost window appears and starts configuring the system to build a recovery partition. After completing the system configuration, press any key to reboot the system. Eject the recovery CD.



**Figure B-30: Manual Recovery Environment for Linux**

**Step 5:** **Access the recovery tool main menu by modifying the “menu.lst”.** To first access the recovery tool main menu, the menu.lst must be modified. In Linux, enter Administrator (root). When prompt appears, type:

```
cd /boot/grub  
vi menu.lst
```

```
Fedora release 9 (Sulphur)
Kernel 2.6.25-14.fc9.i686 on an i686 (tty2)

localhost login: root
Password:
[root@localhost ~]# cd /boot/grub/
[root@localhost grub]# vi menu.lst _
```

Figure B-31: Access menu.lst in Linux (Text Mode)

Step 6: Modify the menu.lst as shown below.

```
#boot=/dev/sda
default=0
timeout=10           ← Modify timeout=10
splashimage=(hd0,0)/grub/splash.xpm.gz
hiddenmenu
title Fedora (2.6.25-14.fc9.i686)
    root (hd0,0)
    kernel /vmlinuz-2.6.25-14.fc9.i686 ro root=UUID=10f1acd
ac38b5c78910 rhgb quiet
    initrd /initrd-2.6.25-14.fc9.i686.img

title Recovery Partition
root (hd0,2)           ← Type command
makeactive
chainloader +1
```

- Type command:  
title Recovery Partition  
root (hd0,2)  
makeactive  
chainloader +1

Step 7: The recovery tool menu appears. (Figure B-32)


```
1. Factory Restore
2. Backup system
3. Restore your last backup.
4. Manual
5. Quit
Please type the number to select and then press Enter:
```

Figure B-32: Recovery Tool Menu

Step 8: Create a factory default image. Follow **Step 2 ~ Step 12** described in **Section B.2.5** to create a factory default image.

## B.5 Recovery Tool Functions

After completing the initial setup procedures as described above, users can access the recovery tool by pressing <F3> while booting up the system. However, if the setup procedure in Section B.3 has been completed and the auto recovery function is enabled, the system will automatically restore from the factory default image without pressing the F3 key. The recovery tool main menu is shown below.



**Figure B-33: Recovery Tool Main Menu**

The recovery tool has several functions including:

1. **Factory Restore:** Restore the factory default image (iei.GHO) created in Section B.2.5.
2. **Backup system:** Create a system backup image (iei\_user.GHO) which will be saved in the hidden partition.
3. **Restore your last backup:** Restore the last system backup image
4. **Manual:** Enter the Symantec Ghost window to configure manually.
5. **Quit:** Exit the recovery tool and restart the system.



### **WARNING:**

Please do not turn off the system power during the process of system recovery or backup.

**WARNING:**

All data in the system will be deleted during the system recovery.


Please backup the system files before restoring the system (either Factory Restore or Restore Backup).

#### B.5.1 Factory Restore

To restore the factory default image, please follow the steps below.

**Step 1:** Type <1> and press <Enter> in the main menu.

**Step 2:** The Symantec Ghost window appears and starts to restore the factory default. A factory default image called **iei.GHO** is created in the hidden Recovery partition.



**Figure B-34: Restore Factory Default**

**Step 3:** The screen shown in **Figure B-35** appears when completed. Press any key to reboot the system.




Figure B-35: Recovery Complete Window

### B.5.2 Backup System

To backup the system, please follow the steps below.

**Step 1:** Type <2> and press <Enter> in the main menu.

**Step 2:** The Symantec Ghost window appears and starts to backup the system. A backup image called **iei\_user.GHO** is created in the hidden Recovery partition.




Figure B-36: Backup System

**Step 3:** The screen shown in **Figure B-37** appears when system backup is complete.

Press any key to reboot the system.




Figure B-37: System Backup Complete Window

### B.5.3 Restore Your Last Backup

To restore the last system backup, please follow the steps below.

**Step 1:** Type <3> and press <Enter> in the main menu.

**Step 2:** The Symantec Ghost window appears and starts to restore the last backup image (iei\_user.GHO).




Figure B-38: Restore Backup

**Step 3:** The screen shown in **Figure B-39** appears when backup recovery is complete.

Press any key to reboot the system.




Figure B-39: Restore System Backup Complete Window

#### B.5.4 Manual

To restore the last system backup, please follow the steps below.

**Step 1:** Type <4> and press <Enter> in the main menu.

**Step 2:** The Symantec Ghost window appears. Use the Ghost program to backup or recover the system manually.





Figure B-40: Symantec Ghost Window

**Step 3:** When backup or recovery is completed, press any key to reboot the system.

## B.6 Restore Systems from a Linux Server through LAN

The One Key Recovery allows a client system to automatically restore to a factory default image saved in a Linux system (the server) through LAN connectivity after encountering a Blue Screen of Death (BSoD) or a hang for around 10 minutes. To be able to use this function, the client system and the Linux system **MUST** reside in the same domain.



### NOTE:

The supported client OS includes:

- Windows 2000
- Windows XP
- Windows Vista
- Windows 7
- Windows CE
- Windows XP Embedded

Prior to restoring client systems from a Linux server, a few setup procedures are required.

**Step 1:** Configure DHCP server settings

**Step 2:** Configure TFTP settings

**Step 3:** Configure One Key Recovery server settings

**Step 4:** Start DHCP, TFTP and HTTP

**Step 5:** Create a shared directory

**Step 6:** Setup a client system for auto recovery

The detailed descriptions are described in the following sections. In this document, two types of Linux OS are used as examples to explain the configuration process – CentOS 5.5 (Kernel 2.6.18) and Debian 5.0.7 (Kernel 2.6.26).

### B.6.1 Configure DHCP Server Settings

#### Step 1: Install the DHCP

#yum install dhcp (CentOS, commands marked in red)

#apt-get install dhcp3-server (Debian, commands marked in blue)

#### Step 2: Confirm the operating system default settings: dhcpcd.conf.

##### CentOS

Use the following command to show the DHCP server sample location:

#vi /etc/dhcpcd.conf

The DHCP server sample location is shown as below:

```
# DHCP Server Configuration file.  
#   see /usr/share/doc/dhcp*/dhcpcd.conf.sample  
#
```

Use the following command to copy the DHCP server sample to etc/dhcpcd.conf:

#cp /usr/share/doc/dhcp-3.0.5/dhcpcd.conf.sample /etc/dhcpcd.conf

#vi /etc/dhcpcd.conf

```
ddns-update-style interim;  
ignore client-updates;  
  
subnet 192.168.0.0 netmask 255.255.255.0 {  
    # --- default gateway  
    option routers           192.168.0.2;  
    option subnet-mask        255.255.255.0;  
    option nis-domain         "domain.org";  
    option domain-name        "domain.org";  
    option domain-name-servers 192.168.0.1;  
    next-server 192.168.0.6;  
    filename "pxelinux.0";  
    option time-offset        -18000; # Eastern Standard Time  
    option ntp-servers        192.168.1.1;  
    option routers             192.168.1.1;
```

##### Debian

#vi /etc/dhcpcd.conf

Edit "/etc/dhcpcd.conf" for your environment. For example, add

next-server PXE server IP address;

```

filename "pxelinux.0";

ddns-update-style interim;
ignore client-updates;

subnet 192.168.0.0 netmask 255.255.255.0 {
    # --- default gateway
    option routers           192.168.0.2;
    option subnet-mask        255.255.255.0;

    option nis-domain         "domain.org";
    option domain-name        "domain.org";
    option domain-name-servers 192.168.0.1;
    next-server 192.168.0.6;
    filename "pxelinux.0";
    option time-offset        -18000; # Eastern Standard Time
    option ntp-servers        192.168.1.1;
    option ntp-servers        192.168.1.1;
}

```

### B.6.2 Configure TFTP Settings

**Step 1:** Install the tftp, httpd and syslinux.

```
#yum install tftp-server httpd syslinux (CentOS)
```

```
#apt-get install tftpd-hpa xinetd syslinux (Debian)
```

**Step 2:** Enable the TFTP server by editing the “/etc/xinetd.d/tftp” file and make it use the remap file. The “-vvv” is optional but it could definitely help on getting more information while running the remap file. For example:

#### CentOS

```
#vi /etc/xinetd.d/tftp
```

Modify:

```
disable = no
```

```
server_args = -s /tftpboot -m /tftpboot/tftpd.remap -vvv_
```

```

socket_type      = dgram
protocol        = udp
wait            = yes
user            = root
server          = /usr/sbin/in.tftpd
server_args     = -s /tftpboot -m /tftpboot/tftpd.remap -vvv_
disable          = no
per_source       = 11
cps              = 100 2
flags            = IPv4

```

### Debian

Replace the TFTP settings from “inetd” to “xinetc” and annotate the “inetd” by adding “#”.

```
#vi /etc/inetd.conf
```

Modify: #tftp dgram udp wait root /usr/sbin..... (as shown below)

```
#:BOOT: TFTP service is provided primarily for booting. Most sites
#       run this only on machines acting as "boot servers."
#
#tftp          dgram    udp      wait    root   /usr/sbin/in.tftpd /usr/sbin/in.tftpd -s
#/var/lib/tftpboot
```

```
#vi /etc/xinetd.d/tftp
```

```
socket_type      = dgram
protocol        = udp
wait            = yes
user            = root
server          = /usr/sbin/in.tftpd
server_args     = -s /tftpboot -m /tftpboot/tftpd.remap -vvv
disable         = no
per_source       = 11
cps             = 100 2
flags           = IPv4
```

### B.6.3 Configure One Key Recovery Server Settings

**Step 1:** Copy the **Utility/RECOVERYR10.TAR.BZ2** package from the One Key Recovery CD to the system (server side).



**Step 2:** Extract the recovery package to /.

```
#cp RecoveryR10.tar.bz2 /
#cd /
#tar -xvf RecoveryR10.tar.bz2
```

**Step 3:** Copy “pxelinux.0” from “syslinux” and install to “/tftboot”.

```
#cp /usr/lib/syslinux/pxelinux.0 /tftboot/
```

#### B.6.4 Start the DHCP, TFTP and HTTP

Start the DHCP, TFTP and HTTP. For example:

##### CentOS

```
#service xinetd restart
```

```
#service httpd restart
```

```
#service dhcpcd restart
```

##### Debian

```
#/etc/init.d/xinetd reload
```

```
#/etc/init.d/xinetd restart
```

```
#/etc/init.d/dhcp3-server restart
```

#### B.6.5 Create Shared Directory

**Step 1:** Install the samba.

```
#yum install samba
```

**Step 2:** Create a shared directory for the factory default image.

```
#mkdir /share  
#cd /share  
#mkdir /image  
#cp iei.gho /image
```



##### **WARNING:**

The file name of the factory default image must be **iei.gho**.

**Step 3:** Confirm the operating system default settings: smb.conf.

```
#vi /etc/samba/smb.conf
```

Modify:

[image]

```
comment = One Key Recovery  
path = /share/image  
browseable = yes  
writable = yes  
public = yes  
create mask = 0644  
directory mask = 0755
```

**Step 4:** Edit “/etc/samba/smb.conf” for your environment. For example:

```
# "security = user" is always a good idea. This will require a Unix account  
# in this server for every user accessing the server. See  
# /usr/share/doc/samba-doc/htmldocs/Samba3-HOWTO/ServerType.html  
# in the samba-doc package for details.  
security = share
```

```
[image]  
comment = One Key Recovery  
path = /share/image  
browseable = yes  
writable = yes  
public = yes  
create mask = 0644  
directory mask = 0755
```

**Step 5:** Modify the hostname

#vi /etc/hostname

Modify: RecoveryServer

```
RecoveryServer  
~
```

#### B.6.6 Setup a Client System for Auto Recovery

**Step 1:** Configure the following BIOS options of the client system.

Advanced → iEi Feature → Auto Recovery Function → **Enabled**

Advanced → iEi Feature → Recover from PXE → **Enabled**

Boot → Launch PXE OpROM → **Enabled**

**Step 2:** Continue to configure the **Boot Option Priorities** BIOS option of the client system:

Boot Option #1 → remain the default setting to boot from the original OS.

Boot Option #2 → select the boot from LAN option.


**Step 3:** Save changes and exit BIOS menu.

Exit → **Save Changes and Exit**

**Step 4:** Install the auto recovery utility into the system by double clicking the **Utility/AUTORECOVERY-SETUP.exe** in the One Key Recovery CD. This utility MUST be installed in the system, otherwise, the system will automatically restore from the factory default image every ten (10) minutes.





**Step 5:** Restart the client system from LAN. If the system encounters a Blue Screen of Death (BSOD) or a hang for around 10 minutes, it will automatically restore from the factory default image. The following screens will show when the system starts auto recovering.



Realtek PCIe GBE Family Controller Series v2.35 (06/14/10)  
CLIENT MAC ADDR: 00 18 7D 13 E6 89 GUID: 00020003-0004-0005-0006-0007000000  
DHCP... ↴

A screenshot of a terminal or log window. The text displays information about a Realtek PCIe GBE Family Controller, including its version (v2.35), date (06/14/10), client MAC address (00 18 7D 13 E6 89), GUID (00020003-0004-0005-0006-0007000000), and the DHCP status (DHCP... ↴).

```
My IP address seems to be C0A80009 192.168.0.9
ip=192.168.0.9:192.168.0.8:192.168.0.2:255.255.255.0
TFTP prefix:
Trying to load: pxelinux.cfg/00020003-0004-0005-0006-000700080009
Trying to load: pxelinux.cfg/01-00-18-7d-13-e6-89
Trying to load: pxelinux.cfg/C0A80009
Trying to load: pxelinux.cfg/C0A80000
Trying to load: pxelinux.cfg/C0A800
Trying to load: pxelinux.cfg/C0A80
Trying to load: pxelinux.cfg/C0A8
Trying to load: pxelinux.cfg/C0A
Trying to load: pxelinux.cfg/C0
Trying to load: pxelinux.cfg/C
Trying to load: pxelinux.cfg/default
boot:
```

**NOTE:**


A firewall or a SELinux is not in use in the whole setup process. If there is a firewall or a SELinux protecting the system, modify the configuration information to accommodate them.

## B.7 Other Information


### B.7.1 Using AHCI Mode or ALi M5283 / VIA VT6421A Controller

When the system uses AHCI mode or some specific SATA controllers such as ALi M5283 or VIA VT6421A, the SATA RAID/AHCI driver must be installed before using one key recovery. Please follow the steps below to install the SATA RAID/AHCI driver.


- Step 1:** Copy the SATA RAID/AHCI driver to a floppy disk and insert the floppy disk into a USB floppy disk drive. The SATA RAID/AHCI driver must be especially designed for the on-board SATA controller.
- Step 2:** Connect the USB floppy disk drive to the system.
- Step 3:** Insert the One Key Recovery CD into the system and boot the system from the CD.
- Step 4:** When launching the recovery tool, press <F6>.



Step 5: When the following window appears, press <S> to select "Specify Additional Device".



Step 6: In the following window, select a SATA controller mode used in the system. Then press <Enter>. The user can now start using the SATA HDD.



**Step 7:** After pressing <Enter>, the system will get into the recovery tool setup menu.

Continue to follow the setup procedure from **Step 4** in **Section B.2.2 Create Partitions** to finish the whole setup process.

### B.7.2 System Memory Requirement

To be able to access the recovery tool by pressing <F3> while booting up the system, please make sure to have enough system memory. The minimum memory requirement is listed below.

- **Using Award BIOS:** 128 MB system memory
- **Using AMI BIOS:** 512 MB system memory.

Appendix

C

# Terminology

---

## IMB-Q770 Micro-ATX Motherboard

AC '97	Audio Codec 97 (AC'97) refers to a codec standard developed by Intel® in 1997.
ACPI	Advanced Configuration and Power Interface (ACPI) is an OS-directed configuration, power management, and thermal management interface.
AHCI	Advanced Host Controller Interface (AHCI) is a SATA Host controller register-level interface.
ATA	The Advanced Technology Attachment (ATA) interface connects storage devices including hard disks and CD-ROM drives to a computer.
ARMD	An ATAPI Removable Media Device (ARMD) is any ATAPI device that supports removable media, besides CD and DVD drives.
ASKIR	Amplitude Shift Keyed Infrared (ASKIR) is a form of modulation that represents a digital signal by varying the amplitude ("volume") of the signal. A low amplitude signal represents a binary 0, while a high amplitude signal represents a binary 1.
BIOS	The Basic Input/Output System (BIOS) is firmware that is first run when the computer is turned on and can be configured by the end user
CODEC	The Compressor-Decompressor (CODEC) encodes and decodes digital audio data on the system.
CMOS	Complimentary metal-oxide-conductor is an integrated circuit used in chips like static RAM and microprocessors.
COM	COM refers to serial ports. Serial ports offer serial communication to expansion devices. The serial port on a personal computer is usually a male DB-9 connector.
DAC	The Digital-to-Analog Converter (DAC) converts digital signals to analog signals.
DDR	Double Data Rate refers to a data bus transferring data on both the rising and falling edges of the clock signal.
DMA	Direct Memory Access (DMA) enables some peripheral devices to bypass the system processor and communicate directly with the system memory.

DIMM	Dual Inline Memory Modules are a type of RAM that offer a 64-bit data bus and have separate electrical contacts on each side of the module.
DIO	The digital inputs and digital outputs are general control signals that control the on/off circuit of external devices or TTL devices. Data can be read or written to the selected address to enable the DIO functions.
EHCI	The Enhanced Host Controller Interface (EHCI) specification is a register-level interface description for USB 2.0 Host Controllers.
EIDE	Enhanced IDE (EIDE) is a newer IDE interface standard that has data transfer rates between 4.0 MBps and 16.6 MBps.
EIST	Enhanced Intel® SpeedStep Technology (EIST) allows users to modify the power consumption levels and processor performance through application software. The application software changes the bus-to-core frequency ratio and the processor core voltage.
FSB	The Front Side Bus (FSB) is the bi-directional communication channel between the processor and the Northbridge chipset.
GbE	Gigabit Ethernet (GbE) is an Ethernet version that transfers data at 1.0 Gbps and complies with the IEEE 802.3-2005 standard.
GPIO	General purpose input
HDD	Hard disk drive (HDD) is a type of magnetic, non-volatile computer storage device that stores digitally encoded data.
ICH	The Input/Output Control Hub (ICH) is an Intel® Southbridge chipset.
IrDA	Infrared Data Association (IrDA) specify infrared data transmission protocols used to enable electronic devices to wirelessly communicate with each other.
L1 Cache	The Level 1 Cache (L1 Cache) is a small memory cache built into the system processor.
L2 Cache	The Level 2 Cache (L2 Cache) is an external processor memory cache.
LCD	Liquid crystal display (LCD) is a flat, low-power display device that consists of two polarizing plates with a liquid crystal panel in between.

## IMB-Q770 Micro-ATX Motherboard

LVDS	Low-voltage differential signaling (LVDS) is a dual-wire, high-speed differential electrical signaling system commonly used to connect LCD displays to a computer.
POST	The Power-on Self Test (POST) is the pre-boot actions the system performs when the system is turned-on.
RAM	Random Access Memory (RAM) is volatile memory that loses data when power is lost. RAM has very fast data transfer rates compared to other storage like hard drives.
SATA	Serial ATA (SATA) is a serial communications bus designed for data transfers between storage devices and the computer chipsets. The SATA bus has transfer speeds up to 1.5 Gbps and the SATA II bus has data transfer speeds of up to 3.0 Gbps.
S.M.A.R.T	Self Monitoring Analysis and Reporting Technology (S.M.A.R.T) refers to automatic status checking technology implemented on hard disk drives.
UART	Universal Asynchronous Receiver-transmitter (UART) is responsible for asynchronous communications on the system and manages the system's serial communication (COM) ports.
UHCI	The Universal Host Controller Interface (UHCI) specification is a register-level interface description for USB 1.1 Host Controllers.
USB	The Universal Serial Bus (USB) is an external bus standard for interfacing devices. USB 1.1 supports 12Mbps data transfer rates and USB 2.0 supports 480Mbps data transfer rates.
VGA	The Video Graphics Array (VGA) is a graphics display system developed by IBM.

Appendix A

ppendix

D

# Watchdog Timer

---

**NOTE:**

The following discussion applies to DOS environment. Contact IEI support or visit the IEI website for specific drivers for other operating systems.

The Watchdog Timer is provided to ensure that standalone systems can always recover from catastrophic conditions that cause the CPU to crash. This condition may have occurred by external EMIs or a software bug. When the CPU stops working correctly, Watchdog Timer either performs a hardware reset (cold boot) or a Non-Maskable Interrupt (NMI) to bring the system back to a known state.

A BIOS function call (INT 15H) is used to control the Watchdog Timer.

INT 15H:

AH – 6FH Sub-function:	
AL – 2:	Sets the Watchdog Timer's period.
BL:	Time-out value (Its unit-second is dependent on the item "Watchdog Timer unit select" in CMOS setup).

**Table D-1: AH-6FH Sub-function**

Call sub-function 2 to set the time-out period of Watchdog Timer first. If the time-out value is not zero, the Watchdog Timer starts counting down. When the timer value reaches zero, the system resets. To ensure that this reset condition does not occur, calling sub-function 2 must periodically refresh the Watchdog Timer. However, the watchdog timer is disabled if the time-out value is set to zero.

A tolerance of at least 10% must be maintained to avoid unknown routines within the operating system (DOS), such as disk I/O that can be very time-consuming.

**NOTE:**

When exiting a program it is necessary to disable the Watchdog Timer,  
otherwise the system resets.

---

**EXAMPLE PROGRAM:**

---

```
; INITIAL TIMER PERIOD COUNTER

;

W_LOOP:
;

    MOV     AX, 6F02H      ;setting the time-out value
    MOV     BL, 30          ;time-out value is 48 seconds
    INT     15H

;

; ADD THE APPLICATION PROGRAM HERE
;

    CMP     EXIT_AP, 1      ;is the application over?
    JNE     W_LOOP          ;No, restart the application

    MOV     AX, 6F02H      ;disable Watchdog Timer
    MOV     BL, 0            ;
    INT     15H

;

; EXIT ;
```

Appendix

E

# Hazardous Materials Disclosure

---

## E.1 Hazardous Materials Disclosure Table for IPB Products Certified as RoHS Compliant Under 2002/95/EC Without Mercury

The details provided in this appendix are to ensure that the product is compliant with the Peoples Republic of China (China) RoHS standards. The table below acknowledges the presences of small quantities of certain materials in the product, and is applicable to China RoHS only.

A label will be placed on each product to indicate the estimated "Environmentally Friendly Use Period" (EFUP). This is an estimate of the number of years that these substances would "not leak out or undergo abrupt change." This product may contain replaceable sub-assemblies/components which have a shorter EFUP such as batteries and lamps. These components will be separately marked.

Please refer to the table on the next page.

## IMB-Q770 Micro-ATX Motherboard

Part Name	Toxic or Hazardous Substances and Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Housing	X	O	O	O	O	X
Display	X	O	O	O	O	X
Printed Circuit Board	X	O	O	O	O	X
Metal Fasteners	X	O	O	O	O	O
Cable Assembly	X	O	O	O	O	X
Fan Assembly	X	O	O	O	O	X
Power Supply Assemblies	X	O	O	O	O	X
Battery	O	O	O	O	O	O

O: This toxic or hazardous substance is contained in all of the homogeneous materials for the part is below the limit requirement in SJ/T11363-2006

X: This toxic or hazardous substance is contained in at least one of the homogeneous materials for this part is above the limit requirement in SJ/T11363-2006

此附件旨在确保本产品符合中国 RoHS 标准。以下表格标示此产品中某有毒物质的含量符合中国 RoHS 标准规定的限量要求。

本产品上会附有“环境友好使用期限”的标签，此期限是估算这些物质“不会有泄漏或突变”的年限。本产品可能包含有较短的环境友好使用期限的可替换元件，像是电池或灯管，这些元件将会单独标示出来。

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯 醚 (PBDE)
壳体	X	O	O	O	O	X
显示	X	O	O	O	O	X
印刷电路板	X	O	O	O	O	X
金属螺帽	X	O	O	O	O	O
电缆组装	X	O	O	O	O	X
风扇组装	X	O	O	O	O	X
电力供应组装	X	O	O	O	O	X
电池	O	O	O	O	O	O

O: 表示该有毒有害物质在该部件所有物质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。

X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T11363-2006 标准规定的限量要求。