

MODEL:  
**IMBA-XQ354S**

**ATX Motherboard for Intel® Core™2 Duo/Quad  
GbE, PCIe x16, VGA, SATA with RAID 0,1,5,10  
PCI, PCIe x4, HD Audio, RoHS Compliant**

# User Manual

# Revision

---

Date	Version	Changes
July 7, 2014	1.10	Initial release

# Copyright

---

## **COPYRIGHT NOTICE**

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

## **TRADEMARKS**

All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

# Manual Conventions

---



## **WARNING!**

Warnings appear where overlooked details may cause damage to the equipment or result in personal injury. Warnings should be taken seriously. Warnings are easy to recognize. The word “warning” is written as “**WARNING**,” both capitalized and bold and is followed by text. The text is the warning message. A warning message is shown below:

---



## **WARNING:**

This is an example of a warning message. Failure to adhere to warning messages may result in permanent damage to the IMBA-XQ354S or personal injury to the user. Please take warning messages seriously.

---



## **CAUTION!**

Cautionary messages should also be heeded to help reduce the chance of losing data or damaging the IMBA-XQ354S. Cautions are easy to recognize. The word “caution” is written as “**CAUTION**,” both capitalized and bold and is followed. The text is the cautionary message. A caution message is shown below:

---



## **CAUTION:**

This is an example of a caution message. Failure to adhere to cautions messages may result in permanent damage to the IMBA-XQ354S. Please take caution messages seriously.

---



## IMBA-XQ354S Motherboard



### **NOTE:**

These messages inform the reader of essential but non-critical information. These messages should be read carefully as any directions or instructions contained therein can help avoid making mistakes. Notes are easy to recognize. The word “note” is written as “**NOTE**,” both capitalized and bold and is followed by text. The text is the cautionary message. A note message is shown below:

---



### **NOTE:**

This is an example of a note message. Notes should always be read. Notes contain critical information about the IMBA-XQ354S. Please take note messages seriously.

---

# Table of Contents

---

<b>1 INTRODUCTION.....</b>	<b>1</b>
1.1 OVERVIEW.....	2
1.2 BENEFITS .....	3
1.3 FEATURES.....	3
1.4 CONNECTORS .....	4
1.5 DIMENSIONS.....	5
1.6 DATA FLOW .....	6
1.7 TECHNICAL SPECIFICATIONS .....	7
<b>2 PACKING LIST.....</b>	<b>9</b>
2.1 ANTI-STATIC PRECAUTIONS .....	10
2.2 UNPACKING PRECAUTIONS.....	10
2.3 UNPACKING CHECKLIST .....	11
2.3.1 <i>Package Contents</i> .....	11
2.3.2 <i>Optional Items</i> .....	12
<b>3 CONNECTOR PINOUTS.....</b>	<b>14</b>
3.1 PERIPHERAL INTERFACE CONNECTORS.....	15
3.1.1 <i>IMBA-XQ354S Layout</i> .....	15
3.1.2 <i>Peripheral Interface Connectors</i> .....	16
3.1.3 <i>External Interface Panel Connectors</i> .....	17
3.2 INTERNAL PERIPHERAL CONNECTORS .....	18
3.2.1 <i>ATX CPU Power Connector</i> .....	18
3.2.2 <i>ATX Power Connector</i> .....	19
3.2.3 <i>Audio Connector</i> .....	20
3.2.4 <i>CD In Connector</i> .....	21
3.2.5 <i>Digital I/O Connector</i> .....	22
3.2.6 <i>CPU Fan Connector</i> .....	23
3.2.7 <i>System Fan Connectors</i> .....	24
3.2.8 <i>Floppy Disk Connector</i> .....	25

## IMBA-XQ354S Motherboard

3.2.9 Front Panel Connector .....	26
3.2.10 Infrared Interface Connector .....	27
3.2.11 PCI Express x4 Slots .....	28
3.2.12 PCI Express x16 Slot.....	30
3.2.13 PCI Slots .....	32
3.2.14 SATA Drive Connectors .....	35
3.2.15 SPDIF Connector.....	36
3.2.16 Serial Port Connectors .....	37
3.2.17 SPI Flash Connector.....	38
3.2.18 Trusted Platform Module (TPM) Connector.....	39
3.2.19 USB Connectors.....	40
<b>3.3 EXTERNAL INTERFACE CONNECTORS .....</b>	<b>41</b>
3.3.1 Audio Connector .....	42
3.3.2 Ethernet Connector.....	43
3.3.3 Keyboard and Mouse Connector .....	44
3.3.4 Parallel Port Connector .....	45
3.3.5 Serial Port Connector.....	46
3.3.6 USB Ports.....	47
3.3.7 VGA Connector .....	47
<b>4 INSTALLATION .....</b>	<b>49</b>
4.1 ANTI-STATIC PRECAUTIONS .....	50
4.2 INSTALLATION CONSIDERATIONS.....	51
4.2.1 Installation Notices .....	51
4.2.2 Installation Checklist .....	52
4.3 CPU, CPU COOLING KIT AND DIMM INSTALLATION .....	53
4.3.1 Socket LGA775 CPU Installation .....	53
4.3.2 Socket LGA775 CF-520 Cooling Kit Installation.....	56
4.3.3 DIMM Installation .....	58
4.4 JUMPER SETTINGS .....	60
4.4.1 Clear CMOS Jumper.....	61
4.4.2 COM Port Pin 9 Function Select.....	62
4.4.3 COM Port Pin 9 Voltage Setting Select .....	63
4.4.4 SPDIF Out Selection.....	64
4.5 CHASSIS INSTALLATION.....	66

4.5.1 Airflow.....	66
4.5.2 IMBA-XQ354S Installation.....	66
4.5.3 Dual RS-232 Cable with Slot Bracket.....	66
4.5.4 Single RS-232 Cable with Slot Bracket.....	67
4.5.5 SATA Drive Connection (Two Cables).....	68
<b>4.6 EXTERNAL PERIPHERAL INTERFACE CONNECTION .....</b>	<b>70</b>
4.6.1 Keyboard and Mouse .....	71
4.6.2 LAN .....	71
4.6.3 Parallel Device Connection.....	72
4.6.4 Serial Device .....	73
4.6.5 USB .....	74
4.6.6 VGA Monitor.....	75
4.6.7 Audio Connector .....	76
<b>5 BIOS SETUP .....</b>	<b>78</b>
5.1 INTRODUCTION.....	79
5.1.1 Starting Setup.....	79
5.1.2 Using Setup .....	79
5.1.3 Getting Help.....	80
5.1.4 Unable to Reboot After Configuration Changes.....	80
5.1.5 BIOS Menu Bar.....	80
5.2 MAIN.....	81
5.3 ADVANCED.....	82
5.3.1 CPU Configuration.....	84
5.3.2 IDE Configuration .....	85
5.3.2.1 IDE Master, IDE Slave .....	87
5.3.3 Floppy Configuration.....	92
5.3.4 Super IO Configuration .....	93
5.3.5 Hardware Health Configuration.....	96
5.3.6 APM Configuration.....	100
5.3.6.1 ACPI Configuration .....	102
5.3.7 AHCI Configuration.....	103
5.3.8 Remote Access Configuration .....	104
5.3.9 Trusted Computing.....	107
5.3.10 USB Configuration.....	108



## IMBA-XQ354S Motherboard

5.4 PCI/PNP.....	109
5.5 BOOT.....	112
5.5.1 <i>Boot Settings Configuration</i> .....	113
5.5.2 <i>Boot Device Priority</i> .....	115
5.5.3 <i>Hard Disk Drives</i> .....	115
5.5.4 <i>CD/DVD Drives</i> .....	116
5.5.5 <i>Removable Drives</i> .....	117
5.6 SECURITY.....	119
5.7 CHIPSETS.....	120
5.7.1 <i>Northbridge Chipset Configuration</i> .....	121
5.7.2 <i>Southbridge Chipset Configuration</i> .....	123
5.8 EXIT.....	124
<b>6 SOFTWARE DRIVERS .....</b>	<b>126</b>
6.1 AVAILABLE SOFTWARE DRIVERS .....	127
6.2 STARTING THE DRIVER PROGRAM .....	127
6.3 CHIPSET DRIVER .....	129
6.4 GRAPHICS DRIVER .....	131
6.5 LAN DRIVER .....	135
6.6 AUDIO DRIVER.....	138
6.6.1 <i>BIOS Setup</i> .....	138
6.6.2 <i>Driver Installation</i> .....	138
6.7 INTEL® MATRIX STORAGE MANAGER DRIVER.....	140
<b>A BIOS OPTIONS .....</b>	<b>145</b>
<b>B TERMINOLOGY.....</b>	<b>148</b>
<b>C DIGITAL I/O INTERFACE.....</b>	<b>152</b>
C.1 INTRODUCTION.....	153
C.2 DIO CONNECTOR PINOUTS.....	153
C.3 ASSEMBLY LANGUAGE SAMPLES.....	153
C.3.1 <i>Enable the DIO Input Function</i> .....	153
C.3.2 <i>Enable the DIO Output Function</i> .....	154
<b>D WATCHDOG TIMER .....</b>	<b>155</b>
<b>E INTEL® MATRIX STORAGE MANAGER .....</b>	<b>158</b>

E.1 INTRODUCTION .....	159
<i>E.1.1 Precautions</i> .....	159
E.2 FEATURES AND BENEFITS.....	160
E.3 ACCESSING THE INTEL® MATRIX STORAGE MANAGER .....	160
E.4 INSTALLING THE OPERATING SYSTEM TO THE RAID ARRAY .....	161
<b>F HAZARDOUS MATERIALS DISCLOSURE.....</b>	<b>162</b>
F.1 HAZARDOUS MATERIALS DISCLOSURE TABLE FOR IPB PRODUCTS CERTIFIED AS ROHS COMPLIANT UNDER 2002/95/EC WITHOUT MERCURY .....	163

# List of Figures

Figure 1–1: IMBA-XQ354S .....	2
Figure 1–2: Overview.....	4
Figure 1-3: IMBA-XQ354S Dimensions (mm).....	5
Figure 1-4: Data Flow Block Diagram.....	6
Figure 3-1: Connector and Jumper Locations.....	15
Figure 3-2: AT Power Connector Location .....	18
Figure 3-3: ATX Power Connector Pinout Locations.....	19
Figure 3-4: Audio Connector Pinouts.....	20
Figure 3-5: Audio CD In Connector Location .....	21
Figure 3-6: Digital I/O Connector Locations .....	22
Figure 3-7: CPU Fan Connector Location .....	23
Figure 3-8: System Fan Connector Location.....	24
Figure 3-9: 34-pin FDD Connector Location .....	25
Figure 3-10: Front Panel Connector Pinout Locations .....	27
Figure 3-11: Infrared Connector Pinout Locations .....	28
Figure 3-12: PCIe x4 Connector Locations .....	29
Figure 3-13: PCIe x16 Connector Location .....	30
Figure 3-14: PCI Slot Location .....	33
Figure 3-15: SATA Drive Connector Locations .....	36
Figure 3-16: SPDIF Connector Pinout Locations .....	37
Figure 3-17: Serial Port Connectors Pinout Locations.....	38
Figure 3-18: SPI Flash Connector Pinouts.....	39
Figure 3-19: TPM Connector Pinout Locations .....	40
Figure 3-20: USB Connector Pinout Locations .....	41
Figure 3-21: IMBA-XQ354S External Interface Connectors.....	42
Figure 3-22: Audio Connector .....	43
Figure 3-23: Ethernet Connector.....	43
Figure 3-24: PS/2 Connector .....	44
Figure 3-25: Parallel Port Connector Location.....	46
Figure 3-26: Serial Port Pinout Locations .....	46

Figure 3-27: VGA Connector .....	48
Figure 4-1: Intel LGA775 Socket .....	54
Figure 4-2: Remove the CPU Socket Protective Shield .....	54
Figure 4-3: Open the CPU Socket Load Plate .....	55
Figure 4-4: Insert the Socket LGA775 CPU .....	56
Figure 4-5: Cooling Kit .....	57
Figure 4-6: Securing the Heat sink to the PCB Board .....	58
Figure 4-7: Installing a DIMM .....	59
Figure 4-8: Clear CMOS Jumper .....	62
Figure 4-9: COM Port Pin 9 Function Select Jumper Location .....	63
Figure 4-10: COM Port Pin 9 Voltage Setting Select Jumper Location .....	64
Figure 4-11: SPDIF Out Selection Jumper Pinout Location .....	65
Figure 4-12: Dual RS-232 Cable Installation .....	67
Figure 4-13: Single RS-232 Cable Installation .....	68
Figure 4-14: SATA Drive Cable Connection .....	69
Figure 4-15: SATA Power Drive Connection .....	70
Figure 4-16: PS/2 Keyboard/Mouse Connector .....	71
Figure 4-17: LAN Connection .....	72
Figure 4-18: Parallel Device Connector .....	73
Figure 4-19: Serial Device Connector .....	74
Figure 4-20: USB Connector .....	75
Figure 4-21: VGA Connector .....	76
Figure 4-22: Audio Connector .....	77
Figure 6-1: Start Up Screen .....	128
Figure 6-2: Drivers .....	128
Figure 6-3: Intel® Setup Welcome Screen .....	129
Figure 6-4: Intel® Chipset Driver License Agreement .....	130
Figure 6-5: Readme File .....	130
Figure 6-6: Intel® Chipset Driver Complete Installation Screen .....	131
Figure 6-7: Graphics Driver Readme File .....	132
Figure 6-8: Graphics Driver Installation Welcome Screen .....	132
Figure 6-9: GMA Driver License Agreement .....	133
Figure 6-10: GMA Driver Installing Notice .....	133
Figure 6-11: GMA Driver Installation Complete .....	134
Figure 6-12: GMA Driver Installing Notice .....	134



## IMBA-XQ354S Motherboard

Figure 6-13: LAN Driver Welcome Screen .....	135
Figure 6-14: LAN Driver License Agreement .....	136
Figure 6-15: LAN Driver Setup Options.....	136
Figure 6-16: LAN Driver Installation Ready Window.....	137
Figure 6-17: LAN Driver Installation Progress.....	138
Figure 6-18: InstallShield Wizard Welcome Screen .....	139
Figure 6-19: Installation Wizard Finished.....	139
Figure 6-20: InstallShield Wizard Setup Screen .....	140
Figure 6-21: Matrix Storage Manager Setup Screen .....	141
Figure 6-22: Matrix Storage Manager Welcome Screen .....	141
Figure 6-23: Matrix Storage Manager Warning Screen.....	142
Figure 6-24: Matrix Storage Manager License Agreement.....	142
Figure 6-25: Matrix Storage Manager Readme File .....	143
Figure 6-26: Matrix Storage Manager Setup Complete.....	143

# List of Tables

---

Table 1-1: Technical Specifications.....	8
Table 2-1: Packing List.....	12
Table 2-2: Optional Items.....	13
Table 3-1: Peripheral Interface Connectors.....	17
Table 3-2: Rear Panel Connectors.....	17
Table 3-3: ATX Power Connector Pinouts.....	18
Table 3-4: ATX Power Connector Pinouts.....	20
Table 3-5: Audio Connector Pinouts.....	21
Table 3-6: Audio CD In Connector Pinouts.....	22
Table 3-7: Digital I/O Connector Pinouts.....	23
Table 3-8: CPU Fan Connector Pinouts.....	23
Table 3-9: System Fan Connector Pinouts.....	24
Table 3-10: 34-pin FDD Connector Pinouts.....	26
Table 3-11: Front Panel Connector Pinouts.....	27
Table 3-12: Infrared Connector Pinouts.....	28
Table 3-13: PCIe x4 Pinouts.....	30
Table 3-14: PCIe x16 Side A Pinouts.....	31
Table 3-15: PCIe x16 Side B Pinouts.....	32
Table 3-16: PCI Slot.....	35
Table 3-17: SATA Drive Connector Pinouts.....	36
Table 3-18: SPDIF Connector Pinouts.....	37
Table 3-19: Serial Port Connector Pinouts.....	38
Table 3-20: SPI Flash Connector.....	39
Table 3-21: TPM Connector Pinouts.....	40
Table 3-22: USB Port Connector Pinouts.....	41
Table 3-23: Ethernet Connector Pinouts.....	43
Table 3-24: Connector LEDs.....	44
Table 3-25: PS/2 Connectors.....	45
Table 3-26: Parallel Port Connector Pinouts.....	45
Table 3-27: Serial Port Pinouts.....	46

## IMBA-XQ354S Motherboard

Table 3-28: USB Connector Pinouts .....	47
Table 3-29: VGA Connector Pinouts.....	47
Table 4-1: Jumpers .....	60
Table 4-2: Clear CMOS Jumper Settings.....	61
Table 4-3: COM Port Pin 9 Function Select Jumper Settings .....	63
Table 4-4: COM Port Pin 9 Voltage Setting Select Jumper Settings .....	64
Table 4-5: SPDIF Out Selection Jumper Settings.....	65
Table 5-1: BIOS Navigation Keys .....	80

# BIOS Menus

---

BIOS Menu 1: Main .....	81
BIOS Menu 2: Advanced .....	83
BIOS Menu 3: CPU Configuration .....	84
BIOS Menu 4: IDE Configuration .....	85
BIOS Menu 5: IDE Master and IDE Slave Configuration .....	87
BIOS Menu 6: IDE Master and IDE Slave Configuration .....	92
BIOS Menu 7: Super IO Configuration .....	93
BIOS Menu 8: Hardware Health Configuration .....	96
BIOS Menu 9: Hardware Health Configuration 2 .....	99
BIOS Menu 10: AHCI Port n Configuration Menu .....	100
BIOS Menu 11: Advanced ACPI Configuration .....	102
BIOS Menu 12: AHCI Configuration .....	103
BIOS Menu 13: Remote Access Configuration [Advanced] .....	104
BIOS Menu 14: Trusted Computing .....	107
BIOS Menu 15: USB Configuration .....	108
BIOS Menu 16: PCI/PnP Configuration .....	110
BIOS Menu 17: Boot .....	112
BIOS Menu 18: Boot Settings Configuration .....	113
BIOS Menu 19: Boot Device Priority Settings .....	115
BIOS Menu 20: Hard Disk Drives .....	116
BIOS Menu 21: CD/DVD Drives .....	117
BIOS Menu 22: Removable Drives .....	118
BIOS Menu 23: Security .....	119
BIOS Menu 24: Chipset .....	120
BIOS Menu 25: Northbridge Chipset Configuration .....	121
BIOS Menu 26: Southbridge Chipset Configuration .....	123
BIOS Menu 27: Exit .....	124




Chapter

1

# Introduction

---

## 1.1 Overview



**Figure 1–1: IMBA-XQ354S**

The IMBA-XQ354S is an ATX form factor industrial PC motherboard. The ATX form factor is a relatively large form factor, providing room for extra features and capabilities including more powerful processors that benefit from the larger dimensions and better cooling of ATX computer cases.

The IMBA-XQ354S supports Intel® Core™2 Quad, Intel® Core™2 Duo and Intel® Celeron® processors and supports up to up to 8.0 GB of DDR2 memory with up to 2.0 GB in each memory slot.

Six SATA ports provide advanced storage capabilities with 3Gb/s data transfer rates. RAID 0 support allows for increased data throughput for applications requiring quick data access. RAID 1, 5 and 10 provide data redundancy allowing for the failure of one or more disks without losing data.

Graphics capabilities include a VGA port on the rear panel, and a PCIe x16 graphics card slot. The graphics card slot supports the latest graphics cards, offering rendering and quality capable of supporting the most intensive graphics applications.

Networking is provided through the Intel® GbE controller. The GbE controller allows network data speeds of up to 1.0 Gb/s, allowing for fast communication between computers on the network and with computers on external networks.

## IMBA-XQ354S Motherboard

Expansion capabilities include 10 USB ports, six serial ports and a parallel port.

### 1.2 Benefits

Some of the IMBA-XQ354S motherboard benefits include,

- Operating reliably in harsh industrial environments up to 60°C
- The system is always available and will reboot if the system crashes
- Powerful processor options are ideal for computing intensive applications
- Data is protected through fast and reliable SATA RAID storage

### 1.3 Features

Some of the IMBA-XQ354S motherboard features are listed below:

- ATX form factor
- RoHS compliant
- LGA 775 CPU socket
- PCI and PCIe expansion slots
- Supports four DDR2 DIMMs up to 2.0 GB each
- One Gigabit Ethernet controller
- Supports 12 USB 2.0 ports
- Integrated audio

## 1.4 Connectors

The connectors on the IMBA-XQ354S are shown in the figure below.




Figure 1–2: Overview



IMBA-XQ354S Motherboard

1.5 Dimensions

The dimensions of the board are listed below:

- Length: 305 mm
- Width: 244 mm




Figure 1-3: IMBA-XQ354S Dimensions (mm)



### 1.6 Data Flow

Figure 1-4 shows the data flow between the system chipset, the CPU and other components installed on the motherboard.




Figure 1-4: Data Flow Block Diagram

## IMBA-XQ354S Motherboard

### 1.7 Technical Specifications

IMBA-XQ354S motherboard technical specifications are listed in **Table 1-1**.

Specification	IMBA-XQ354S
<b>Form Factor</b>	ATX
<b>CPU Supported</b>	LGA775 Intel® Core™2 Quad LGA775 Intel® Core™2 Duo LGA775 Intel® Celeron® D
<b>Front Side Bus</b>	800 MHz, 1066 MHz or 1333 MHz
<b>Northbridge Chipset</b>	Intel® Q35
<b>Southbridge Chipset</b>	Intel® ICH9DO
<b>Memory</b>	Supports four dual-channel 2.0 GB (max.) 667 MHz or 800 MHz DDR2 SDRAM DIMMs (system max. 8.0 GB)
<b>Expansion Slots</b>	1 x PCIe x16 slot 3 x PCIe x4 slot 3 x PCI slot
<b>BIOS</b>	AMI BIOS
<b>Graphics</b>	VGA integrated in Intel® Q35
<b>Floppy Disk Drives</b>	Two 5.25" 360 KB or 1.2 MB floppy disk drives (FDD) and/or 3.5".720 KB, 1.44 MB or 2.88 MB FDD.
<b>Serial Ports</b>	Six RS-232 ports supported with two from the iTE IT8718F super I/O and four from the Fintek F81216DG
<b>Peripherals</b>	1 x Parallel port supporting normal, EPP and ECP modes 12 x USB 2.0/1.1 ports 1 x Dual PS/2 connector (for keyboard and mouse)
<b>USB 2.0/1.1 port</b>	Four External Eight via internal pin header
<b>Serial ATA</b>	Supports six independent serial ATA (SATA) channels with 3.0 Gb/s data transfer rates
<b>Ethernet</b>	Intel® 82573L (MAC+PHY) through the PCIe x1 interface

Specification	IMBA-XQ354S
Digital I/O	8-bit, 4-bit input/4-bit output
Super I/O Controller	iTE IT8718F
Audio	Realtek ALC888 HD Audio codec
Watchdog Timer	Software Programmable supports 1~255 sec. system reset
Trusted Platform Module	Supports TPM v1.2 and above
Power Supply	ATX supported
Fans	1 x 4-pin CPU cooling fan 2 x 3-pin system cooling fans
Power Consumption	3.3 V @ 2.96 A 5 V @ 6.92 A 5 VSB @ 1.61 A 12 V @ 2.77 A (2.66 GHz Intel® Core™2 Duo E6850CPU with 1333 MHz FSB and 8.0 GB of DDR2 memory running 3DMark 2001)
Operating temperature	0°C ~ 60°C (requires cooler and silicone heat sink paste)
Humidity	0% ~ 95% (non-condensing)
Dimensions	305 mm x 244 mm
Weight GW/NW	1200 g/600 g

**Table 1-1: Technical Specifications**

Chapter

2

# Packing List

---

## 2.1 Anti-static Precautions

---



### WARNING!

Failure to take ESD precautions during the installation of the IMBA-XQ354S may result in permanent damage to the IMBA-XQ354S and severe injury to the user.

---

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the IMBA-XQ354S. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the IMBA-XQ354S, or any other electrical component is handled, the following anti-static precautions are strictly adhered to.

- **Wear an anti-static wristband:** - Wearing a simple anti-static wristband can help to prevent ESD from damaging the board.
- **Self-grounding:** - Before handling the board touch any grounded conducting material. During the time the board is handled, frequently touch any conducting materials that are connected to the ground.
- **Use an anti-static pad:** When configuring the IMBA-XQ354S, place it on an anti-static pad. This reduces the possibility of ESD damaging the IMBA-XQ354S.
- **Only handle the edges of the PCB:** - When handling the PCB, hold the PCB by the edges.

## 2.2 Unpacking Precautions

When the IMBA-XQ354S is unpacked, please do the following:

- Follow the anti-static precautions outlined in **Section 2.1**.
- Make sure the packing box is facing upwards so the IMBA-XQ354S does not fall out of the box.
- Make sure all the components shown in **Section 2.3** are present.



## IMBA-XQ354S Motherboard

### 2.3 Unpacking Checklist












#### NOTE:

If any of the components listed in the checklist below are missing, do not proceed with the installation. Contact the IEI reseller or vendor the IMBA-XQ354S was purchased from or contact an IEI sales representative directly by sending an email to [sales@ieiworld.com](mailto:sales@ieiworld.com).

#### 2.3.1 Package Contents

The IMBA-XQ354S is shipped with the following components:





Quantity	Item and Part Number	Image
1	IMBA-XQ354S	
2	Dual RS-232 cable (P/N: 19800-003600-100-RS)	
1	Single RS-232 cable (P/N: 19800-010900-200-RS)	
6	SATA cable (P/N: 32801-000703-400-RS)	
1	I/O Shielding (P/N: 45014-0025C0-00-RS)	
1	Mini jumper pack (2.54 mm) (P/N: 33100-000656-RS)	

Quantity	Item and Part Number	Image
1	One Key Recovery CD (P/N: IEI-7B000-000478-RS)	
1	Utility CD	
1	Quick Installation Guide	





**Table 2-1: Packing List**

### 2.3.2 Optional Items

The IMBA-XQ354S is shipped with the following components:

Item and Part Number	Image
Dual USB cable (w bracket) (P/N: 19800-003100-300-RS)	
4-port USB cable (P/N: 19800-000100-200-RS)	
RS-232/422/485 cable (P/N: 3200-000063-RS)	
CPU cooler (P/N: CF-775A-RS)	

## IMBA-XQ354S Motherboard

Item and Part Number	Image
CPU cooler (P/N: CF-520-RS-R11)	
20-pin Infineon TPM, software management tool, firmware V3.17 (P/N: TPM-IN01-R11)	
PCIe x16 VGA output SDVO card supports dual display (IEI CPU board only) (P/N: SDVO-100VGA-R10)	
PCIe x16 DVI output SDVO card supports dual display (IEI CPU board only) (P/N: SDVO-100DVI-R10)	

**Table 2-2: Optional Items**

Chapter

**3**

# Connector Pinouts

---

## IMBA-XQ354S Motherboard

### 3.1 Peripheral Interface Connectors

Section 3.1.2 shows peripheral interface connector locations. Section 3.1.2 lists all the peripheral interface connectors seen in Section 3.1.2.

#### 3.1.1 IMBA-XQ354S Layout

Figure 3-1 shows the on-board peripheral connectors, rear panel peripheral connectors and on-board jumpers.




Figure 3-1: Connector and Jumper Locations



### 3.1.2 Peripheral Interface Connectors

**Table 3-1** shows a list of the peripheral interface connectors on the IMBA-XQ354S. Detailed descriptions of these connectors can be found below.

Connector	Type	Label
ATX power connector, CPU	4-pin ATX	CPU12 V1
ATX power connector, system	24-pin ATX	ATX1
Audio connector	10-pin header	FPAUDIO1
CD in connector	4-pin header	CDIN1
Digital I/O connector	10-pin header	DIO1
Fan connector, CPU	4-pin wafer	CPU_FAN1
Fan connector, System	3-pin wafer	SYS_FAN1 SYS_FAN2
Floppy disk connector	34-pin box header	FDD1
Front panel connector	14-pin header	F_PANEL1
Infrared connector	5-pin header	IR1
PCI connectors	PCI slot	PCI1 PCI2 PCI3
PCIe x4 connectors	PCIe x4 slot	PCIEX4_1 PCIEX4_2 PCIEX4_3
PCIe x16 connector	PCIe x16 slot	PCIEX16_1
SATA connectors	7-pin SATA	SATA1 SATA2 SATA3 SATA4 SATA5 SATA6
SPDIF connector	5-pin header	SPDIF1

## IMBA-XQ354S Motherboard

Connector	Type	Label
Serial port connectors	9-pin box header	COM2 COM3 COM4 COM5 COM6
SPI flash connector	8-pin header	JSPI1
TPM connector	20-pin header	TPM1
USB connectors	10-pin header	USB45 USB67 USB89 USB1011

**Table 3-1: Peripheral Interface Connectors**

### 3.1.3 External Interface Panel Connectors

**Table 3-2** lists the rear panel connectors on the IMBA-XQ354S. Detailed descriptions of these connectors can be found in **Section 3.1**.

Connector	Type	Label
Audio jacks (six)	Audio jacks	AUDIO1
Keyboard and mouse connectors	Dual PS/2	KB_MS1
LAN connector	RJ-45	LAN1_USB01
Parallel port connector	D-sub 26 female	3IN1_DSUB1
RS-232 serial port connector	D-sub 9 male	3IN1_DSUB1
USB 2.0 ports	Dual USB ports	LAN1_USB01 USB23
VGA port connector	D-sub 15 female	3IN1_DSUB1

**Table 3-2: Rear Panel Connectors**


### 3.2 Internal Peripheral Connectors

Internal peripheral connectors are found on the motherboard and are only accessible when the motherboard is outside of the chassis. This section has complete descriptions of all the internal, peripheral connectors on the IMBA-XQ354S.

#### 3.2.1 ATX CPU Power Connector

- CN Label:** CPU12 V1
- CN Type:** 4-pin ATX power connector
- CN Location:** See **Figure 3-2**
- CN Pinouts:** See **Table 3-3**

The 4-pin ATX power connector is connected to an ATX power supply.



**Figure 3-2: AT Power Connector Location**

PIN NO.	DESCRIPTION
1	GND
2	GND
3	+12 V
4	+12 V


**Table 3-3: ATX Power Connector Pinouts**

## IMBA-XQ354S Motherboard

### 3.2.2 ATX Power Connector

- CN Label:** ATX1
- CN Type:** 24-pin ATX
- CN Location:** See **Figure 3-3**
- CN Pinouts:** See **Table 3-4**

The ATX connector is connected to an external ATX power supply. Power is provided to the system, from the power supply through this connector.



**Figure 3-3: ATX Power Connector Pinout Locations**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	+3.3 V	13	+3.3 V
2	+3.3 V	14	-12 V
3	GND	15	GND
4	+5 V	16	PS-ON
5	GND	17	GND
6	+5 V	18	GND
7	GND	19	GND
8	NC	20	NC
9	+VCC5SB	21	+5 V


PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
10	+12 V	22	+5 V
11	+12 V	23	+5 V
12	NC	24	GND

**Table 3-4: ATX Power Connector Pinouts**

### 3.2.3 Audio Connector

- CN Label:** FPAUDIO1
- CN Type:** 10-pin header
- CN Location:** See **Figure 3-4**
- CN Pinouts:** See **Table 3-5**

The 10-pin audio connector is connected to external audio devices including speakers and microphones for the input and output of audio signals to and from the system.



**Figure 3-4: Audio Connector Pinouts**



## IMBA-XQ354S Motherboard


PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	Microphone left	2	GND
3	Microphone right	4	PRESENCE
5	Line right	6	GND
7	SENSE_SEND	8	N/C
9	Line left	10	GND

**Table 3-5: Audio Connector Pinouts**

### 3.2.4 CD In Connector

- CN Label:** CD\_IN1
- CN Type:** 4-pin header
- CN Location:** See **Figure 3-5**
- CN Pinouts:** See **Table 3-6**

The 4-pin audio CD in connector is connected to an external audio CD device for the input and output of audio signals from a CD player to the system.



**Figure 3-5: Audio CD In Connector Location**


PIN NO.	DESCRIPTION
1	Left signal
2	Ground
3	Ground
4	Right signal

**Table 3-6: Audio CD In Connector Pinouts**

### 3.2.5 Digital I/O Connector

- CN Label:** DIO1
- CN Type:** 10-pin header
- CN Location:** See **Figure 3-6**
- CN Pinouts:** See **Table 3-7**

The digital input/output connector is managed through a Super I/O chip. The Digital I/O connector pins are user programmable.



**Figure 3-6: Digital I/O Connector Locations**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	GND	2	VCC
3	Output 3	4	Output 2
5	Output 1	6	Output 0
7	Input 3	8	Input 2

## IMBA-XQ354S Motherboard


PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
9	Input 1	10	Input 0

**Table 3-7: Digital I/O Connector Pinouts**

### 3.2.6 CPU Fan Connector

- CN Label:** CPU\_FAN1
- CN Type:** 4-pin wafer
- CN Location:** See **Figure 3-7**
- CN Pinouts:** See **Table 3-8**

The cooling fan connector provides a 12 V, 500mA current to a CPU cooling fan. The connector has a "rotation" pin to get rotation signals from fans and notify the system so the system BIOS can recognize the fan speed. Please note that only specified fans can issue the rotation signals.



**Figure 3-7: CPU Fan Connector Location**

PIN NO.	DESCRIPTION
1	GND
2	+12 VCC
3	Rotation Signal
4	Control

**Table 3-8: CPU Fan Connector Pinouts**

### 3.2.7 System Fan Connectors


**CN Label:** SYS\_FAN1, SYS\_FAN2

**CN Type:** 3-pin header

**CN Location:** See **Figure 3-8**

**CN Pinouts:** See **Table 3-9**

The cooling fan connector provides a 12 V, 500mA current to a system cooling fan. The connector has a "rotation" pin to get rotation signals from fans and notify the system so the system BIOS can recognize the fan speed. Please note that only specified fans can issue the rotation signals.



**Figure 3-8: System Fan Connector Location**

PIN NO.	DESCRIPTION
1	GND
2	+12 V
3	Fan Speed Detect

**Table 3-9: System Fan Connector Pinouts**


## IMBA-XQ354S Motherboard

### 3.2.8 Floppy Disk Connector

- CN Label:** FDD1
- CN Type:** 34-pin box header
- CN Location:** See **Figure 3-9**
- CN Pinouts:** See **Table 3-10**

The floppy disk connector is connected to a floppy disk drive. The IMBA-XQ354S supports the following floppy disk drives:

- 360 KB
- 720 KB
- 1.2 MB
- 1.44 MB
- 2.88 MB



**Figure 3-9: 34-pin FDD Connector Location**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	GND	2	REDUCE WRITE
3	GND	4	N/C
5	N/C	6	N/C
7	GND	8	INDEX#
9	GND	10	MOTOR ENABLE A#



PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
11	GND	12	DRIVE SELECT B#
13	GND	14	DRIVE SELECT A#
15	GND	16	MOTOR ENABLE B#
17	GND	18	DIRECTION#
19	GND	20	STEP#
21	GND	22	WRITE DATA#
23	GND	24	WRITE GATE#
25	GND	26	TRACK 0#
27	GND	28	WRITE PROTECT#
29	GND	30	READ DATA#
31	GND	32	SIDE 1 SELECT#
33	GND	34	DISK CHANGE#

**Table 3-10: 34-pin FDD Connector Pinouts**

### 3.2.9 Front Panel Connector

- CN Label:** F\_PANEL1
- CN Type:** 14-pin header
- CN Location:** See **Figure 3-10**
- CN Pinouts:** See **Table 3-11**

The front panel connector connects to external switches and indicators to monitor and control the motherboard. These indicators and switches include:

- Power button
- Reset button
- Power LED
- HDD LED
- Speaker

IMBA-XQ354S Motherboard




Figure 3-10: Front Panel Connector Pinout Locations


FUNCTION	PIN NO.	DESCRIPTION	FUNCTION	PIN NO.	DESCRIPTION
Power LED	1	LED +5 V	Speaker	2	+5 V
	3	N/C		4	N/C
	5	Ground		6	N/C
Power Button	7	Power Button+	8	Speaker	
	9	Power Button-	Reset	10	N/C
HDD LED	11	+5 V		12	RESET-
	13	HDLED-		14	GND

Table 3-11: Front Panel Connector Pinouts

3.2.10 Infrared Interface Connector

- CN Label:** IR1
- CN Type:** 5-pin header
- CN Location:** See **Figure 3-11**
- CN Pinouts:** See **Table 3-12**

The infrared interface connector supports both Serial Infrared (SIR) and Amplitude Shift Key Infrared (ASKIR) interfaces.



**Figure 3-11: Infrared Connector Pinout Locations**

PIN NO.	DESCRIPTION
1	VCC
2	NC
3	IR-RX
4	GND
5	IR-TX

**Table 3-12: Infrared Connector Pinouts**

### 3.2.11 PCI Express x4 Slots

**CN Label:** PCIE4X\_1, PCIE4X\_2 and PCIE4X\_3

**CN Type:** PCIe x4 slots

**CN Location:** See **Figure 3-12**

**CN Pinouts:** See **Table 3-13**

PCIe x4 expansion devices can be inserted into the PCIe x4 slots.

IMBA-XQ354S Motherboard




Figure 3-12: PCIe x4 Connector Locations

SIDE A				SIDE B			
PIN	NAME	PIN	NAME	PIN	NAME	PIN	NAME
A1	N/C	A2	+12 V	B1	+12 V	B2	+12 V
A3	+12 V	A4	GND	B3	+12 V	B4	GND
A5	N/C	A6	N/C	B5	SMCLK	B6	SMDAT
A7	N/C	A8	N/C	B7	GND	B8	+3.3 V
A9	+3.3 V	A10	+3.3 V	B9	N/C	B10	3.3 V
A11	RESET	A12	GND	B11	WAKE#	B12	N/C
A13	REFCLK+	A14	REFCLK-	B13	GND	B14	HSOp(0)
A15	GND	A16	HSIp(0)	B15	HSOn(0)	B16	GND
A17	HSIn(0)	A18	GND	B17	N/C	B18	GND
A19	N/C	A20	GND	B19	HSOp(1)	B20	HSOn(1)
A21	HSIp(1)	A22	HSIn(1)	B21	GND	B22	GND
A23	GND	A24	GND	B23	HSOp(2)	B24	HSOn(2)
A25	HSIp(2)	A26	HSIn(2)	B25	GND	B26	GND
A27	GND	A28	GND	B27	HSOp(3)	B28	HSOn(3)


SIDE A				SIDE B			
A29	HSIp(3)	A30	HSIn(3)	B29	GND	B30	N/C
A31	GND	A32	N/C	B31	N/C	B32	GND

**Table 3-13: PCIe x4 Pinouts**

### 3.2.12 PCI Express x16 Slot

- CN Label:**            **PCIEX16\_1**
- CN Type:**            **PCIe x16 slot**
- CN Location:**       **See Figure 3-13**
- CN Pinouts:**        **See Table 3-14 (Side A) Table 3-15 (Side B)**

PCIe x16 expansion devices can be inserted into the PCIe x16 slot.



**Figure 3-13: PCIe x16 Connector Location**

PIN	NAME	PIN	NAME	PIN	NAME	PIN	NAME
A1	Name	A22	HSIn(1)	A43	HSIp(6)	A64	HSIp(11)
A2	PRSNT#1	A23	GND	A44	HSIn(6)	A65	HSIn(11)
A3	+12v	A24	GND	A45	GND	A66	GND
A4	+12v	A25	HSIp(2)	A46	GND	A67	GND
A5	GND	A26	HSIn(2)	A47	HSIp(7)	A68	HSIp(12)



## IMBA-XQ354S Motherboard

PIN	NAME	PIN	NAME	PIN	NAME	PIN	NAME
A6	JTAG2	A27	GND	A48	HSIn(7)	A69	HSIn(12)
A7	JTAG3	A28	GND	A49	GND	A70	GND
A8	JTAG4	A29	HSIp(3)	A50	RSVD	A71	GND
A9	JTAG5	A30	HSIn(3)	A51	GND	A72	HSIp(13)
A10	+3.3v	A31	GND	A52	HSIp(8)	A73	HSIn(13)
A11	+3.3v	A32	RSVD	A53	HSIn(8)	A74	GND
A12	PWRGD	A33	RSVD	A54	GND	A75	GND
A13	GND	A34	GND	A55	GND	A76	HSIp(14)
A14	REFCLK+	A35	HSIp(4)	A56	HSIp(9)	A77	HSIn(14)
A15	REFCLK-	A36	HSIn(4)	A57	HSIn(9)	A78	GND
A16	GND	A37	GND	A58	GND	A79	GND
A17	HSIp(0)	A38	GND	A59	GND	A80	HSIp(15)
A18	HSIn(0)	A39	HSIp(5)	A60	HSIp(10)	A81	HSIn(15)
A19	GND	A40	HSIn(5)	A61	HSIn(10)	A82	GND
A20	RSVD	A41	GND	A62	GND		
A21	GND	A42	GND	A63	GND		

**Table 3-14: PCIe x16 Side A Pinouts**

PIN	NAME	PIN	NAME	PIN	NAME	PIN	NAME
B1	+12v	B22	GND	B43	GND	B64	GND
B2	+12v	B23	HSOp(2)	B44	GND	B65	GND
B3	RSVD	B24	HSOn(2)	B45	HSOp(7)	B66	HSOp(12)
B4	GND	B25	GND	B46	HSOn(7)	B67	HSOn(12)
B5	SMCLK	B26	GND	B47	GND	B68	GND
B6	SMDAT	B27	HSOp(3)	B48	PRSNT#2	B69	GND
B7	GND	B28	HSOn(3)	B49	GND	B70	HSOp(13)
B8	+3.3v	B29	GND	B50	HSOp(8)	B71	HSOn(13)
B9	JTAG1	B30	RSVD	B51	HSOn(8)	B72	GND
B10	3.3 Vaux	B31	PRSNT#2	B52	GND	B73	GND
B11	WAKE#	B32	GND	B53	GND	B74	HSOp(14)
B12	RSVD	B33	HSOp(4)	B54	HSOp(9)	B75	HSOn(14)

PIN	NAME	PIN	NAME	PIN	NAME	PIN	NAME
B13	GND	B34	HSOn(4)	B55	HSOn(9)	B76	GND
B14	HSOp(0)	B35	GND	B56	GND	B77	GND
B15	HSOn(0)	B36	GND	B57	GND	B78	HSOp(15)
B16	GND	B37	HSOp(5)	B58	HSOp(10)	B79	HSOn(15)
B17	PRSNT#2	B38	HSOn(5)	B59	HSOn(10)	B80	GND
B18	GND	B39	GND	B60	GND	B81	PRSNT#2
B19	HSOp(1)	B40	GND	B61	GND	B82	RSVD#2
B20	HSOn(1)	B41	HSOp(6)	B62	HSOp(11)		
B21	GND	B42	HSOn(6)	B63	HSOn(11)		

**Table 3-15: PCIe x16 Side B Pinouts**

### 3.2.13 PCI Slots

- CN Label:** PCI1, PCI2 and PCI3
- CN Type:** PCI Slot
- CN Location:** See **Figure 3-14**
- CN Pinouts:** See **Table 3-16**

The PCI slot enables a PCI expansion module to be connected to the board.

IMBA-XQ354S Motherboard




Figure 3-14: PCI Slot Location

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
A1	TRST	B1	-12 V
A2	+12 V	B2	TCK
A3	TMS	B3	GND
A4	TDI	B4	TDO
A5	+5 V	B5	+5 V
A6	INTA	B6	+5 V
A7	INTC	B7	INTB
A8	+5 V	B8	INTD
A9	RESERVED3	B9	PRSENT1
A10	+5 V	B10	RESERVED1
A11	RESERVED4	B11	PRSENT2
A12	GND	B12	GND
A13	GND	B13	GND
A14	3.3 V_AUX	B14	RESERVED2

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
A15	RST	B15	GND
A16	+5 V	B16	CLK
A17	GNT	B17	GND
A18	GND	B18	REQ
A19	PME	B19	+5 V
A20	AD30	B20	AD31
A21	+3.3 V	B21	AD29
A22	AD28	B22	GND
A23	AD26	B23	AD27
A24	GND	B24	AD25
A25	AD24	B25	+3.3 V
A26	IDSEL	B26	C/BE3
A27	+3.3 V	B27	AD23
A28	AD22	B28	GND
A29	AD20	B29	AD21
A30	GND	B30	AD19
A31	AD18	B31	+3.3 V
A32	AD16	B32	AD17
A33	+3.3 V	B33	C/BE2
A34	FRAME	B34	GND
A35	GND	B35	IRDY
A36	TRDY	B36	+3.3 V
A37	GND	B37	DEVSEL
A38	STOP	B38	GND
A39	+3.3 V	B39	LOCK
A40	SDONE	B40	PERR
A41	SBO	B41	+3.3 V
A42	GND	B42	SERR
A43	PAR	B43	+3.3 V
A44	AD15	B44	C/BE1
A45	+3.3 V	B45	AD14

## IMBA-XQ354S Motherboard

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
A46	AD13	B46	GND
A47	AD11	B47	AD12
A48	GND	B48	AD10
A49	AD9	B49	GND
A52	C/BE0	B52	AD8
A53	+3.3 V	B53	AD7
A54	AD6	B54	+3.3 V
A55	AD4	B55	AD5
A56	GND	B56	AD3
A57	AD2	B57	GND
A68	AD0	B68	AD1
A59	+5 V	B59	+5 V
A60	REQ64	B60	ACK64
A61	+5 V	B61	+5 V
A62	+5 V	B62	+5 V

**Table 3-16: PCI Slot**

### 3.2.14 SATA Drive Connectors

**CN Label:** SATA1, SATA2, SATA3, SATA4, SATA5 and SATA6


**CN Type:** SATA drive connectors

**CN Location:** See **Figure 3-15**

**CN Pinouts:** See **Table 3-17**

The six SATA drive connectors are each connected to a SATA drive. SATA drives transfer data at speeds as high as 3Gb/s. The SATA drives can be configured in a RAID configuration.





**Figure 3-15: SATA Drive Connector Locations**

PIN NO.	DESCRIPTION
1	GND
2	TX+
3	TX-
4	GND
5	RX-
6	RX+
7	GND

**Table 3-17: SATA Drive Connector Pinouts**

### 3.2.15 SPDIF Connector

- CN Label:** SPDIF1
- CN Type:** 5-pin header
- CN Location:** See **Figure 3-16**
- CN Pinouts:** See **Table 3-18**

Use the SPDIF connector to connect digital audio devices to the system.

IMBA-XQ354S Motherboard




Figure 3-16: SPDIF Connector Pinout Locations

PIN	DESCRIPTION
1	5 V audio
2	NC
3	SPDIF out
4	GND audio
5	SPDIF in

Table 3-18: SPDIF Connector Pinouts

3.2.16 Serial Port Connectors


**CN Label:** COM2, COM3, COM4, COM5, COM6

**CN Type:** 9-pin box headers

**CN Location:** See Figure 3-17

**CN Pinouts:** See Table 3-19

The 10-pin serial port connectors provide a RS-232 serial communications channels. The serial port connectors can be connected to external RS-232 serial port devices.



**Figure 3-17: Serial Port Connectors Pinout Locations**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	Data Carrier Detect (DCD)	2	Receive Data (RXD)
3	Transmit Data (TXD)	4	Data Terminal Ready (DTR)
5	Ground (GND)	6	Data Set to Ready (DSR)
7	Request to Send (RTS)	8	Clear to Sent (CTS)
9	Ring Indicator (RI)	10	N/C


**Table 3-19: Serial Port Connector Pinouts**

### 3.2.17 SPI Flash Connector

- CN Label:** JSPI1
- CN Type:** 8-pin header
- CN Location:** See **Figure 3-18**
- CN Pinouts:** See **Table 3-20**

The SPI connector is for flashing the SPI BIOS.

**IMBA-XQ354S Motherboard**



**Figure 3-18: SPI Flash Connector Pinouts**


PIN	DESCRIPTION	PIN	DESCRIPTION
1	VCC	2	GND
3	CS#	4	CLOCK
5	SO	6	SI
7	NC	8	NC

**Table 3-20: SPI Flash Connector**

**3.2.18 Trusted Platform Module (TPM) Connector**

- CN Label:** TPM1
- CN Type:** 20-pin header
- CN Location:** See **Figure 3-19**
- CN Pinouts:** See **Table 3-21**

The Trusted Platform Module (TPM) connector secures the system on boot.



**Figure 3-19: TPM Connector Pinout Locations**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	LCLK	2	GND2
3	LFRAME#	4	KEY
5	LRESET#	6	+5 V
7	LAD3	8	LAD2
9	+3 V	10	LAD1
11	LAD0	12	GND3
13	SCL	14	SDA
15	SB3 V	16	SERIRQ
17	GND1	18	GLKRUN#
19	LPCPD#	20	LDRQ#

**Table 3-21: TPM Connector Pinouts**

### 3.2.19 USB Connectors

**CN Label:** USB45, USB67, USB89 and USB1011

**CN Type:** 8-pin header

**CN Location:** See **Figure 3-20**

**CN Pinouts:** See **Table 3-22**



## IMBA-XQ354S Motherboard

The 10-pin USB connector each provides connectivity to two USB 1.1 or two USB 2.0 ports. Each USB connector can support two USB devices. Additional external USB ports are found on the rear panel. The USB ports are used for I/O bus expansion.





Figure 3-20: USB Connector Pinout Locations

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	VCC	2	GND
3	DATA-	4	DATA+
5	DATA+	6	DATA-
7	GND	8	VCC

Table 3-22: USB Port Connector Pinouts

### 3.3 External Interface Connectors

Figure 3-21 shows the IMBA-XQ354S motherboard external interface connectors. The IMBA-XQ354S on-board external interface connectors are shown in Figure 3-21:



**Figure 3-21: IMBA-XQ354S External Interface Connectors**

### 3.3.1 Audio Connector

<b>CN Label:</b>	<b>AUDIO1</b>
<b>CN Type:</b>	Audio jacks
<b>CN Location:</b>	See <b>Figure 3-21</b>

The six audio jacks on the external audio connector enable the IMBA-XQ354S to be connected to external audio devices as specified below.

- **CEN/LFE Out (Orange):** Connects to the center speaker and sub-woofer.
- **Surround Out (Black):** Connects to a speaker on the left and right.
- **Side Out (Gray):** Connects to side speakers.
- **Line In port (Light Blue):** Connects a CD-ROM, DVD player, or other audio devices.
- **Line Out port (Lime):** Connects to a headphone or a speaker. With multi-channel configurations, this port connect to front speakers.
- **Microphone (Pink):** Connects a microphone.

**IMBA-XQ354S Motherboard**



**Figure 3-22: Audio Connector**


**3.3.2 Ethernet Connector**

- CN Label:** LAN1
- CN Type:** RJ-45
- CN Location:** See **Figure 3-21**
- CN Pinouts:** See **Table 3-23**

A 10/100/1000 Mb/s connection can be made to a Local Area Network.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	TX+	5	N/C
2	N/C	6	RX-
3	TX-	7	N/C
4	RX+	8	N/C

**Table 3-23: Ethernet Connector Pinouts**



**Figure 3-23: Ethernet Connector**

The RJ-45 Ethernet connector has two status LEDs, one green and one yellow. The green LED indicates activity on the port and the yellow LED indicates the port is linked.


SPEED LED		LINK LED	
Status	Description	Status	Description
GREEN	ON: 100 MB OFF: 10 MB	YELLOW	ON: Linked Flashing: Activity

**Table 3-24: Connector LEDs**

### 3.3.3 Keyboard and Mouse Connector

- CN Label:** KB\_MS1
- CN Type:** PS/2
- CN Location:** See **Figure 3-21**
- CN Pinouts:** See **Table 3-25** and **Figure 3-24**

The IMBA-XQ354S has two PS/2 connectors on the mounting bracket for easy connection to a PS/2 keyboard and PS/2 mouse.



**Figure 3-24: PS/2 Connector**

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	KEYBOARD DATA	7	MOUSE DATA
2	NC	8	NC

## IMBA-XQ354S Motherboard

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
3	GND	9	GND
4	+5 V	10	+5 V
5	KEYBOARD CLOCK	11	MOUSE DATA
6	NC	12	NC

**Table 3-25: PS/2 Connectors**

### 3.3.4 Parallel Port Connector


- CN Label:** LPT
- CN Type:** 26-pin box header
- CN Location:** See **Figure 3-21**
- CN Pinouts:** See **Table 3-26**

The 26-pin parallel port connector connects to a parallel port connector interface or some other parallel port device such as a printer.

PIN NO.	DESCRIPTION	PIN NO.	DESCRIPTION
1	STROBE#	14	AUTO FORM FEED #
2	DATA 0	15	ERROR#
3	DATA 1	16	INITIALIZE
4	DATA 2	17	PRINTER SELECT LN#
5	DATA 3	18	GROUND
6	DATA 4	19	GROUND
7	DATA 5	20	GROUND
8	DATA 6	21	GROUND
9	DATA 7	22	GROUND
10	ACKNOWLEDGE	23	GROUND
11	BUSY	24	GROUND
12	PAPER EMPTY	25	GROUND
13	PRINTER SELECT		

**Table 3-26: Parallel Port Connector Pinouts**





**Figure 3-25: Parallel Port Connector Location**


### 3.3.5 Serial Port Connector

- CN Label:** COM1
- CN Type:** D-sub 9 connector
- CN Location:** See **Figure 3-21**
- CN Pinouts:** See **Table 3-27** and **Figure 3-26**

The RS-232 serial connector provides serial connection in the RS-232 mode.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	DCD#	6	DSR#
2	RxD	7	RTS#
3	TxD	8	CTS#
4	DTR#	9	RI#
5	GND		

**Table 3-27: Serial Port Pinouts**



**Figure 3-26: Serial Port Pinout Locations**

## IMBA-XQ354S Motherboard

### 3.3.6 USB Ports

**CN Label:** USB01 and USB23

**CN Type:** USB Combo ports

**CN Location:** See **Figure 3-21**

**CN Pinouts:** See **Table 3-28**

The USB combo port and LAN/USB combo port provides connectivity to five additional USB devices. USB devices connect directly to the USB connectors on the rear panel.

PIN	DESCRIPTION	PIN	DESCRIPTION
1	+5 V	5	+5 V
2	D3-	6	D4-
3	D3+	7	D4+
4	GND	8	GND

**Table 3-28: USB Connector Pinouts**

### 3.3.7 VGA Connector

**CN Label:** VGA

**CN Type:** D-sub 15-pin female connector


**CN Location:** See **Figure 3-21**

**CN Pinouts:** See **Figure 3-27** and **Table 3-29**

The standard 15-pin female VGA connector connects to a CRT or LCD monitor.

PIN	DESCRIPTION	PIN	DESCRIPTION	PIN	DESCRIPTION
1	RED	6	GROUND	11	NC
2	GREEN	7	GROUND	12	SDA
3	BLUE	8	GROUND	13	HSYNC
4	NC	9	NC	14	VSYNC
5	GROUND	10	GROUND	15	SCL

**Table 3-29: VGA Connector Pinouts**



**Figure 3-27: VGA Connector**

Chapter

4

# Installation

---

## 4.1 Anti-static Precautions

---



### WARNING:

Failure to take ESD precautions during the installation of the IMBA-XQ354S may result in permanent damage to IMBA-XQ354S and severe injury to the user.

---

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the IMBA-XQ354S. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the IMBA-XQ354S, or any other electrical component is handled, the following anti-static precautions are strictly adhered to.

- ***Wear an anti-static wristband:*** - Wearing a simple anti-static wristband can help to prevent ESD from damaging the board.
- ***Self-grounding:***- Before handling the board touch any grounded conducting material. During the time the board is handled, frequently touch any conducting materials that are connected to the ground.
- ***Use an anti-static pad:*** When configuring the IMBA-XQ354S, place it on an anti-static pad. This reduces the possibility of ESD damaging the IMBA-XQ354S.
- ***Only handle the edges of the PCB:-:*** When handling the PCB, hold the PCB by the edges.



## 4.2 Installation Considerations

---



### NOTE:

The following installation notices and installation considerations should be read and understood before the IMBA-XQ354S is installed. All installation notices pertaining to the installation of IMBA-XQ354S should be strictly adhered to. Failing to adhere to these precautions may lead to severe damage of the IMBA-XQ354S and injury to the person installing the motherboard.

---

### 4.2.1 Installation Notices

---



### WARNING:

The installation instructions described in this manual should be carefully followed in order to prevent damage to the IMBA-XQ354S, IMBA-XQ354S components and injury to the user.

---

Before and during the installation please **DO** the following:

- **Read the user manual:**
  - The user manual provides a complete description of the IMBA-XQ354S installation instructions and configuration options.
- **Wear an electrostatic discharge cuff (ESD):**
  - Electronic components are easily damaged by ESD. Wearing an ESD cuff removes ESD from the body and helps prevent ESD damage.
- **Place the IMBA-XQ354S on an antistatic pad:**
  - When installing or configuring the motherboard, place it on an antistatic pad. This helps to prevent potential ESD damage.
- **Turn all power to the IMBA-XQ354S off:**
  - When working with the IMBA-XQ354S, make sure that it is disconnected from all power supplies and that no electricity is being fed into the system.

Before and during the installation of the IMBA-XQ354S **DO NOT:**

- Remove any of the stickers on the PCB board. These stickers are required for warranty validation.
- Use the product before verifying all the cables and power connectors are properly connected.
- Allow screws to come in contact with the PCB circuit, connector pins, or its components.

#### 4.2.2 Installation Checklist

The following checklist is provided to ensure the IMBA-XQ354S is properly installed.

- All the items in the packing list are present
- A compatible memory module is properly inserted into the slot
- The jumpers have been properly configured
- The IMBA-XQ354S is inserted into a chassis with adequate ventilation
- The correct power supply is being used
- The following devices are properly connected
  - RS-232 cables
  - USB cables
  - FDD cables
  - Power cables
- The following external peripheral devices are properly connected to the chassis:
  - VGA screen
  - Keyboard
  - Mouse
  - RS-232 serial communications device

### 4.3 CPU, CPU Cooling Kit and DIMM Installation

---

**WARNING:**

A CPU should never be turned on without the specified cooling kit being installed. If the cooling kit (heat sink and fan) is not properly installed and the system turned on, permanent damage to the CPU, IMBA-XQ354S and other electronic components attached to the system may be incurred. Running a CPU without a cooling kit may also result in injury to the user.

---

The CPU, CPU cooling kit and DIMM are the most critical components of the IMBA-XQ354S. If one of these component is not installed the IMBA-XQ354S cannot run.

#### 4.3.1 Socket LGA775 CPU Installation

---

**NOTE:**

To enable Hyper-Threading Technology, the CPU, chipset and operating system must all support Hyper-Threading Technology.


---

**WARNING:**

CPUs are expensive and sensitive components. When installing the CPU please be careful not to damage it in anyway. Make sure the CPU is installed properly and ensure the correct cooling kit is properly installed.

---

The LGA775 socket is shown in **Figure 4-1**.



**Figure 4-1: Intel LGA775 Socket**


To install a socket LGA775 CPU onto the IMBA-XQ354S, follow the steps below:



**WARNING:**

When handling the CPU, only hold it on the sides. DO NOT touch the pins at the bottom of the CPU.

**Step 1: Remove the protective cover.** Remove the black protective cover by prying it off the load plate. To remove the protective cover, locate the “REMOVE” sign and use your fingernail to pry the protective cover off. See **Figure 4-2**.




**Figure 4-2: Remove the CPU Socket Protective Shield**

**Step 2: Open the socket.** Disengage the load lever by pressing the lever down and slightly outward to clear the retention tab. Rotate the load lever to a fully open

## IMBA-XQ354S Motherboard

position. Then rotate the load plate towards the opposite direction.


See **Figure 4-3**.



**Figure 4-3: Open the CPU Socket Load Plate**

- Step 3: Inspect the CPU socket** Make sure there are no bent pins and make sure the socket contacts are free of foreign material. If any debris is found, remove it with compressed air.
  - Step 4: Orientate the CPU properly.** Make sure the IHS (Integrated Heat Sink) side is facing upward.
  - Step 5: Correctly position the CPU.** Match the Pin 1 mark with the cut edge on the CPU socket.
  - Step 6: Align the CPU pins.** Locate pin 1 and the two orientation notches on the CPU. Carefully match the two orientation notches on the CPU with the socket alignment keys.
  - Step 7: Insert the CPU.** Gently insert the CPU into the socket. If the CPU pins are properly aligned, the CPU should slide into the CPU socket smoothly.
- See **Figure 4-4**.





**Figure 4-4: Insert the Socket LGA775 CPU**

- Step 8: Close the CPU socket.** Close the load plate and engage the load lever by pushing it back to its original position. Secure the load lever under the retention tab on the side of CPU socket.
- Step 9: Connect the CPU 12 V cable to the 12** After the cooling kit is installed connect the CPU cable to the CPU 12 V power connector.

#### 4.3.2 Socket LGA775 CF-520 Cooling Kit Installation



**WARNING:**

It is strongly recommended that you **DO NOT** use the original heat sink and cooler provided by Intel on the IMBA-XQ354S.

The cooling kit includes a support bracket that is combined with the heat sink mounted on the CPU to counterweigh and balance the load on both sides of the PCB.

## IMBA-XQ354S Motherboard



**Figure 4-5: Cooling Kit**

A Socket LGA775 CPU cooling kit shown in **Figure 4-5** can be purchased separately. The cooling kit comprises a CPU heat sink and a cooling fan.




### **WARNING:**

Do not wipe off (accidentally or otherwise) the pre-sprayed layer of thermal paste on the bottom of the heat sink. The thermal paste between the CPU and the heat sink is important for optimum heat dissipation.

To install the cooling kit follow the instructions below.

- Step 1:** Place the cooling kit onto the socket LGA775 CPU. Make sure the CPU cable can be properly routed when the cooling kit is installed.
- Step 2:** Properly align the cooling kit. Make sure the four spring screw fasteners can pass through the pre-drilled holes on the PCB.
- Step 3:** Mount the cooling kit. Gently place the cooling kit on top of the CPU. Make sure the four threaded screws on the corners of the cooling kit properly pass through the predrilled holes on the bottom of the PCB.
- Step 4:** Secure the cooling kit. From the solder side of the PCB, align the support bracket to the screw threads on heat sink that were inserted through the PCB holes. (See **Figure 4-6**)



**Figure 4-6: Securing the Heat sink to the PCB Board**

- Step 5: Tighten the screws.** Use a screwdriver to tighten the four screws. Tighten each nut a few turns at a time and do not over-tighten the screws.
- Step 6: Connect the fan cable.** Connect the cooling kit fan cable to the fan connector on the IMBA-XQ354S. Carefully route the cable and avoid heat generating chips and fan blades.

### 4.3.3 DIMM Installation




**WARNING:**

Using incorrectly specified memory modules may cause permanent damage to the IMBA-XQ354S. Please make sure the memory modules comply with the recommended memory specifications.

To install a DIMM, please follow the steps below and refer to **Figure 4-7**.

## IMBA-XQ354S Motherboard



**Figure 4-7: Installing a DIMM**


- Step 1: Open the DIMM socket handles.** The DIMM socket has two handles that secure the DIMM into the socket. Before the DIMM can be inserted into the socket, the handles must be opened. See **Figure 4-7**.
- Step 2: Align the DIMM with the socket.** The DIMM must be oriented in such a way that the notch in the middle of the DIMM must be aligned with the plastic bridge in the socket. See **Figure 4-7**.
- Step 3: Insert the DIMM.** Once properly aligned, the DIMM can be inserted into the socket. As the DIMM is inserted, the white handles on the side of the socket will close automatically and secure the DIMM to the socket. See **Figure 4-7**.
- Step 4: Removing a DIMM.** To remove a DIMM, push both handles outward. The memory module is ejected by a mechanism in the socket.

### 4.4 Jumper Settings



**NOTE:**

A jumper is a metal bridge that is used to close an electrical circuit. It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To CLOSE/SHORT a jumper means connecting the pins of the jumper with the plastic clip and to OPEN a jumper means removing the plastic clip from a jumper.



Before the IMBA-XQ354S is installed in the system, the jumpers must be set in accordance with the desired configuration. The jumpers on the IMBA-XQ354S are listed in **Table 4-1**.

Description	Label	Type
Clear CMOS	J_CMOS1	3-pin header
COM3 Pin 9 setting	J_COM_F3	3-pin header
COM4 Pin 9 setting	J_COM_F4	3-pin header
COM5 Pin 9 setting	J_COM_F5	3-pin header
COM6 Pin 9 setting	J_COM_F6	3-pin header
COM3 Pin 9 voltage setting	J_COM_V3	3-pin header
COM4 Pin 9 voltage setting	J_COM_V4	3-pin header
COM5 Pin 9 voltage setting	J_COM_V5	3-pin header
COM6 Pin 9 voltage setting	J_COM_V6	3-pin header
SPDIF out selection	SPDIF_OUT	3-pin header

**Table 4-1: Jumpers**



## IMBA-XQ354S Motherboard

### 4.4.1 Clear CMOS Jumper

<b>Jumper Label:</b>	<b>J_CMOS1</b>
<b>Jumper Type:</b>	3-pin header
<b>Jumper Settings:</b>	See <b>Table 4-2</b>
<b>Jumper Location:</b>	See <b>Figure 4-8</b>

If the IMBA-XQ354S fails to boot due to improper BIOS settings, the clear CMOS jumper clears the CMOS data and resets the system BIOS information. To do this, use the jumper cap to close pins 2 and 3 for a few seconds then reinstall the jumper clip back to pins 1 and 2.

If the “CMOS Settings Wrong” message is displayed during the boot up process, the fault may be corrected by pressing the F1 to enter the CMOS Setup menu. Do one of the following:

- Enter the correct CMOS setting
- Load Optimal Defaults
- Load Failsafe Defaults.


After having done one of the above, save the changes and exit the CMOS Setup menu.

The clear CMOS jumper settings are shown in **Table 4-2**.

AT Power Select	Description	
Short 1 - 2	Keep CMOS Setup	Default
Short 2 - 3	Clear CMOS Setup	

**Table 4-2: Clear CMOS Jumper Settings**

The location of the clear CMOS jumper is shown in **Figure 4-8** below.



**Figure 4-8: Clear CMOS Jumper**

#### 4.4.2 COM Port Pin 9 Function Select

- Jumper Label:** J\_COM\_F3, J\_COM\_F4, J\_COM\_F5 and J\_COM\_F6
- Jumper Type:** 3-pin header
- Jumper Settings:** See Table 4-3
- Jumper Location:** See Figure 4-9



**NOTE:**

If the Pin 9 function is selected as voltage output, the voltage must be specified as either +5 V or as +12 V. To do this please refer to the following section.

The COM Port Pin 9 Function Select jumpers configure pin 9 on the COM3, COM4, COM5 and COM6 connectors. Pin 9 on COM3, COM4, COM5 and COM6 can be set as either a ring (RI) signal or as a power source. The COM Port Pin 9 Function Select jumper selections options are shown in **Table 4-3**.


COM Port	Jumper	Pin 9 Voltage Input	Pin 9 RI Function
COM3	J_COM_F3	Short 1-2	Short 2-3
COM4	J_COM_F4	Short 1-2	Short 2-3
COM5	J_COM_F5	Short 1-2	Short 2-3

## IMBA-XQ354S Motherboard

COM Port	Jumper	Pin 9 Voltage Input	Pin 9 RI Function
COM6	J_COM_F6	Short 1-2	Short 2-3

**Table 4-3: COM Port Pin 9 Function Select Jumper Settings**

The COM Port Pin 9 Function Select jumper location is shown in **Figure 4-9** below.



**Figure 4-9: COM Port Pin 9 Function Select Jumper Location**

### 4.4.3 COM Port Pin 9 Voltage Setting Select

<b>Jumper Label:</b>	J_COM_V3, J_COM_V4, J_COM_V5 and J_COM_V6
<b>Jumper Type:</b>	3-pin header
<b>Jumper Settings:</b>	See Table 4-4
<b>Jumper Location:</b>	See Figure 4-10



**NOTE:**


To specify pin 9 on the COM ports as either 5 V or 12 V output, pin 9 on the respective jumper must be set to the voltage function and not the RI function. Please see the previous section.

The COM Port Pin 9 Voltage Setting Select jumpers configure the voltage output provided by pin 9 on the COM3, COM4, COM5 and COM6 connectors. Pin 9 on COM3, COM4, COM5 and COM6 can provide 5 V or 12 V of power to an external device. The COM Port Pin 9 Voltage Setting Select jumper selections options are shown in **Table 4-4**.

COM Port	Jumper	Pin 9 +5 V	Pin 9 +12 V
COM3	J_COM_V3	Short 1-2	Short 2-3
COM4	J_COM_V4	Short 1-2	Short 2-3
COM5	J_COM_V5	Short 1-2	Short 2-3
COM6	J_COM_V6	Short 1-2	Short 2-3

**Table 4-4: COM Port Pin 9 Voltage Setting Select Jumper Settings**

The COM Port Pin 9 Voltage Setting Select jumper location is shown in **Figure 4-10** below.



**Figure 4-10: COM Port Pin 9 Voltage Setting Select Jumper Location**

#### 4.4.4 SPDIF Out Selection

- Jumper Label:** JP1
- Jumper Type:** 3-pin header
- Jumper Settings:** See Table 4-5


## IMBA-XQ354S Motherboard

**Jumper Location:** See **Figure 4-11**

The SPDIF Out Selection jumper specifies the type of connection made to the SPDIF connector. The SPDIF1 port can provide digital audio to external speakers or compressed AC3 data to an external Dolby Digital Decoder via a coaxial cable. The SPDIF Out Selection jumper specifies the connection type. Jumper settings are shown in **Table 4-5** and the jumper location is shown in **Figure 4-11**.

SPDIF_OUT	Description	
1-2	RCA connector	Default
2-3	Optical connector	

**Table 4-5: SPDIF Out Selection Jumper Settings**



**Figure 4-11: SPDIF Out Selection Jumper Pinout Location**



## 4.5 Chassis Installation

### 4.5.1 Airflow



#### **WARNING:**

Airflow is critical to the cooling of the CPU and other onboard components. The chassis in which the IMBA-XQ354S must have air vents to allow cool air to move into the system and hot air to move out.

---

The IMBA-XQ354S must be installed in a chassis with ventilation holes on the sides allowing airflow to travel through the heat sink surface. In a system with an individual power supply unit, the cooling fan of a power supply can also help generate airflow through the board surface.

### 4.5.2 IMBA-XQ354S Installation

To install the IMBA-XQ354S motherboard into the chassis please refer to the reference material that came with the chassis.


### 4.5.3 Dual RS-232 Cable with Slot Bracket

The dual RS-232 cable slot connector consists of two connectors attached to two independent cables. Each cable is then attached to a D-sub 9 male connector that is mounted onto a slot. To install the dual RS-232 cable, please follow the steps below.

**Step 1: Locate the connectors.** The locations of the RS-232 connectors are shown in **Chapter 3**.

**Step 2: Insert the cable connectors.** Insert one connector into each serial port box headers. See **Figure 4-12**. A key on the front of the cable connectors ensures the connector can only be installed in one direction.

## IMBA-XQ354S Motherboard



**Figure 4-12: Dual RS-232 Cable Installation**


**Step 3: Secure the bracket.** The dual RS-232 connector has two D-sub 9 male connectors secured on a bracket. To secure the bracket to the chassis please refer to the reference material that came with the chassis

#### 4.5.4 Single RS-232 Cable with Slot Bracket

The single RS-232 cable consists of one serial port connectors attached to a serial communications cable that is then attached to a D-sub 9 male connector that is mounted onto a bracket. To install the single RS-232 cable, please follow the steps below.

**Step 1: Locate the connector.** The location of the RS-232 connector is shown in Chapter 3.

**Step 2: Insert the cable connector.** Insert the connector into the serial port box header. See **Figure 4-13**. A key on the front of the cable connectors ensures the connector can only be installed in one direction.



**Figure 4-13: Single RS-232 Cable Installation**

**Step 3: Secure the bracket.** The single RS-232 connector has one D-sub 9 male connector secured to a bracket. To secure the bracket to the chassis please refer to the reference material that came with the chassis


#### **4.5.5 SATA Drive Connection (Two Cables)**

The IMBA-XQ354S is shipped with six SATA drive cables. To connect the SATA drives to the connectors, please follow the steps below.

**Step 1: Locate the connectors.** The locations of the SATA drive connectors are shown in **Chapter 3**.


**Step 2: Insert the cable connector.** Insert the cable connector into the on-board SATA drive connector until it clips into place. See Figure 4-14.

## IMBA-XQ354S Motherboard



**Figure 4-14: SATA Drive Cable Connection**

- Step 3:** Connect the cable to the SATA disk. Connect the connector on the other end of the cable to the connector at the back of the SATA drive. See Figure 4-15.
- Step 4:** Connect the SATA power cable. Connect the SATA power connector to the back of the SATA drive. See Figure 4-15.



**Figure 4-15: SATA Power Drive Connection**

## 4.6 External Peripheral Interface Connection

The following external peripheral devices can be connected to the external peripheral interface connectors.

- Keyboard and mouse connectors
- Serial port devices
- VGA screens
- Parallel port devices
- Ethernet connection
- USB devices
- Audio jacks

To install these devices, connect the corresponding cable connector from the actual device to the corresponding IMBA-XQ354S external peripheral interface connector making sure the pins are properly aligned.




## IMBA-XQ354S Motherboard

### 4.6.1 Keyboard and Mouse

The IMBA-XQ354S has a dual PS/2 connector on the external peripheral interface panel. The dual PS/2 connector is used to connect to a keyboard and mouse to the system. Follow the steps below to connect a keyboard and mouse to the IMBA-XQ354S.

**Step 1:** **Locate the dual PS/2 connector.** The location of the dual PS/2 connector is shown in **Chapter 3**.

**Step 2:** **Insert the keyboard/mouse connector.** Insert a PS/2 keyboard or mouse connector into the appropriate PS/2 connector on the external peripheral interface connector. See **Figure 4-16**.




**Figure 4-16: PS/2 Keyboard/Mouse Connector**

### 4.6.2 LAN

There is one external RJ-45 LAN connector. The RJ-45 connector enables connection to an external network. To connect a LAN cable with an RJ-45 connector, please follow the instructions below.

**Step 1:** Locate the RJ-45 connector. The location of the USB connector is shown in Chapter 3.

**Step 2:** Align the connectors. Align the RJ-45 connector on the LAN cable with the RJ-45 connector on the IMBA-XQ354S. See **Figure 4-17**.



**Figure 4-17: LAN Connection**

**Step 3:** Insert the LAN cable RJ-45 connector. Once aligned, gently insert the LAN cable RJ-45 connector into the on-board RJ-45 connector.

### 4.6.3 Parallel Device Connection

The IMBA-XQ354S has a single female D-sub 25 connector on the external peripheral interface panel for parallel devices. Follow the steps below to connect a parallel device to the IMBA-XQ354S.

**Step 1:** Locate the D-sub 25 connector. The location of the D-sub 25 connector is shown in Chapter 3.

**Step 2:** Insert the D-sub 25 connector. Insert the D-sub 25 connector of a parallel device into the D-sub 25 connector on the external peripheral interface. See **Figure 4-18**.

## IMBA-XQ354S Motherboard




Figure 4-18: Parallel Device Connector


**Step 3:** **Secure the connector.** Secure the D-sub 25 connector to the external interface by tightening the two retention screws on either side of the connector.

#### 4.6.4 Serial Device

The IMBA-XQ354S has a single male D-sub 9 connector on the external peripheral interface panel for a serial device. Follow the steps below to connect a serial device to the IMBA-XQ354S.

**Step 1:** **Locate the D-sub 9 connector.** The location of the D-sub 9 connector is shown in **Chapter 3**.

**Step 2:** **Insert the serial connector.** Insert the D-sub 9 connector of a serial device into the D-sub 9 connector on the external peripheral interface. See **Figure 4-19**.



**Figure 4-19: Serial Device Connector**

**Step 3:** **Secure the connector.** Secure the serial device connector to the external interface by tightening the two retention screws on either side of the connector.

#### **4.6.5 USB**

The external USB Series "A" receptacle connectors provide easier and quicker access to external USB devices. Follow the steps below to connect USB devices to the IMBA-XQ354S.

**Step 1:** **Locate the USB Series "A" receptacle connectors.** The location of the USB Series "A" receptacle connectors are shown in **Chapter 3**.

**Step 2:** **Insert a USB Series "A" plug.** Insert the USB Series "A" plug of a device into the USB Series "A" receptacle on the external peripheral interface. See **Figure 4-20**.



## IMBA-XQ354S Motherboard




Figure 4-20: USB Connector

### 4.6.6 VGA Monitor

The IMBA-XQ354S has a single female D-sub 15 connector on the external peripheral interface panel. The D-sub 15 connector is connected to a CRT or VGA monitor. To connect a monitor to the IMBA-XQ354S, please follow the instructions below.

- Step 1:** **Locate the female D-sub 15 connector.** The location of the female D-sub 15 connector is shown in **Chapter 3**.
- Step 2:** **Align the VGA connector.** Align the male D-sub 15 connector on the VGA screen cable with the female D-sub 15 connector on the external peripheral interface.
- Step 3:** **Insert the VGA connector.** Once the connectors are properly aligned with the insert the male connector from the VGA screen into the female connector on the IMBA-XQ354S. See **Figure 4-21**.






Figure 4-21: VGA Connector

**Step 4: Secure the connector.** Secure the D-sub 15 VGA connector from the VGA monitor to the external interface by tightening the two retention screws on either side of the connector.

#### 4.6.7 Audio Connector

The six audio jacks on the external audio connector enable the IMBA-XQ354S to be connected to a 7.1 channel surround sound setup. To install the audio devices, follow the steps below.

**Step 1: Identify the audio plugs.** The plugs on your home theater system or speakers may not match the colors on the rear panel. If audio plugs are plugged into the wrong jacks, sound quality will be very bad.

**Step 2: Plug the audio plugs into the audio jacks.** Plug the audio plugs into the audio jacks. If the plugs on your speakers are different, an adapter will need to be used to plug them into the audio jacks.

- **CEN/LFE Out (Orange):** Connects to the center speaker and sub-woofer.
- **Surround Out (Black):** Connects to a speaker on the left and right.

## IMBA-XQ354S Motherboard

- **Side Out (Gray):** Connects to side speakers.
- **Line In port (Light Blue):** Connects a CD-ROM, DVD player, or other audio devices.
- **Line Out port (Lime):** Connects to a headphone or a speaker. With multi-channel configurations, this port connect to front speakers.
- **Microphone (Pink):** Connects a microphone.




Figure 4-22: Audio Connector

**Step 3: Check audio clarity.** Check that the sound is coming through the right speakers by adjusting the balance front to rear and left to right.

Chapter

**5**

# BIOS Setup

---

## IMBA-XQ354S Motherboard

### 5.1 Introduction

A licensed copy of AMI BIOS is preprogrammed into the ROM BIOS. The BIOS setup program allows users to modify the basic system configuration. This chapter describes how to access the BIOS setup program and the configuration options that may be changed.



#### NOTE:

Some of the BIOS options may vary throughout the life cycle of the product and are subject to change without prior notice.

---

#### 5.1.1 Starting Setup

The AMI BIOS is activated when the computer is turned on. The setup program can be activated in one of two ways.

1. Press the **DELETE** key as soon as the system is turned on or
2. Press the **DELETE** key when the “**Press Del to enter SETUP**” message appears on the screen.

If the message disappears before the **DELETE** key is pressed, restart the computer and try again.

#### 5.1.2 Using Setup

Use the arrow keys to highlight items, press **ENTER** to select, use the PageUp and PageDown keys to change entries, press **F1** for help and press **ESC** to quit. Navigation keys are shown in.

Key	Function
Up arrow	Move to previous item
Down arrow	Move to next item

Key	Function
Left arrow	Move to the item on the left hand side
Right arrow	Move to the item on the right hand side
Esc key	Main Menu – Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
Page Up key	Increase the numeric value or make changes
Page Dn key	Decrease the numeric value or make changes
F1 key	General help, only for Status Page Setup Menu and Option Page Setup Menu
F2 /F3 key	Change color from total 16 colors. F2 to select color forward.
F10 key	Save all the CMOS changes, only for Main Menu

**Table 5-1: BIOS Navigation Keys**

### 5.1.3 Getting Help

When **F1** is pressed a small help window describing the appropriate keys to use and the possible selections for the highlighted item appears. To exit the Help Window press **Esc** or the **F1** key again.

### 5.1.4 Unable to Reboot After Configuration Changes

If the computer cannot boot after changes to the system configuration is made, CMOS defaults. Use the jumper described in **Chapter 5**.

### 5.1.5 BIOS Menu Bar

The **menu bar** on top of the BIOS screen has the following main items:

- **Main** Changes the basic system configuration.
- **Advanced** Changes the advanced system settings.
- **PCIPnP** Changes the advanced PCI/PnP Settings
- **Boot** Changes the system boot configuration.



## IMBA-XQ354S Motherboard

- **Security** Sets User and Supervisor Passwords.
- **Chipset** Changes the chipset settings.
- **Power** Changes power management settings.
- **Exit** Selects exit options and loads default settings

The following sections completely describe the configuration options found in the menu items at the top of the BIOS screen and listed above.

### 5.2 Main

The Main BIOS menu (**BIOS Menu 1**) appears when the BIOS Setup program is entered. The Main menu gives an overview of the basic system information.

BIOS SETUP UTILITY	
Main	Advanced    PCI/PnP    Boot    Security    Chipset    Exit
<b>System Overview</b> <hr/> <b>AMIBIOS</b> Version    :08.00.15 Build Date:08/26/08 ID         :E200MR14  <b>Processor</b> Intel Core2 CPU                    6300 @ 1.86GHz Speed        :1866MHz Count        :1  <b>System Memory</b> Size         :2039MB  <b>System Time</b> [14:20:27] <b>System Date</b> [Tue 05/06/2008]	Use [ENTER], [TAB] or [SHIFT-TAB] to select a field.  Use [+] or [-] to configure system Time.  ←→    Select Screen ↑↓    Select Item +-    Change Field Tab   Select Field F1    General Help F10   Save and Exit ESC   Exit
v02.61 (C)Copyright 1985-2006, American Megatrends, Inc.	

#### BIOS Menu 1: Main

##### → System Overview

The **System Overview** lists a brief summary of different system components. The fields in **System Overview** cannot be changed. The items shown in the system overview include:

- **AMI BIOS:** Displays auto-detected BIOS information
  - **Version:** Current BIOS version
  - **Build Date:** Date the current BIOS version was made
  - **ID:** Installed BIOS ID
- **Processor:** Displays auto-detected CPU specifications
  - **Type:** Names the currently installed processor
  - **Speed:** Lists the processor speed
  - **Count:** The number of CPUs on the motherboard
- **System Memory:** Displays the auto-detected system memory.
  - **Size:** Lists memory size

The **System Overview** field also has two user configurable fields:

➔ **System Time [hh:mm:ss]**

Use the **System Time** option to set the system time. Manually enter the hours, minutes and seconds.

➔ **System Date [DAY dd/mm/yyyy]**

Use the **System Date** option to set the system date. Manually enter the day, month and year.

### 5.3 Advanced

Use the **Advanced** menu to configure the CPU and peripheral devices through the following sub-menus:



**WARNING:**


Setting the wrong values in the sections below may cause the system to malfunction. Make sure that the settings made are compatible with the hardware.

---

▪ 5.3.1 CPU Configuration .....	84
▪ 5.3.2 IDE Configuration.....	85
▪ 5.3.3 Floppy Configuration.....	92

## IMBA-XQ354S Motherboard


- 5.3.4 Super IO Configuration ..... 93
- 5.3.5 Hardware Health Configuration..... 96
- 5.3.6 APM Configuration ..... 100
- 5.3.7 AHCI Configuration ..... 103
- 5.3.8 Remote Access Configuration..... 104
- 5.3.9 Trusted Computing..... 107
- 5.3.10 USB Configuration ..... 108



**BIOS Menu 2: Advanced**

### 5.3.1 CPU Configuration

Use the CPU Configuration menu (**BIOS Menu 3**) to view detailed CPU specifications and configure the CPU.



#### BIOS Menu 3: CPU Configuration


The CPU Configuration menu (**BIOS Menu 3**) lists the following CPU details:

- **Manufacturer:** Lists the name of the CPU manufacturer
- **Frequency:** Lists the CPU processing speed
- **FSB Speed:** Lists the FSB speed
- **Cache L1:** Lists the CPU L1 cache size
- **Cache L2:** Lists the CPU L2 cache size
- **Ratio Actual:** Clock speed ratio

## IMBA-XQ354S Motherboard

### 5.3.2 IDE Configuration

Use the **IDE Configuration** menu (**BIOS Menu 4**) to change and/or set the configuration of the IDE devices installed in the system.



#### BIOS Menu 4: IDE Configuration

##### → SATA#n Configuration [Enhanced]

Use the **SATA#n** BIOS option to enable the nth SATA drive port.

- **Enhanced** DEFAULT The nth SATA drive port is activated
- **Disabled** The nth SATA drive port is disabled

##### → Configure SATA#n as [IDE]

Use the **Configure SATA#n as** BIOS option to configure the nth SATA port as an IDE drive, a SATA drive (AHCI mode) or a SATA drive in a RAID configuration.



- **IDE    DEFAULT**    The drive connected to the nth SATA port is configured as an IDE drive
- **RAID**                The SATA drive connected to the nth SATA drive port is specified as a SATA drive that is part of a RAID array
- **AHCI**                The SATA drive connected to the nth SATA drive port is specified as a normal SATA drive.

→ **IDE Master and IDE Slave**

When entering setup, BIOS auto detects the presence of IDE devices. BIOS displays the status of the auto detected IDE devices. The following IDE devices are detected and are shown in the **IDE Configuration** menu:


- Primary IDE Master
- Primary IDE Slave
- Secondary IDE Master
- Secondary IDE Slave
- Third IDE Master
- Fourth IDE Master

The **IDE Configuration** menu (**BIOS Menu 4**) allows changes to the configurations for the IDE devices installed in the system. If an IDE device is detected, and one of the above listed four BIOS configuration options are selected, the IDE configuration options shown in **Section 5.3.2.1** appear.

## IMBA-XQ354S Motherboard

### 5.3.2.1 IDE Master, IDE Slave

Use the **IDE Master** and **IDE Slave** configuration menu to view both primary and secondary IDE device details and configure the IDE devices connected to the system.



#### BIOS Menu 5: IDE Master and IDE Slave Configuration

##### ➔ Auto-Detected Drive Parameters

The “grayed-out” items in the left frame are IDE disk drive parameters automatically detected from the firmware of the selected IDE disk drive. The drive parameters are listed as follows:

- **Device:** Lists the device type (e.g. hard disk, CD-ROM etc.)
- **Type:** Indicates the type of devices a user can manually select
- **Vendor:** Lists the device manufacturer
- **Size:** List the storage capacity of the device.
- **LBA Mode:** Indicates whether the LBA (Logical Block Addressing) is a method of addressing data on a disk drive is supported or not.

- **Block Mode:** Block mode boosts IDE drive performance by increasing the amount of data transferred. Only 512 bytes of data can be transferred per interrupt if block mode is not used. Block mode allows transfers of up to 64 KB per interrupt.
- **PIO Mode:** Indicates the PIO mode of the installed device.
- **Async DMA:** Indicates the highest Asynchronous DMA Mode that is supported.
- **Ultra DMA:** Indicates the highest Synchronous DMA Mode that is supported.
- **S.M.A.R.T.:** Indicates whether or not the Self-Monitoring Analysis and Reporting Technology protocol is supported.
- **32Bit Data Transfer:** Enables 32-bit data transfer.

### → Type [Auto]

Use the **Type** BIOS option select the type of device the AMIBIOS attempts to boot from after the Power-On Self-Test (POST) is complete.

- |   |                            |   |
|---|----------------------------|---|
| → | <b>Not Installed</b>       | BIOS is prevented from searching for an IDE disk drive on the specified channel.  |
| → | <b>Auto</b> <b>DEFAULT</b> | The BIOS auto detects the IDE disk drive type attached to the specified channel. This setting should be used if an IDE hard disk drive is attached to the specified channel.                    |
| → | <b>CD/DVD</b>              | The CD/DVD option specifies that an IDE CD-ROM drive is attached to the specified IDE channel. The BIOS does not attempt to search for other types of IDE disk drives on the specified channel. |
| → | <b>ARMD</b>                | This option specifies an ATAPI Removable Media Device. These include, but are not limited to:<br><br>ZIP<br><br>LS-120  |

## IMBA-XQ354S Motherboard

### → LBA/Large Mode [Auto]

Use the **LBA/Large Mode** option to disable or enable BIOS to auto detects LBA (Logical Block Addressing). LBA is a method of addressing data on a disk drive. In LBA mode, the maximum drive capacity is 137 GB.

- **Disabled** BIOS is prevented from using the LBA mode control on the specified channel.
- **Auto**      **DEFAULT** BIOS auto detects the LBA mode control on the specified channel.

### → Block (Multi Sector Transfer) [Auto]

Use the **Block (Multi Sector Transfer)** to disable or enable BIOS to auto detect if the device supports multi-sector transfers.

- **Disabled** BIOS is prevented from using Multi-Sector Transfer on the specified channel. The data to and from the device occurs one sector at a time.
- **Auto**      **DEFAULT** BIOS auto detects Multi-Sector Transfer support on the drive on the specified channel. If supported the data transfer to and from the device occurs multiple sectors at a time.

### → PIO Mode [Auto]

Use the **PIO Mode** option to select the IDE PIO (Programmable I/O) mode program timing cycles between the IDE drive and the programmable IDE controller. As the PIO mode increases, the cycle time decreases.

- **Auto**      **DEFAULT** BIOS auto detects the PIO mode. Use this value if the IDE disk drive support cannot be determined.
- **0**                      PIO mode 0 selected with a maximum transfer rate of 3.3 MB/s
- **1**                      PIO mode 1 selected with a maximum transfer rate of 5.2 MB/s
- **2**                      PIO mode 2 selected with a maximum transfer rate of 8.3 MB/s

- 3 PIO mode 3 selected with a maximum transfer rate of 11.1 MB/s
- 4 PIO mode 4 selected with a maximum transfer rate of 16.6 MB/s  
(This setting generally works with all hard disk drives manufactured after 1999. For other disk drives, such as IDE CD-ROM drives, check the specifications of the drive.)

→ **DMA Mode [Auto]**

Use the **DMA Mode** BIOS selection to adjust the DMA mode options.

- **Auto**      **DEFAULT**      BIOS auto detects the DMA mode. Use this value if the IDE disk drive support cannot be determined.
- **SWDMA0**      Single Word DMA mode 0 selected with a maximum data transfer rate of 2.1 MB/s
- **SWDMA1**      Single Word DMA mode 1 selected with a maximum data transfer rate of 4.2 MB/s
- **SWDMA2**      Single Word DMA mode 2 selected with a maximum data transfer rate of 8.3 MB/s
- **MWDMA0**      Multi Word DMA mode 0 selected with a maximum data transfer rate of 4.2 MB/s
- **MWDMA1**      Multi Word DMA mode 1 selected with a maximum data transfer rate of 13.3 MB/s
- **MWDMA2**      Multi Word DMA mode 2 selected with a maximum data transfer rate of 16.6 MB/s
- **UDMA1**      Ultra DMA mode 0 selected with a maximum data transfer rate of 16.6 MB/s
- **UDMA1**      Ultra DMA mode 1 selected with a maximum data transfer rate of 25 MB/s
- **UDMA2**      Ultra DMA mode 2 selected with a maximum data transfer rate of 33.3 MB/s



## IMBA-XQ354S Motherboard

- ➔ **UDMA3** Ultra DMA mode 3 selected with a maximum data transfer rate of 44 MB/s (To use this mode, it is required that an 80-conductor ATA cable is used.)
- ➔ **UDMA4** Ultra DMA mode 4 selected with a maximum data transfer rate of 66.6 MB/s (To use this mode, it is required that an 80-conductor ATA cable is used.)
- ➔ **UDMA5** Ultra DMA mode 5 selected with a maximum data transfer rate of 99.9 MB/s (To use this mode, it is required that an 80-conductor ATA cable is used.)

### ➔ **S.M.A.R.T [Auto]**

Use the **S.M.A.R.T** option to auto-detect, disable or enable Self-Monitoring Analysis and Reporting Technology (SMART) on the drive on the specified channel. **S.M.A.R.T** predicts impending drive failures. The **S.M.A.R.T** BIOS option enables or disables this function.

- ➔ **Auto**      **DEFAULT**      BIOS auto detects HDD SMART support.
- ➔ **Disabled**      Prevents BIOS from using the HDD SMART feature.
- ➔ **Enabled**      Allows BIOS to use the HDD SMART feature


### ➔ **32Bit Data Transfer [Enabled]**

Use the **32Bit Data Transfer** BIOS option to enables or disable 32-bit data transfers.

- ➔ **Disabled**      Prevents the BIOS from using 32-bit data transfers.
- ➔ **Enabled**      **DEFAULT**      Allows BIOS to use 32-bit data transfers on supported hard disk drives.

### 5.3.3 Floppy Configuration

Use the **Floppy Configuration menu** to configure the floppy disk drive connected to the system.



#### BIOS Menu 6: IDE Master and IDE Slave Configuration

##### → Floppy A


Use the **Floppy A/B** option to configure the floppy disk drive. Options are listed below:

- Disabled
- 360 KB 5 1/4"
- 1.2 MB 5 1/4"
- 720 KB 3 1/2"
- 1.44 MB 3 1/2"
- 2.88 MB 3 1/2"

## IMBA-XQ354S Motherboard

### 5.3.4 Super IO Configuration

Use the **Super IO Configuration** menu (**BIOS Menu 7**) to set or change the configurations for the FDD controllers, parallel ports and serial ports.



#### BIOS Menu 7: Super IO Configuration

##### ➔ Serial Port1 Address [3F8/IRQ4]

Use the **Serial Port1 Address** option to select the Serial Port 1 base address.

- ➔ **Disabled** No base address is assigned to Serial Port 1
- ➔ **3F8/IRQ4** **DEFAULT** I/O port address is 3F8 and the interrupt address is IRQ4
- ➔ **3E8/IRQ4** I/O port address is 3E8 and the interrupt address is IRQ4
- ➔ **2E8/IRQ3** I/O port address is 2E8 and the interrupt address is IRQ3

##### ➔ Serial Port1 Mode [Normal]

Use the **Serial Port1 Mode** option to select the Serial Port1 operational mode.

- **Normal**      **DEFAULT**      Serial Port 1 mode is normal
- **IrDA**                              Serial Port 1 mode is IrDA
- **ASK IR**                              Serial Port 1 mode is ASK IR

### → **Serial Port2 Address [2F8/IRQ3]**

Use the **Serial Port2 Address** option to select the Serial Port 2 base address.

- **Disabled**                              No base address is assigned to Serial Port 2
- **2F8/IRQ3**      **DEFAULT**      I/O port address is 3F8 and the interrupt address is IRQ3
- **3E8/IRQ4**                              I/O port address is 3E8 and the interrupt address is IRQ4
- **2E8/IRQ3**                              I/O port address is 2E8 and the interrupt address is IRQ3

### → **Serial Port2 Mode [Normal]**

Use the **Serial Port2 Mode** option to select the Serial Port2 operational mode.

- **Normal**      **DEFAULT**      Serial Port 2 mode is normal
- **IrDA**                              Serial Port 2 mode is IrDA
- **ASK IR**                              Serial Port 2 mode is ASK IR

### → **Parallel Address [378]**

The **Parallel Port Address** BIOS option assigns the I/O port address of the parallel port.

The following address options are available:

- **Disabled**                              No I/O port address is assigned to the parallel port
- **378**                              **DEFAULT**      Parallel Port I/O port address is 378
- **278**                              Parallel Port I/O port address is 278
- **3BC**                              Parallel Port I/O port address is 3BC

### → **Parallel Port Mode [Normal]**

The Parallel Port Mode selection selects the mode the parallel port operates in.

## IMBA-XQ354S Motherboard

- **Normal**                      **DEFAULT**      The normal parallel port mode is the standard mode for parallel port operation.
- **EPP**    The parallel port operates in the enhanced parallel port mode (EPP). The EPP mode supports bi-directional communication between the system and the parallel port device and the transmission rates between the two are much faster than the Normal mode.
- **ECP**    The parallel port operates in the extended capabilities port (ECP) mode. The ECP mode supports bi-directional communication between the system and the parallel port device and the transmission rates between the two are much faster than the SPP mode.
- **EPP + ECP**                                      The parallel port operates in the extended capabilities port (ECP) mode. The ECP mode supports bi-directional communication between the system and the parallel port device and the transmission rates between the two are much faster than the Normal mode  
  
The parallel port becomes compatible with EPP devices described above

### → **Parallel Port IRQ [IRQ7]**


The **Parallel Port Address** BIOS option assigns the parallel port interrupt address. The following address options are available.

- **IRQ5**    Parallel port interrupt address is IRQ5
- **IRQ7**    **DEFAULT**      Parallel port interrupt address is IRQ7



### 5.3.5 Hardware Health Configuration

The **Hardware Health Configuration** menu (**BIOS Menu 8** and **BIOS Menu 9**) shows the operating temperature, fan speeds and system voltages.



#### BIOS Menu 8: Hardware Health Configuration

##### → FAN Mode Setting [Full On Mode]

Use the **FAN Mode Setting** option to configure the fan mode options for the following fans:

- CPU fan
- System fan 1
- System fan 2

The fan mode setting options are listed below.

- **Full On Mode**      **DEFAULT**      Fan is on all the time

## IMBA-XQ354S Motherboard

- **Automatic mode** Fan is off when the temperature is low enough.  
Parameters must be set by the user.

When the **FAN Mode Setting** option is in the **Automatic Mode**, the following parameters can be set.

- CPU Temp. Limit of OFF
- CPU Temp. Limit of Start
- CPU Fan Start PWM
- Slope PWM 1

→ **CPU Temp. Limit of OFF [000]**

---



**WARNING:**

Setting this value too high may cause the fan to stop when the CPU is at a high temperature and therefore cause the system to be damaged.

---

The **CPU Temp. Limit of OFF** option can only be set if the **CPU FAN Mode Setting** option is set to **Automatic Mode**. Use the **CPU Temp. Limit of OFF** option to select the CPU temperature at which the cooling fan should automatically turn off. To select a value, select the **CPU Temp. Limit of OFF** option and enter a decimal number between 000 and 127. The temperature range is specified below.

- Minimum Value: 0°C
- Maximum Value: 127°C

→ **CPU Temp. Limit of Start [020]**

---



**WARNING:**

Setting this value too high may cause the fan to start only when the CPU is at a high temperature and therefore cause the system to be damaged.

---

The **CPU Temp. Limit of Start** option can only be set if the **CPU FAN Mode Setting** option is set to **Automatic Mode**. Use the **CPU Temp. Limit of Start** option to select the CPU temperature at which the cooling fan should automatically turn on. When the fan starts, it rotates using the starting pulse width modulation (PWM) specified in the **Fan 3 Start PWM** option below. To select a value, select the **CPU Temp. Limit of Start** option and enter a decimal number between 000 and 127. The temperature range is specified below.

- Minimum Value: 0°C
- Maximum Value: 127°C

→ **CPU Fan Start PWM [070]**

The **Fan 3 Start PWM** option can only be set if the **CPU FAN Mode Setting** option is set to **Automatic Mode**. Use the **Fan 3 Start PWM** option to select the PWM mode the fan starts to rotate with after the temperature specified in the **Temperature 3 Limit of Start** is exceeded. The Super I/O chipset supports 128 PWM modes. To select a value, select the **Fan 3 Start PWM** option and enter a decimal number between 000 and 127. The temperature range is specified below.

- PWM Minimum Mode: 0
- PWM Maximum Mode: 127

→ **Slope PWM 1 [1 PWM]**

The **Slope PWM 1** option can only be set if the **CPU FAN Mode Setting** option is set to **Automatic Mode**. Use the **Slope PWM 1** option to select the linear rate at which the PWM mode increases with respect to an increase in temperature. A list of available options is shown below:

- 0 PWM
- 1 PWM
- 2 PWM
- 4 PWM
- 8 PWM
- 16 PWM
- 32 PWM

## IMBA-XQ354S Motherboard

- 64 PWM

BIOS SETUP UTILITY	
Main	Advanced
PCIPnP    Boot    Security    Chipset    Exit	
<b>Hardware Health Event Monitoring</b>	
CPU Temperature	:43C/109F
System Temperature #1	:33C/91F
System Temperature #2	:33C/91F
CPU Fan Speed	:4821 RPM
SYS Fan Speed	:N/A
SYS Fan2 Speed	:N/A
CPU Core	:1.306 V
DDR2 1.8V	:1.920 V
+3.30V	:3.376 V
+5.00V	:5.080 V
+12.0V	:12.160 V
FSB VTT	:1.136 V
+1.5V	:1.440 V
+1.25V	:1.248 V
VBAT	:3.106 V
	←→ Select Screen ↑↓ Select Item F1 General Help F10 Save and Exit ESC Exit
v02.61 (C)Copyright 1985-2006, American Megatrends, Inc.	

### BIOS Menu 9: Hardware Health Configuration 2


The following system parameters and values are shown. The system parameters that are monitored are:

- **System Temperatures:** The following system temperatures are monitored
  - CPU Temperature
  - System Temperature 1
  - System Temperature 2
- **Fan Speeds:** The CPU cooling fan speed is monitored.
  - CPU fan speed
  - System fan 1 speed
  - System fan 2 speed
- **Voltages:** The following system voltages are monitored
  - CPU Core
  - DDR2 +1.8 V
  - +3.30 V
  - +5.00 V

- +12.0 V
- FSB VTT
- +1.5 V
- +1.25 V
- VBAT

### 5.3.6 APM Configuration

Use the **APM Configuration** menu (**BIOS Menu 10**) to configure the drive connected to SATA connector n.



#### BIOS Menu 10: AHCI Port n Configuration Menu

##### ➔ Restore on AC Power Loss [Last State]

Use the **Restore on AC Power Loss** BIOS option to specify what state the system returns to if there is a sudden loss of power to the system.

- ➔ **Power Off**                      The system remains turned off



## IMBA-XQ354S Motherboard

- **Power On**                      The system turns on
- **Last State**    **DEFAULT**    The system returns to its previous state. If it was on, it turns itself on. If it was off, it remains off.

### → **Resume on Keyboard/Mouse [Disabled]**

Use the **Resume on Keyboard/Mouse** BIOS option to enable activity on either the keyboard or mouse to rouse the system from a suspend or standby state. That is, the system is roused when the mouse is moved or a button on the keyboard is pressed.

- **Disabled**    **DEFAULT**    Wake event not generated by activity on the keyboard or mouse
- **Enabled**                      Wake event generated by activity on the keyboard or mouse
- **Disabled**    **DEFAULT**    Wake event not generated by an incoming call
- **Enabled**                      Wake event generated by an incoming call


### → **Resume on PCI-Express WAKE# [Enabled]**

Use the **Resume PCI-Express WAKE#** BIOS option to enable activity on the PCI-Express WAKE# signal to rouse the system from a suspend or standby state.

- **Disabled**                      Wake event not generated by PCI-Express WAKE# signal activity
- **Enabled**    **DEFAULT**    Wake event generated by PCI-Express WAKE# signal activity

### 5.3.6.1 ACPI Configuration

Use the **ACPI Configuration** menu (**BIOS Menu 11**) to select the ACPI state when the system is suspended.



#### BIOS Menu 11: Advanced ACPI Configuration

##### → Suspend Mode [S1(POS)]


Use the **Suspend Mode** option to specify the sleep state the system enters when it is not being used.

- **S1 (POS)**                      The system enters S1(POS) sleep state. The system appears off. The CPU is stopped; RAM is refreshed; the system is running in a low power mode.
- **S3 (STR)    DEFAULT**      The system enters S3(STR) sleep state.

## IMBA-XQ354S Motherboard

### 5.3.7 AHCI Configuration

Use the **AHCI Configuration** Settings menu (**BIOS Menu 12**) to report on the auto-detection of devices connected to the onboard SATA drive connectors.




#### BIOS Menu 12: AHCI Configuration

##### → AHCI Port n [Not Detected]

Use the **AHCI Port n** BIOS option to check what AHCI (Advanced Host Controller Interface) devices are detected to a specified SATA drive connector. If a device is detected, selecting the BIOS option, e.g. "**AHCI Port 3**" opens a new window.

### 5.3.8 Remote Access Configuration

Use the **Remote Access Configuration** menu (**BIOS Menu 13**) to configure remote access parameters. The **Remote Access Configuration** is an AMIBIOS feature and allows a remote host running a terminal program to display and configure the BIOS settings.



#### BIOS Menu 13: Remote Access Configuration [Advanced]

##### ➔ Remote Access [Disabled]

Use the **Remote Access** option to enable or disable access to the remote functionalities of the system.

➔ **Disabled**      **DEFAULT**      Remote access is disabled.

## IMBA-XQ354S Motherboard

### → Enabled

Remote access configuration options shown below appear:

- Serial Port Number
- Serial Port Mode
- Flow Control
- Redirection after BIOS POST
- Terminal Type
- VT-UTF8 Combo Key Support
- Sredir Memory Display Delay

These configuration options are discussed below.

### → Serial Port Number [COM1]

Use the **Serial Port Number** option to select the serial port used for remote access.

→ **COM1**    **DEFAULT**    System is remotely accessed through COM1

→ **COM2**    System is remotely accessed through COM2

**NOTE:** Make sure the selected COM port is enabled through the Super I/O configuration menu.

### → Base Address, IRQ [3F8h,4]

The **Base Address, IRQ** option cannot be configured and only shows the interrupt address of the serial port listed above.

### → Serial Port Mode [115200 8,n,1]

Use the **Serial Port Mode** option to select baud rate through which the console redirection is made. The following configuration options are available

- 115200 8,n,1 **DEFAULT**
- 57600 8,n,1
- 38400 8,n,1
- 19200 8,n,1
- 09600 8,n,1



**→ Redirection After BIOS POST [Always]**

Use the **Redirection After BIOS POST** option to specify when console redirection should occur.

- **Disabled**                      The console is not redirected after POST
- **Boot Loader**                      Redirection is active during POST and during Boot Loader
- **Always**                      **DEFAULT**                      Redirection is always active (Some OSes may not work if set to Always)

**→ Terminal Type [ANSI]**


Use the **Terminal Type** BIOS option to specify the remote terminal type.

- **ANSI**                      **DEFAULT**                      The target terminal type is ANSI
- **VT100**                      The target terminal type is VT100
- **VT-UTF8**                      The target terminal type is VT-UTF8

## IMBA-XQ354S Motherboard

### 5.3.9 Trusted Computing

Use the **Trusted Computing** menu (**BIOS Menu 14**) to configure settings related to the Trusted Computing Group (TCG) Trusted Platform Module (TPM).



#### BIOS Menu 14: Trusted Computing


##### → TCG/TPM Support [No]

Use the **TCG/TPM Support** option to configure support for the TPM.

- **No**    DEFAULT    TPM support is disabled.
- **Yes**                TPM support is enabled.

### 5.3.10 USB Configuration

Use the **USB Configuration** menu (**BIOS Menu 15**) to read USB configuration information and configure the USB settings.



#### BIOS Menu 15: USB Configuration

##### ➔ USB Functions [Enabled]

Use the **USB Function** BIOS option to enable or disable USB function support.

- ➔ Disabled USB function support disabled
- ➔ Enabled **DEFAULT** USB function support enabled

##### ➔ Legacy USB Support [Enabled]

Use the **Legacy USB Support** BIOS option to enable USB mouse and USB keyboard support.

## IMBA-XQ354S Motherboard

Normally if this option is not enabled, any attached USB mouse or USB keyboard does not become available until a USB compatible operating system is fully booted with all USB drivers loaded. When this option is enabled, any attached USB mouse or USB keyboard can control the system even when there is no USB driver loaded onto the system.

- ➔ **Disabled** Legacy USB support disabled
- ➔ **Enabled**     **DEFAULT** Legacy USB support enabled
- ➔ **Auto** Legacy USB support disabled if no USB devices are connected

### ➔ USB 2.0 Controller [Enabled]

Use the **USB 2.0 Controller** BIOS option to enable or disable the USB 2.0 controller

- ➔ **Disabled** USB 2.0 controller disabled
- ➔ **Enabled**     **DEFAULT** USB 2.0 controller enabled

### ➔ USB2.0 Controller Mode [HiSpeed]

Use the **USB2.0 Controller Mode** option to set the speed of the USB2.0 controller.

- ➔ **FullSpeed** The controller is capable of operating at 12 Mb/s
- ➔ **HiSpeed**     **DEFAULT** The controller is capable of operating at 480 Mb/s

## 5.4 PCI/PnP


Use the PCI/PnP menu (**BIOS Menu 16**) to configure advanced PCI and PnP settings.



### **WARNING:**

Setting wrong values for the BIOS selections in the PCIPnP BIOS menu may cause the system to malfunction.

---



**BIOS Menu 16: PCI/PnP Configuration**

→ **IRQ# [Available]**

Use the **IRQ#** address to specify what IRQs can be assigned to a particular peripheral device.

- **Available**    **DEFAULT**    The specified IRQ is available to be used by PCI/PnP devices
- **Reserved**                    The specified IRQ is reserved for use by Legacy ISA devices

Available IRQ addresses are:

- IRQ3
- IRQ4
- IRQ5
- IRQ7
- IRQ9



## IMBA-XQ354S Motherboard

- IRQ10
- IRQ 11
- IRQ 14
- IRQ 15

### → DMA Channel# [Available]

Use the **DMA Channel#** option to assign a specific DMA channel to a particular PCI/PnP device.

- |   |                  |                |  |
|---|------------------|----------------|--|
| → | <b>Available</b> | <b>DEFAULT</b> | The specified DMA is available to be used by PCI/PnP devices |
| → | <b>Reserved</b>  |                | The specified DMA is reserved for use by Legacy ISA devices  |

Available DMA Channels are:

- DM Channel 0
- DM Channel 1
- DM Channel 3
- DM Channel 5
- DM Channel 6
- DM Channel 7


### → Reserved Memory Size [Disabled]

Use the **Reserved Memory Size** BIOS option to specify the amount of memory that should be reserved for legacy ISA devices.

- |   |                 |                |   |
|---|-----------------|----------------|---|
| → | <b>Disabled</b> | <b>DEFAULT</b> | No memory block reserved for legacy ISA devices |
| → | <b>16K</b>      |                | 16 KB reserved for legacy ISA devices           |
| → | <b>32K</b>      |                | 32 KB reserved for legacy ISA devices           |
| → | <b>64K</b>      |                | 54 KB reserved for legacy ISA devices           |

## 5.5 Boot

Use the Boot menu (**BIOS Menu 17**) to configure system boot options.




**BIOS Menu 17: Boot**

## IMBA-XQ354S Motherboard

### 5.5.1 Boot Settings Configuration

Use the Boot Settings Configuration menu (**BIOS Menu 17**) to configure advanced system boot options.



#### BIOS Menu 18: Boot Settings Configuration

##### → Quick Boot [Enabled]

Use the **Quick Boot** BIOS option to make the computer speed up the boot process.

- **Disabled** No POST procedures are skipped
- **Enabled** **DEFAULT** Some POST procedures are skipped to decrease the system boot time

##### → Quiet Boot [Disabled]

Use the **Quiet Boot** BIOS option to select the screen display when the system boots.

- **Disabled** **DEFAULT** Normal POST messages displayed

→ **Enabled** OEM Logo displayed instead of POST messages

→ **AddOn ROM Display Mode [Force BIOS]**

The **AddOn ROM Display Mode** option allows add-on ROM (read-only memory) messages to be displayed.

→ **Force BIOS** **DEFAULT** Allows the computer system to force a third party BIOS to display during system boot.

→ **Keep Current** Allows the computer system to display the information during system boot.

→ **Bootup Num-Lock [Off]**

The **Bootup Num-Lock** BIOS option allows the Number Lock setting to be modified during boot up.

→ **Off** **DEFAULT** Does not enable the keyboard Number Lock automatically. To use the 10-keys on the keyboard, press the Number Lock key located on the upper left-hand corner of the 10-key pad. The Number Lock LED on the keyboard lights up when the Number Lock is engaged.

→ **On** Allows the Number Lock on the keyboard to be enabled automatically when the computer system boots up. This allows the immediate use of the 10-key numeric keypad located on the right side of the keyboard. To confirm this, the Number Lock LED light on the keyboard is lit.

→ **Boot From LAN Support (82573L) [Disabled]**

The **BOOT From LAN Support** allows the system to be booted remotely over a network through LAN1.

→ **Disabled** **DEFAULT** Cannot be booted remotely through this port


→ **Enabled** Can be booted remotely through this port

## IMBA-XQ354S Motherboard

### 5.5.2 Boot Device Priority

Use the **Boot Device Priority** menu (**BIOS Menu 19**) to specify the boot sequence from the available devices. The following options are available:

- 1<sup>st</sup> Boot Device
- 2<sup>nd</sup> Boot Device
- 3<sup>rd</sup> Boot Device



#### BIOS Menu 19: Boot Device Priority Settings

### 5.5.3 Hard Disk Drives

Use the **Hard Disk Drives** menu to specify the boot sequence of the available HDDs. When the menu is opened, the HDDs connected to the system are listed as shown below:


- 1st Drive
- 2nd Drive
- 3rd Drive





**NOTE:**

Only installed drives are shown in the list.



**BIOS Menu 20: Hard Disk Drives**

**5.5.4 CD/DVD Drives**

Use the **CD/DVD Drives** menu to specify the boot sequence of the available CD/DVD drives. When the menu is opened, the CD drives and DVD drives connected to the system are listed as shown below:


- 1st Drive
- 2nd Drive
- 3rd Drive

## IMBA-XQ354S Motherboard



### NOTE:

Only installed CD and DVD drives are shown in the list



### BIOS Menu 21: CD/DVD Drives

## 5.5.5 Removable Drives

Use the **Removable Drives** menu (**BIOS Menu 22**) to specify the boot sequence of the available FDDs. When the menu is opened, the FDDs connected to the system are listed as shown below:

- 1st Drive
- 2nd Drive



**NOTE:**

Only installed removable drives are shown in the list. This menu does not show if there are no removable drives.


BIOS SETUP UTILITY						
Main	Advanced	PCIPnP	Boot	Security	Chipset	Exit
Removable Drives				Specifies the boot sequence from the available devices.		
1st Drive			[Removable Drive 1]			
2nd Drive			[Removable Drive 2]			
3rd Drive			[Removable Drive 3]			
				←→ Select Screen ↑↓ Select Item +- Change Option F1 General Help F10 Save and Exit ESC Exit		
v02.61 (C) Copyright 1985-2006, American Megatrends, Inc.						

**BIOS Menu 22: Removable Drives**

## IMBA-XQ354S Motherboard

## 5.6 Security

Use the Security menu (**BIOS Menu 23**) to set system and user passwords.



### BIOS Menu 23: Security

#### → Change Supervisor Password

Use the **Change Supervisor Password** to set or change a supervisor password. The default for this option is **Not Installed**. If a supervisor password must be installed, select this field and enter the password. After the password has been added, **Install** appears next to **Change Supervisor Password**.

#### → Change User Password

Use the **Change User Password** to set or change a user password. The default for this option is **Not Installed**. If a user password must be cleared, select this field and enter the password. After the password has been added, **Install** appears next to **Change User Password**.


## 5.7 Chipsets

Use the **Chipset** menu to access the Northbridge and Southbridge configuration menus



**WARNING:**

Setting the wrong values for the Chipset BIOS selections in the Chipset BIOS menu may cause the system to malfunction.




**BIOS Menu 24: Chipset**



## IMBA-XQ354S Motherboard

### 5.7.1 Northbridge Chipset Configuration

Use the Northbridge Chipset Configuration menu (**BIOS Menu 25**) to configure the Northbridge chipset settings.



#### BIOS Menu 25:Northbridge Chipset Configuration

##### ➔ Memory Remap Feature [Enabled]

Use the **Memory Remap Feature** option to allow the overlapped PCI memory above the total physical memory to be remapped. Enabling this option allows full use of 4 GB or more RAM in Windows VISTA, which reports only up to 3.12 GB when this feature is disabled.

- ➔ **Enabled**      **DEFAULT**      Overlapped PCI memory can be remapped
- ➔ **Disabled**                      Overlapped PCI memory cannot be remapped

→ **Memory Hole [Disabled]**

The **Memory Hole** reserves the memory space between 15 MB and 16 MB for ISA expansion cards that require a specified area of memory to work properly. If an older ISA expansion card is used, please refer to the documentation that came with the card to see if it is necessary to reserve the space.

→ **Disabled**      **DEFAULT**      Memory is not reserved for ISA expansion cards

→ **Enabled**                      Memory is reserved for ISA expansion cards

→ **Initiate Graphic Adapter**

Use the **Initiate Graphic Adapter** option to select the graphics controller used as the primary boot device. Select either an integrated graphics controller (IGD) or a combination of PCI graphics controller, a PCI express (PEG) controller or an IGD. Configuration options are listed below:

- IGD
- PEG/IGD
- PEG/PCI              **DEFAULT**
- PCI/PEG
- PCI/IGD

→ **Internal Graphics Mode Select [Enable, 8 MB]**

The **Internal Graphic Mode Select** option determines the amount of system memory that can be used by the Internal graphics device.


→ **Enable, 1 MB**                      1 MB of memory used by internal graphics device

→ **Enable, 8 MB**      **DEFAULT**      8 MB of memory used by internal graphics device

## IMBA-XQ354S Motherboard

### 5.7.2 Southbridge Chipset Configuration

Use the Southbridge Configuration menu (**BIOS Menu 26**) to configure the Southbridge chipset.



#### BIOS Menu 26: Southbridge Chipset Configuration

##### → HDA Controller [Disabled]

Use the **HDA Controller** option to enable the Southbridge high definition audio controller. If the optional AC-KIT-833HD has been connected to the system, or any other HDA device, this option should be enabled.

→ **Disabled**      **DEFAULT**      Southbridge HDA controller is disabled

→ **Enabled**                      Southbridge HDA controller is enabled


##### → ASF Support [Enabled]

Use the **ASF Support** BIOS to allow remote management using ASF technology.

- ➔ **Disabled**                      The system will not communicate with a remote management server.
  
- ➔ **Enabled**    **DEFAULT**      The Alert Standard Format (ASF) controller is activated and can communicate with a remote management server.

### 5.8 Exit

Use the **Exit** menu (**BIOS Menu 27**) to load default BIOS values, optimal failsafe values and to save configuration changes.



#### BIOS Menu 27:Exit

- ➔ **Save Changes and Exit**

Use the **Save Changes and Exit** option to save the changes made to the BIOS options and to exit the BIOS configuration setup program.

## IMBA-XQ354S Motherboard

### → Discard Changes and Exit

Use the **Discard Changes and Exit** option to exit the BIOS configuration setup program without saving the changes made to the system.

### → Discard Changes

Use the **Discard Changes** option to discard the changes and remain in the BIOS configuration setup program.

### → Load Optimal Defaults

Use the **Load Optimal Defaults** option to load the optimal default values for each of the parameters on the Setup menus. **F9 key can be used for this operation.**

### → Load Failsafe Defaults

Use the **Load Failsafe Defaults** option to load failsafe default values for each of the parameters on the Setup menus. **F8 key can be used for this operation.**



Chapter

**6**

# Software Drivers

---

## 6.1 Available Software Drivers

---



**NOTE:**

The content of the CD may vary throughout the life cycle of the product and is subject to change without prior notice.

---

The following drivers can be installed on the system:

- 6.3 Chipset Driver ..... 129
- 6.4 Graphics Driver ..... 131
- 6.5 LAN Driver..... 135
- 6.6 Audio Driver..... 138
- 6.7 Intel® Matrix Storage Manager Driver ..... 140


Installation instructions are given below.

## 6.2 Starting the Driver Program

To access the driver installation programs, please do the following.

- Step 1:** Insert the CD-ROM that came with the system into a CD-ROM drive attached to the system.


**Step 2:** The screen in **Figure 6-1** appears.



**Figure 6-1: Start Up Screen**

**Step 3:** Click **IMBA-XQ354S**.

**Step 4:** The list of drivers in **Figure 6-2** appears.



**Figure 6-2: Drivers**

## IMBA-XQ354S Motherboard

### 6.3 Chipset Driver

To install the Intel® chipset driver, please follow the steps below.

**Step 1:** Click "INF" in the driver menu.

**Step 2:** Browse through the folders and double-click "infinst911 autol".

**Step 3:** The Welcome screen appears (Figure 6-3).



**Figure 6-3: Intel® Setup Welcome Screen**

**Step 4:** Click **NEXT** to continue.

**Step 5:** The Intel® license agreement screen appears (Figure 6-4).






**Figure 6-4: Intel Chipset Driver License Agreement**

**Step 6:** Click **YES** to accept the agreement and continue.

**Step 7:** The Readme file contents are displayed (**Figure 6-5**).



**Figure 6-5: Readme File**

**Step 8:** Click **NEXT** to begin the installation.



## IMBA-XQ354S Motherboard

**Step 9:** When the setup is complete, the final screen appears (Figure 6-6).



**Figure 6-6: Intel® Chipset Driver Complete Installation Screen**

**Step 10:** To exit the installation, click **FINISH**.


## 6.4 Graphics Driver

To install the chipset driver, please follow the steps below:

**Step 1:** Click "VGA" in the driver menu and select the folder which corresponds to the operating system.

**Step 2:** Double-click the driver file.


**Step 3:** The version information file appears (Figure 6-7).



**Figure 6-7: Graphics Driver Readme File**

**Step 4:** Click **NEXT** to continue.

**Step 5:** The welcome screen appears (**Figure 6-8**).




**Figure 6-8: Graphics Driver Installation Welcome Screen**

**Step 6:** Click **NEXT** to continue.

## IMBA-XQ354S Motherboard


**Step 7:** The license agreement appears (Figure 6-9).



**Figure 6-9: GMA Driver License Agreement**

**Step 8:** Click YES to continue.

**Step 9:** The Readme file appears (Figure 6-10).



**Figure 6-10: GMA Driver Installing Notice**




**Step 10:** Click **NEXT** to continue.

**Step 11:** The driver installation progress is shown (**Figure 6-11**).



**Figure 6-11: GMA Driver Installation Complete**

**Step 12:** Click **NEXT** to continue to the final screen.



**Figure 6-12: GMA Driver Installing Notice**

## IMBA-XQ354S Motherboard

**Step 13:** For newly installed drivers to take effect, the computer must be restarted. Select "Yes" to restart the computer now (close any other programs first), or "No" to restart it later. Click **FINISH** to complete the installation.

### 6.5 LAN Driver


To install the LAN drivers, please follow the steps below.

**Step 1:** Click "LAN" in the driver menu and click the **Intel** folder.

**Step 2:** Select the folder which corresponds to the operating system.

**Step 3:** Double-click the driver file.

**Step 4:** The welcome screen appears (**Figure 6-13**).




**Figure 6-13: LAN Driver Welcome Screen**

**Step 5:** Click **NEXT** to continue.

**Step 6:** The license agreement appears (**Figure 6-14**).






**Figure 6-14: LAN Driver License Agreement**

**Step 7:** Accept the conditions of the license agreement and click **NEXT** to continue.

**Step 8:** The Setup Options screen appears (**Figure 6-15**).




**Figure 6-15: LAN Driver Setup Options**

**Step 9:** Select the setup options (default recommended) and click **NEXT** to continue.

## IMBA-XQ354S Motherboard

**Step 10:** The drivers are ready to install. Click **INSTALL** to begin the installation process (Figure 6-16).



**Figure 6-16: LAN Driver Installation Ready Window**

**Step 11:** Click **INSTALL** to begin the driver installation.

**Step 12:** The window shows the installation is complete (Figure 6-17).




Figure 6-17: LAN Driver Installation Progress

**Step 13:** Click **FINISH** to exit the setup program.

## 6.6 Audio Driver

To install the Realtek High Definition (HD) Audio driver, please follow the steps below.

### 6.6.1 BIOS Setup

**Step 1:** Enter the BIOS setup. To do this, reboot the system and press **DEL** during POST.

**Step 2:** Go to the Southbridge Configuration menu. Enable the High Definition Audio controller.

**Step 3:** Press **F10** to save the changes and exit the BIOS setup. The system reboots.

### 6.6.2 Driver Installation

To install the audio driver please follow the steps below.


**Step 1:** Select "**AUDIO**" in the driver menu and select the **ALC888** folder.

**Step 2:** Select the folder which corresponds to the operating system.

## IMBA-XQ354S Motherboard

**Step 3:** Double-click the driver file.


**Step 4:** The audio driver InstallShield wizard begins (**Figure 6-18**).



**Figure 6-18: InstallShield Wizard Welcome Screen**

**Step 5:** Click **NEXT** to continue the installation.

**Step 6:** Don't click on any screens until the final screen appears (**Figure 6-19**).



**Figure 6-19: Installation Wizard Finished**

**Step 7:** For the audio drivers to take effect, the computer must be restarted. Select "Yes" to restart the computer immediately after exiting the wizard, or "No" to restart it later. Click **FINISH** to exit the InstallShield Wizard.

## 6.7 Intel® Matrix Storage Manager Driver


To install the Intel® Matrix Storage Manager driver, please follow the steps below:

**Step 1:** Select **SATA** in the driver menu.

**Step 2:** Double-click the **Intel Matrix Storage Manager** folder.

**Step 3:** Double-click the **IATA89CD.exe** program icon.

**Step 4:** **Figure 6-20** shows the InstallShield Wizard preparing to guide the user through the rest of the process.



**Figure 6-20: InstallShield Wizard Setup Screen**

**Step 5:** **Figure 6-21** shows the Matrix Storage Manager software configuring the installation process.



## IMBA-XQ354S Motherboard




Figure 6-21: Matrix Storage Manager Setup Screen

**Step 6:** Figure 6-22 shows the Matrix Storage Manager welcome screen.






Figure 6-22: Matrix Storage Manager Welcome Screen

**Step 7:** Click **NEXT** and a warning appears (**Figure 6-23**). Read the warning carefully and decide whether or not to continue the installation process.



**Figure 6-23: Matrix Storage Manager Warning Screen**

**Step 8:** Click **NEXT** and a license agreement appears (**Figure 6-24**).



**Figure 6-24: Matrix Storage Manager License Agreement**

**Step 9:** Read the license agreement. To accept the terms and conditions stipulated in the license agreement shown, click **YES** and the Readme information file shown in **Figure 6-25** appears.

IMBA-XQ354S Motherboard




Figure 6-25: Matrix Storage Manager Readme File

**Step 10:** Read the Readme file information and click **NEXT**.

**Step 11:** After the driver installation process is complete, a confirmation screen appears (Figure 6-26).




Figure 6-26: Matrix Storage Manager Setup Complete

**Step 12:** The confirmation screen offers the option of restarting the computer now or later.

For the settings to take effect, the computer must be restarted. Click **FINISH** to exit the wizard.

Appendix

**A**

# BIOS Options

---



Below is a list of BIOS configuration options in the BIOS chapter.

<b>System Overview .....</b>	<b>81</b>
<b>System Time [hh:mm:ss] .....</b>	<b>82</b>
<b>System Date [DAY dd/mm/yyyy] .....</b>	<b>82</b>
<b>SATA#n Configuration [Enhanced].....</b>	<b>85</b>
<b>Configure SATA#n as [IDE].....</b>	<b>85</b>
<b>IDE Master and IDE Slave.....</b>	<b>86</b>
<b>Auto-Detected Drive Parameters.....</b>	<b>87</b>
<b>Type [Auto] .....</b>	<b>88</b>
<b>LBA/Large Mode [Auto].....</b>	<b>89</b>
<b>Block (Multi Sector Transfer) [Auto] .....</b>	<b>89</b>
<b>PIO Mode [Auto].....</b>	<b>89</b>
<b>DMA Mode [Auto].....</b>	<b>90</b>
<b>S.M.A.R.T [Auto].....</b>	<b>91</b>
<b>32Bit Data Transfer [Enabled].....</b>	<b>91</b>
<b>Floppy A.....</b>	<b>92</b>
<b>Serial Port1 Address [3F8/IRQ4] .....</b>	<b>93</b>
<b>Serial Port1 Mode [Normal].....</b>	<b>93</b>
<b>Serial Port2 Address [2F8/IRQ3] .....</b>	<b>94</b>
<b>Serial Port2 Mode [Normal].....</b>	<b>94</b>
<b>Parallel Address [378] .....</b>	<b>94</b>
<b>Parallel Port Mode [Normal].....</b>	<b>94</b>
<b>Parallel Port IRQ [IRQ7].....</b>	<b>95</b>
<b>FAN Mode Setting [Full On Mode].....</b>	<b>96</b>
<b>CPU Temp. Limit of OFF [000] .....</b>	<b>97</b>
<b>CPU Temp. Limit of Start [020] .....</b>	<b>97</b>
<b>CPU Fan Start PWM [070].....</b>	<b>98</b>
<b>Slope PWM 1 [1 PWM] .....</b>	<b>98</b>
<b>Restore on AC Power Loss [Last State] .....</b>	<b>100</b>
<b>Resume on Keyboard/Mouse [Disabled] .....</b>	<b>101</b>
<b>Resume on PCI-Express WAKE# [Enabled].....</b>	<b>101</b>
<b>Suspend Mode [S1(POS)].....</b>	<b>102</b>
<b>AHCI Port n [Not Detected] .....</b>	<b>103</b>
<b>Remote Access [Disabled].....</b>	<b>104</b>

## IMBA-XQ354S Motherboard

Serial Port Number [COM1].....	105
Base Address, IRQ [3F8h,4].....	105
Serial Port Mode [115200 8,n,1].....	105
Redirection After BIOS POST [Always] .....	106
Terminal Type [ANSI].....	106
TCG/TPM Support [No].....	107
USB Functions [Enabled].....	108
Legacy USB Support [Enabled].....	108
USB 2.0 Controller [Enabled].....	109
USB2.0 Controller Mode [HiSpeed] .....	109
IRQ# [Available].....	110
DMA Channel# [Available] .....	111
Reserved Memory Size [Disabled] .....	111
Quick Boot [Enabled] .....	113
Quiet Boot [Disabled] .....	113
AddOn ROM Display Mode [Force BIOS] .....	114
Bootup Num-Lock [Off] .....	114
Boot From LAN Support (82573L) [Disabled] .....	114
Change Supervisor Password .....	119
Change User Password.....	119
Memory Remap Feature [Enabled].....	121
Memory Hole [Disabled].....	122
Initiate Graphic Adapter .....	122
Internal Graphics Mode Select [Enable, 8 MB] .....	122
HDA Controller [Disabled].....	123
ASF Support [Enabled].....	123
Save Changes and Exit .....	124
Discard Changes and Exit.....	125
Discard Changes.....	125
Load Optimal Defaults.....	125
Load Failsafe Defaults.....	125

Appendix

**B**

# Terminology

---

## IMBA-XQ354S Motherboard

<b>AC '97</b>	Audio Codec 97 (AC'97) refers to a codec standard developed by Intel® in 1997.
<b>ACPI</b>	Advanced Configuration and Power Interface (ACPI) is an OS-directed configuration, power management, and thermal management interface.
<b>AHCI</b>	Advanced Host Controller Interface (AHCI) is a SATA Host controller register-level interface.
<b>ATA</b>	The Advanced Technology Attachment (ATA) interface connects storage devices including hard disks and CD-ROM drives to a computer.
<b>ARMD</b>	An ATAPI Removable Media Device (ARMD) is any ATAPI device that supports removable media, besides CD and DVD drives.
<b>ASKIR</b>	Amplitude Shift Keyed Infrared (ASKIR) is a form of modulation that represents a digital signal by varying the amplitude (“volume”) of the signal. A low amplitude signal represents a binary 0, while a high amplitude signal represents a binary 1.
<b>BIOS</b>	The Basic Input/Output System (BIOS) is firmware that is first run when the computer is turned on and can be configured by the end user
<b>CODEC</b>	The Compressor-Decompressor (CODEC) encodes and decodes digital audio data on the system.
<b>CompactFlash®</b>	CompactFlash® is a solid-state storage device. CompactFlash® devices use flash memory in a standard size enclosure. Type II is thicker than Type I, but a Type II slot can support both types.
<b>CMOS</b>	Complimentary metal-oxide-conductor is an integrated circuit used in chips like static RAM and microprocessors.
<b>COM</b>	COM refers to serial ports. Serial ports offer serial communication to expansion devices. The serial port on a personal computer is usually a male D-sub 9 connector.
<b>DAC</b>	The Digital-to-Analog Converter (DAC) converts digital signals to analog signals.
<b>DDR</b>	Double Data Rate refers to a data bus transferring data on both the rising and falling edges of the clock signal.

<b>DMA</b>	Direct Memory Access (DMA) enables some peripheral devices to bypass the system processor and communicate directly with the system memory.
<b>DIMM</b>	Dual Inline Memory Modules are a type of RAM that offer a 64-bit data bus and have separate electrical contacts on each side of the module.
<b>DIO</b>	The digital inputs and digital outputs are general control signals that control the on/off circuit of external devices or TTL devices. Data can be read or written to the selected address to enable the DIO functions.
<b>EHCI</b>	The Enhanced Host Controller Interface (EHCI) specification is a register-level interface description for USB 2.0 Host Controllers.
<b>EIDE</b>	Enhanced IDE (EIDE) is a newer IDE interface standard that has data transfer rates between 4.0 MB/s and 16.6 MB/s.
<b>EIST</b>	Enhanced Intel® SpeedStep Technology (EIST) allows users to modify the power consumption levels and processor performance through application software. The application software changes the bus-to-core frequency ratio and the processor core voltage.
<b>FSB</b>	The Front Side Bus (FSB) is the bi-directional communication channel between the processor and the Northbridge chipset.
<b>GbE</b>	Gigabit Ethernet (GbE) is an Ethernet version that transfers data at 1.0 Gb/s and complies with the IEEE 802.3-2005 standard.
<b>GPIO</b>	General purpose input
<b>HDD</b>	Hard disk drive (HDD) is a type of magnetic, non-volatile computer storage device that stores digitally encoded data.
<b>ICH</b>	The Input/Output Control Hub (ICH) is an Intel® Southbridge chipset.
<b>IrDA</b>	Infrared Data Association (IrDA) specify infrared data transmission protocols used to enable electronic devices to wirelessly communicate with each other.
<b>L1 Cache</b>	The Level 1 Cache (L1 Cache) is a small memory cache built into the system processor.
<b>L2 Cache</b>	The Level 2 Cache (L2 Cache) is an external processor memory cache.



## IMBA-XQ354S Motherboard

<b>LCD</b>	Liquid crystal display (LCD) is a flat, low-power display device that consists of two polarizing plates with a liquid crystal panel in between.
<b>LVDS</b>	Low-voltage differential signaling (LVDS) is a dual-wire, high-speed differential electrical signaling system commonly used to connect LCD displays to a computer.
<b>POST</b>	The Power-on Self Test (POST) is the pre-boot actions the system performs when the system is turned-on.
<b>RAM</b>	Random Access Memory (RAM) is volatile memory that loses data when power is lost. RAM has very fast data transfer rates compared to other storage like hard drives.
<b>SATA</b>	Serial ATA (SATA) is a serial communications bus designed for data transfers between storage devices and the computer chipsets. The SATA bus has transfer speeds up to 1.5 Gb/s and the SATA II bus has data transfer speeds of up to 3.0 Gb/s.
<b>S.M.A.R.T</b>	Self Monitoring Analysis and Reporting Technology (S.M.A.R.T) refers to automatic status checking technology implemented on hard disk drives.
<b>UART</b>	Universal Asynchronous Receiver-transmitter (UART) is responsible for asynchronous communications on the system and manages the system's serial communication (COM) ports.
<b>UHCI</b>	The Universal Host Controller Interface (UHCI) specification is a register-level interface description for USB 1.1 Host Controllers.
<b>USB</b>	The Universal Serial Bus (USB) is an external bus standard for interfacing devices. USB 1.1 supports 12 Mb/s data transfer rates and USB 2.0 supports 480 Mb/s data transfer rates.
<b>VGA</b>	The Video Graphics Array (VGA) is a graphics display system developed by IBM.

Appendix

**C**

# Digital I/O Interface

---

## IMBA-XQ354S Motherboard

### C.1 Introduction

The DIO connector is interfaced to GPIO ports on the Super I/O chipset. The DIO has both 4-bit digital inputs and 4-bit digital outputs. The digital inputs and digital outputs are generally control signals that control the on/off circuit of external devices or TTL devices. Data can be read or written to the selected address to enable the DIO functions.



#### NOTE:

For further information, please refer to the datasheet for the Super I/O chipset.

### C.2 DIO Connector Pinouts

The Digital I/O port pins and their pin numbers are listed in the table below.

Pin	Description	Super I/O Pin No	Super I/O Pin Description
1	Ground	N/A	N/A
2	VCC	N/A	N/A
3	Output 3	20	GP27
4	Output 2	21	GP26
5	Output 1	22	GP25
6	Output 0	23	GP24
7	Input 3	24	GP23
8	Input 2	25	GP22
9	Input 1	26	GP21
10	Input 0	27	GP20

**Table C-1: Digital I/O Connector Pinouts**

### C.3 Assembly Language Samples

#### C.3.1 Enable the DIO Input Function

The BIOS interrupt call INT 15H controls the digital I/O. An assembly program to enable digital I/O input functions is listed below.

<b>MOV</b>	<b>AX, 6F08H</b>	Sets the digital port as input
<b>INT</b>	<b>15H</b>	Initiates the INT 15H BIOS call

### C.3.2 Enable the DIO Output Function

The BIOS interrupt call INT 15H controls the digital I/O. An assembly program to enable digital I/O output functions is listed below.

<b>MOV</b>	<b>AX, 6F09H</b>	Sets the digital port as output
<b>MOV</b>	<b>BL, 09H</b>	
<b>INT</b>	<b>15H</b>	Initiates the INT 15H BIOS call

Appendix

**D**

# Watchdog Timer

---





**NOTE:**

The following discussion applies to DOS environment. IEI support is contacted or the IEI website visited for specific drivers for more sophisticated operating systems, e.g., Windows and Linux.

The Watchdog Timer is provided to ensure that standalone systems can always recover from catastrophic conditions that cause the CPU to crash. This condition may have occurred by external EMIs or a software bug. When the CPU stops working correctly, Watchdog Timer either performs a hardware reset (cold boot) or a Non-Maskable Interrupt (NMI) to bring the system back to a known state.

A BIOS function call (INT 15H) is used to control the Watchdog Timer.

INT 15H:

<b>AH – 6FH Sub-function:</b>	
AL – 2:	Sets the Watchdog Timer’s period.
BL:	Time-out value (Its unit-second is dependent on the item “Watchdog Timer unit select” in CMOS setup).

**Table D-1: AH-6FH Sub-function**

Call sub-function 2 to set the time-out period of Watchdog Timer first. If the time-out value is not zero, the Watchdog Timer starts counting down. When the timer value reaches zero, the system resets. To ensure that this reset condition does not occur, calling sub-function 2 must periodically refresh the Watchdog Timer. However, the watchdog timer is disabled if the time-out value is set to zero.

A tolerance of at least 10% must be maintained to avoid unknown routines within the operating system (DOS), such as disk I/O that can be very time-consuming.

## IMBA-XQ354S Motherboard

**NOTE:**

When exiting a program it is necessary to disable the Watchdog Timer, otherwise the system resets.

**EXAMPLE PROGRAM:**

**; INITIAL TIMER PERIOD COUNTER**

;

**W\_LOOP:**

;

```

MOV      AX, 6F02H      ;setting the time-out value
MOV      BL, 30         ;time-out value is 48 seconds
INT      15H

```

;

**; ADD THE APPLICATION PROGRAM HERE**

;

```

CMP      EXIT_AP, 1     ;is the application over?
JNE      W_LOOP        ;No, restart the application

MOV      AX, 6F02H      ;disable Watchdog Timer
MOV      BL, 0         ;
INT      15H

```

;

**; EXIT ;**

Appendix

**E**

# Intel® Matrix Storage Manager

---

## IMBA-XQ354S Motherboard

### E.1 Introduction

The IMBA-XQ354S can provide data protection for serial ATA (SATA) disks via the Intel® Matrix Storage Manager using one of three fault-tolerant RAID levels: RAID 1, 5 or 10. When using two hard drives, matrix RAID allows RAID 0 and RAID 1 functions to be combined, where critical files can be stored on RAID 1, and RAID 0 can be used for non-critical items such as software. RAID 5 and RAID 0 can be combined to provide higher performance, capacity, and fault tolerance.



#### **CAUTION!**

A configured RAID volume (which may consist of multiple hard drives) appears to an operating system as a contingent storage space. The operating system will not be able to distinguish the physical disk drives contained in a RAID configuration.

---

#### E.1.1 Precautions

One key benefit a RAID configuration brings is that a single hard drive can fail within a RAID array without damaging data. With RAID1 array, a failed drive can be replaced and the RAID configuration restored.



#### **WARNING!**

Irrecoverable data loss occurs if a working drive is removed when trying to remove a failed drive. It is strongly recommended to mark the physical connections of all SATA disk drives. Drive locations can be identified by attaching stickers to the drive bays. If a drive member of a RAID array should fail, the failed drive can then be correctly identified.

---

**CAUTION!**

Do not accidentally disconnect the SATA drive cables. Carefully route the cables within the chassis to avoid system down time.

## E.2 Features and Benefits

- Supports RAID levels 0, 1, 5 and 10
- Supports connectivity to two or more disk drives
- Supported Operating Systems include: Windows XP, Windows Server 2003 and Windows Vista

## E.3 Accessing the Intel® Matrix Storage Manager

To access the Intel® Matrix Storage Manager, please follow the steps below.

**Step 1: Connect SATA drives to the system.** Connect two or more SATA drives to the system. Make sure the drives have the same capacity, are the same type and have the same speed.

**NOTE:**

Make sure the SATA drives are EXACTLY the same when they are configured in a RAID configuration. If they are not the same size, disk drive capacity is sacrificed and overall performance affected.

**Step 2: Enable SATA drives in BIOS.** Start the computer and access the BIOS setup program. Enable RAID support for all SATA devices. Refer to the applicable BIOS configuration section in this user manual.

**Step 3: Configure “Option ROM Messages” BIOS option to Force BIOS.** This is to allow the “Press <CTRL+I> to enter Configuration Utility.....” message to appear during the POST.



## IMBA-XQ354S Motherboard

- Step 4: Save and Exit BIOS.** After the SATA support option is enabled, save and exit the BIOS.
- Step 5: Reboot the system.** Reboot the system after saving and exiting the BIOS.
- Step 6: Press Ctrl+I. during the system boot process,** press Ctrl+I when prompted to enter the RAID configuration software.
- Step 7: Configure the RAID settings.** Use the Intel® Matrix Storage Manager to configure the RAID array. Brief descriptions of configuration options are given below.

### E.4 Installing the Operating System to the RAID Array

To install the operating system to the RAID array some extra steps are necessary during the installation process.

- Step 1: Prepare a RAID driver floppy disk on another computer.** If installing on the RAID array a RAID driver floppy disk must be made. The RAID driver floppy disk utility is on the CD in the “5-SATA/Floppy Configuration Utility” folder. The floppy disk will be formatted and the drivers installed.
- Step 2: Restart the system with a floppy drive attached.** Attach a normal floppy drive or USB floppy drive to the system.
- Step 3: Press F6 when prompted.** During the installation process, Windows OS prompts the user to press F6 to install the RAID drivers. Press F6 and choose from the drivers on the floppy disk.
- Step 4: Install the OS.** Continue with OS installation as usual.

Appendix

**F**

# Hazardous Materials Disclosure

---

## **F.1 Hazardous Materials Disclosure Table for IPB Products Certified as RoHS Compliant Under 2002/95/EC Without Mercury**

The details provided in this appendix are to ensure that the product is compliant with the Peoples Republic of China (China) RoHS standards. The table below acknowledges the presences of small quantities of certain materials in the product, and is applicable to China RoHS only.

A label will be placed on each product to indicate the estimated “Environmentally Friendly Use Period” (EFUP). This is an estimate of the number of years that these substances would “not leak out or undergo abrupt change.” This product may contain replaceable sub-assemblies/components which have a shorter EFUP such as batteries and lamps. These components will be separately marked.

Please refer to the table on the next page.

Part Name	Toxic or Hazardous Substances and Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (CR(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
<b>Housing</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Display</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Printed Circuit Board</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Metal Fasteners</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Cable Assembly</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Fan Assembly</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Power Supply Assemblies</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
<b>Battery</b>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

O: This toxic or hazardous substance is contained in all of the homogeneous materials for the part is below the limit requirement in SJ/T11363-2006

X: This toxic or hazardous substance is contained in at least one of the homogeneous materials for this part is above the limit requirement in SJ/T11363-2006

## IMBA-XQ354S Motherboard

此附件旨在确保本产品符合中国 RoHS 标准。以下表格标示此产品中某有毒物质的含量符合中国 RoHS 标准规定的限量要求。

本产品上会附有“环境友好使用期限”的标签，此期限是估算这些物质“不会有泄漏或突变”的年限。本产品可能包含有较短的环境友好使用期限的可替换元件，像是电池或灯管，这些元件将会单独标示出来。

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (CR(VI))	多溴联苯 (PBB)	多溴二苯 醚 (PBDE)
壳体	○	○	○	○	○	○
显示	○	○	○	○	○	○
印刷电路板	○	○	○	○	○	○
金属螺帽	○	○	○	○	○	○
电缆组装	○	○	○	○	○	○
风扇组装	○	○	○	○	○	○
电力供应组装	○	○	○	○	○	○
电池	○	○	○	○	○	○

○: 表示该有毒有害物质在该部件所有物质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。  
X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T11363-2006 标准规定的限量要求。