

UR35

Industrial Cellular Router Quick Start Guide



Ursalink Technology Co., Ltd.

Welcome

Thank you for choosing Ursalink UR35 industrial cellular router.

This guide describes how to install the UR35 and how to log in the Web GUI to configure the device. Once you complete the installation, refer to the Ursalink UR35 User Guide for instructions on how to perform configurations on the device.

Related Documents

This Start Guide only explains the installation of Ursalink UR35 router. For more functionality and advanced settings, please refer to the relevant documents as below.

Document	Description	
Ursalink UR35 Datasheet	Datasheet for the Ursalink UR35 industrial cellular router.	
Urgaliak UD228UD25 Ugar Cuida	Users could refer to the guide for instruction on how to log in the	
Ursainik UK32&UK35 User Guide	web GUI, and how to configure all the settings.	

The related documents are available on Ursalink website: <u>http://www.ursalink.com</u>.

Declaration of Conformity

UR35 are in conformity with the essential requirements and other relevant provisions of the CE, FCC, and RoHS.





For assistance, please contact Ursalink technical support: Email: support@ursalink.com Tel: 86-592-5023060 Fax: 86-592-5023065



1. Packing List

Before you begin to install the UR35 router, please check the package contents to verify that you have received the items below.

1.1 Package Contents



If any of the above items is missing or damaged, please contact your Ursalink sales representative.



2. Hardware Introduction

2.1 Overview

A. Front Panel



B. Left Side Panel



- ① Wi-Fi Antenna Connector
- ② AUX Antenna Cellular Connector
- ③ GPS Antenna Connector
- (4) MAIN Cellular Antenna Connector
- ⑤ LED Indicator Area
 POWER: Power Indicator
 SYSTEM: Status Indicator
 Wi-Fi: Wi-Fi Indicator
 VPN: VPN Indicator
 SIM : SIM Status Indicator
 ▼: Signal Strength Indicator
- 6 Ethernet Port & Indicator

- Grounding Stud
- 8 SIM and Reset Button Holder
- 9 Power Connector
- ① Serial Port & I/O

2.2 Dimensions (mm)









2.3 Pinouts

PIN	RS232	RS485	DI	DO	Description
1			IN		Digital Input
2	GND		GND		Ground
3		В			Data -
4	TXD				Transmit Data
5				СОМ	Common Ground
6				OUT	Digital Output
7		А			Data +
8	RXD				Receive Data

Description

Positive Negative

PIN	
9	
10	

2.4 LED Indicators

1 2 3 4 5 6 7 8

V+ V-

0 0

LED	Indication	Status	Description				
	Devuer Status	Off	The power is switched off				
POWER	Power Status	On	The power is switched on				
		Creare Links	Static: Start-up				
SYSTEM	System Status	Green Light	Blinking slowly: the system is running properly				
		Red Light	The system goes wrong				
		Off	VPN is disconnected				
VPN	VPN Status	Green Light	VPN is connected				
		Off	Wi-Fi is disabled				
Wi-Fi	Wi-Fi Status		Static: Wi-Fi is enabled				
		Green Light	Blinking slowly: sending or receiving data via Wi-Fi				
		Off	SIM1 or SIM2 is registering or fails to register (or there are				
		OII	no SIM cards inserted)				
			Blinking slowly: SIM1 (as primary SIM) has been registered				
			and is ready for dial-up				
		Croop Light	Blinking rapidly: SIM1(as primary SIM) has been registered				
CINA	SIM Card Status	Green Light	and is dialing up now				
31111	Silvi Caru Status		Static: SIM1 (as primary SIM) has been registered and				
			dialed up successfully				
			Blinking slowly: SIM2 (as primary SIM) has been registered				
		Orange	and is ready for dial-up				
		Light	Blinking rapidly: SIM2 (as primary SIM) 9has been				
			registered and is dialing up now				



			Static: SIM2 (as primary SIM) has been registered and dialed up successfully
		Off	No signal
Signal	Size 1 1 /2 /2		Static/Off/Off: weak signals with 1-10 ASU (please check if the antenna is installed correctly, or move the antenna to a suitable location to get better signal)
Strength	Signal 1/2/3	Green Light	Static/Static/Off: normal signals with 11-20 ASU (average signal strength)
			Static/Static/Static: strong signals with 21-31 ASU (signal is good)

2.5 Reset Button

Eurotion	Description	
Function	SYSTEM LED	Action
Pohoot	Blinking	Press and hold the reset button for about 5-15 seconds.
Reboot Static Green Release the		Release the button and wait for system to reboot.
Blinking Static Green →		Press and hold the reset button for more than 15 seconds.
		Release the button and wait.
Reset	Rapidly Blinking	
$Off \rightarrow Blinking$		The router is now reset to factory defaults.

2.6 Ethernet Port Indicator

Indicator	Status	Description
	On	Connected
Link Indicator (Orange)	Blinking	Transmitting data
	Off	Disconnected



3. Hardware Installation

Environmental Requirements

- Power Input: 9-48 VDC
- Power Consumption: Typical 3.9 W, Max 4.6 W
- Operating Temperature: -40°C to 70°C (-40°F -158°F)
- Relative Humidity: 0% to 95% (non-condensing) at 25°C/77°F

3.1 SIM Card/Micro SD Card Installation



UR35 do not support hot-plug. Please cut off the power before insert or take off cards.

- A. Unscrew the cover of the SIM card/Micro SD then insert the card then take it off.
- B. Put SIM card/Micro SD card into the slot and screw it up.





3.2 Antenna Installation

Rotate the antenna into the antenna connector accordingly.

The external antenna should be installed vertically always on a site with a good signal.





3.3 Connect the Router to a Computer

Please connect PC to any port among LAN1-LAN4 of UR35 router directly.



3.4 Mount the Router

The router can be placed on a desktop or mounted to a wall or a DIN rail.

3.4.1 Wall Mounting (Measured in mm)

Use 2 pcs of M3 \times 6 flat head Phillips screws to fix the wall mounting kit to the router, and then use 2 pcs of M3 drywall screws to mount the router associated with the wall mounting kit on the wall.

Recommended torque for mounting is 1.0 N·m, and the maximum allowed is 1.2 N·m.



3.4.2 DIN Rail Mounting (Measured in mm)

Use 2 pcs of M3 \times 6 flat head Phillips screws to fix the DIN rail to the router, and then hang the DIN rail on the mounting bracket. It is necessary to choose a standard bracket.



Recommended torque for mounting is 1.0 N·m, and the maximum allowed is 1.2 N·m.





3.5 Power Supply Installation

- A. Take out the terminal from the router and unscrew the bolt on terminal.
- B. Screw down the bolt after inserting power cable into the terminal.



Connecting the Power Cable

Color	Polarity
Red	+
Yellow	-

If you insert wires into the reverse holes, the router will not start and you must switch the wires into the correct holes.

3.6 Protective Grounding Installation

A. Remove the grounding nut.

B. Connect the grounding ring of the cabinet's grounding wire onto the grounding stud and screw up the grounding nut.





The router must be grounded when deployed. According to operating environment, the ground wire should be connected with grounding stud of router.



Getting Started

4. PC Configuration for Web GUI Accessing to Router

Please connect PC to any port among LAN1-LAN4 of UR35 router directly. PC can obtain an IP address, or you can configure a static IP address manually. The following steps are based on Windows 10 operating system for your reference.

(Note: As remote access is disabled by default, you can't access to the router's Web GUI if you connect PC to WAN port of the router. But it will function properly if you enable it on the Web GUI.)



ightarrow ~ ightarrow ~ ightarrow ighta	and Internet > Network and Sharing Center	✓ ♂ Search Control Panel		
Control Panel Home	View your basic network information	and set up connections	General	
hange adapter settings	View your active networks	Access human Internet	Connection IPv4 Connectivity:	No network access
hange advanced sharing ettings	Yeastar5G Private network	HomeGroup: Ready to create Connections: all Wi-Fi (Yeastar5G)	IPv6 Connectivity:	No network access
			Duration:	00:01:21
	Identifying	Access type: No network access Connections: Ethernet	Speed:	1.0 Gbps
	Change your networking settings		Details	
	Set up a new connection or network Set up a broadband, dial-up, or VPN co	nnection; Ethernet	Activity	
	Troubleshoot problems	or get troubleshapting information.	t	Received
		,	Properties 210	
ee also				
HomeGroup Infrared			Properties Disable	Diagnose
nternet Options Vindows Firewall				Close
Clink (Tth	ornot" (May bayo o	lifforant namos)	(A) Click "Proper	tios"

Ursalink UR35 Quick Start Guide



Ethernet Properties X	Internet Protocol Version 4 (TCP/IPv4) Properties	Internet Protocol Version 4 (TCP/IPv4) Properties
Networking Sharing	General Alternate Configuration	General
Connect using:	You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.	You can get IP settings assigned this capability. Otherwise, you n for the appropriate IP settings. 192.168.1.20 ts
Configure	Obtain an IP address automatically	Obtain an IP address autor 192.168. 1.1
Genetic assure for only tense	Use the following IP address: IP address:	Use the following IP address: IP address: 192 . 168 . 1 . 20
 ☑	Subnet mask:	Subnet mask: 255 . 255 . 255 . 0
Internet Protocol Version 4 (TCP/IPv4)	Obtain DNS server address automatically	Obtain DNS server address automatically
	Use the following DNS server addresses:	Use the following DNS server addresses:
Install Uninstall Properties	Preferred DNS server:	Preferred DNS server: 192 . 168 . 1 . 1
Description Transmission Control Protocol/Internet Protocol. The default	Alternate DNS server:	Alternate DNS server:
wide area network protocol that provides communication across diverse interconnected networks.	Validate settings upon exit Advanced	□Validate settings upon exit 192.168.1.1
OK Cancel	OK Cancel	OK Cancel

- 5) Double Click "Internet Protocol Version 4 (TCP/IPv4)" to configure IP address and DNS server.
- 6 Method 1: click "Obtain an IP address automatically";

Method 2: click "Use the following IP address" to assign a static IP manually within the same subnet of the router.

(Note: Remember to click "OK" to finish configuration.)



5. Access to Web GUI of Router for Cellular Connection

This chapter explains how to log in UR35 router's Web GUI, and connect the router to cellular network. Ursalink router provides Web-based configuration interface for management. If this is the first time you configure the router, please use the default settings below:

IP Address: **192.168.1.1** Username: **admin** Password: **password**

5.1 To Log in the Router



A. Start a Web browser on your PC (Chrome and IE are recommended), type in the IP address, and press Enter on your keyboard.

B. Enter the username and password, click "Login".

♥ URSALINK × +				-		×
\leftarrow \rightarrow O 192.168.1.1/login.html		□ ☆	=	Ø	٥	
192.168.1.1		English				
	VRSALINK					
	Sername					
	Password					
	Login					

If you enter the username or password incorrectly more than 5 times, the login page will be locked for 10 minutes.

C. When you log in with the default username and password, you will be asked to modify the password. It's suggested that you change the password for the sake of security. Click "Cancel" button if you want to modify it later.

e.luligo i uconoru	
Old Password	
New Password	
Confirm New Password	



D. After you log in the Web GUI, you can view system information and perform configuration on the router.

	For your device security, please change the default password!											
Status		Overview	Cellular	Network	WLAN	VPN	Routing	Host List	GPS			
Network	•	System Information										
		Model		UR35	UR35							
System	Partnumber			L00E-W22-S1111-GPS-P								
		Serial Number		621992583655	621992583655							
muusua		MAC	24:E1:24:F0:32	24:E1:24:F0:32:8A								
Maintenance	×	Firmware Version	1	35.1.0.13	35.1.0.13							
		Hardware Version	n	V1.0	V1.0							
		Local Time		2019-07-18 15	2019-07-18 15:02:16 Thursday							
		Uptime		00:01:54	00:01:54							
		CPU Load		17%								
		RAM (Capacity/A	vailable)	128MB/68MB(53.13%)							
		Flash (Capacity/A	Available)	128MB/91MB(71.09%)							

5.2 Configure the Cellular Connection

Take inserting SIM card into SIM1 slot as an example; please refer to the following detailed operations.

- A. Click "Network" \rightarrow "Interface" \rightarrow "Cellular" \rightarrow "Cellular Setting" to configure the cellular info.
- B. Enable SIM1.
- C. Choose relevant network type. "Auto", "4G First", "4G Only", "3G First", "3G Only", "2G First" and "2G Only" are optional.
- D. Click "Save" and "Apply" for configuration to take effect.

Status	Port	WAN	LAN	WLAN C	ellular (2) Cellular		
Network 👻	Cellular Set	ting	SIM1		SIM2		
Interface	Enable				v		
Firewall 1 Interface	Network Type	è	Auto	•	Auto 🔻		
QoS	APN		4G First 4G Only				
DHCP	Username		3G First 3G Only	(3)"Auto	o" or others		
	Password		2G First 2G Only				
DDNS	Access Num	ber					
Link Failover	PIN Code						
Routing	Authenticatio	n Type	Auto	•	Auto v		
	Roaming						



				Apply			
Status	Port WAN	LAN WLAN	Cellular	Loopbac 5 Apply			
	Cellular Setting						
Network 🔻		SIM1	SIM2	SIM2			
Interface	Enable	e					
Firewall	Network Type	Auto	▼ Auto	T			
0.05	APN						
	Username						
DHCP	Password						
DDNS	Access Number						
Link Failover	PIN Code						
Deutier	Authentication Type	Auto	▼ Auto	Ŧ			
Rouing	Roaming						
VPN	SMS Center						
System 🕨	Connection Setting						
	Dual SIM Strategy						
Industrial 🕨 🕨	Enable NAT	Image: A start of the start					
	ICMP Server	8.8.8.8					
Maintenance	Secondary ICMP Server	114.114.114.114					
	PING Times	5					
APP 🕨	Packet Loss Rate	20	%				
	SMS Settings						
	(4) Save	PDU	•				
	Caut						
	Save						

If you select "Auto", the router will obtain ISP information from SIM card to set APN, Username, and Password automatically. This option will only be taken effect when the SIM card is issued from a well-known ISP.

If you select "4G First" or "4G Only", you can click "Save" to finish the configuration directly.

If you select "3G First", "3G Only", "2G First" or "2G Only", you should manually configure APN, Username, Password, and Access Number.

UR35 routers have two cellular interfaces, named SIM1 & SIM2. Only one cellular interface is active at one time. If both cellular interfaces are enabled, SIM1 interface takes precedence by default.



5.3 Check the Cellular Connection Status

5.3.1 Check the Cellular Connection Ctatus by Web GUI of Router

Click "Status" \rightarrow "Cellular" to view the status of the cellular connection. If it shows "Connected", it means SIM1 has dialed up successfully.

URSAL	INK												
Status		Overview	Cellular	Network	WLAN	VPN	Routing	Host List	GPS				
Network	•	Modem											
		Status		Ready									
System	•	Model		U9300C									
Industrial		Current SIM		SIM1									
mustia		Signal Level		29asu (-56dBm)									
Maintenance	•	Register Status		Registered (Hom	ie network)								
		IMSI		46007061521924	460070615219248								
APP	•	ICCID		898602E6131532	2019248								
		ISP		CHINA MOBILE									
		Network Type		LTE									
		PLMN ID		46007									
		LAC		fffe									
		Cell ID		f700e28									
		IMEI		86280803245998	87								
		Network											
		Hetwork			ſ								
		Status		Connected <	Connect	ted							
		IP Address		10.39.128.14									
		Netmask		255.255.255.252									
		Gateway		10.39.128.13									
		DNS		211.143.147.120									
		Connection Duration		0 days, 00:15:35				Manual Refresh 🔻	Refresh				

5.3.2 Check the Cellular Connection Status by Hardware

On the other hand, you can check the status of SIM indicator. If it keeps on green light statically, it means SIM1 has dialed up successfully.

5.4 Check out if Network Works Properly by Browser on PC

Open your preferred browser on PC, then type any available web address into address bar and see if it is able to visit Internet via UR35 router.

[END]