

# mITX-H610A (MH610AI-SI)

---

mITX-H610A Mini-ITX Motherboard

User's Manual 1st Ed

## Copyright Notice

---

This document is copyrighted, 2022. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, or for any infringements upon the rights of third parties that may result from its use.

The material in this document is for product information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, GIGAIPC assumes no liabilities resulting from errors or omissions in this document, or from the use of the information contained herein.

GIGAIPC reserves the right to make changes in the product design without notice to its users.

## Acknowledgement

---

All other products' name or trademarks are properties of their respective owners.

- Microsoft Windows is a registered trademark of Microsoft Corp.
- Intel, Pentium, Celeron, and Xeon are registered trademarks of Intel Corporation
- Core, Atom are trademarks of Intel Corporation
- ITE is a trademark of Integrated Technology Express, Inc.
- IBM, PC/AT, PS/2, and VGA are trademarks of International Business Machines Corporation.

All other product names or trademarks are properties of their respective owners.

## Packing List

---

Before setting up your product, please make sure the following items have been shipped:

Item	Quantity
mITX-H610A MB	1
SATA power cable	1
I/O Shield	1

If any of these items are missing or damaged, please contact your distributor or sales representative immediately.

## About this Document

---

This User's Manual contains all the essential information, such as detailed descriptions and explanations on the product's hardware and software features (if any), its specifications, dimensions, jumper/connector settings/definitions, and driver installation instructions (if any), to facilitate users in setting up their product.

Users may refer to the [GIGAIPC.com](http://GIGAIPC.com) for the latest version of this document.

## Safety Precautions

---

Please read the following safety instructions carefully. It is advised that you keep this manual for future references

1. All cautions and warnings on the device should be noted.
2. Make sure the power source matches the power rating of the device.
3. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
4. Always completely disconnect the power before working on the system's hardware.
5. No connections should be made when the system is powered as a sudden rush of power may damage sensitive electronic components.
6. If the device is not to be used for a long time, disconnect it from the power supply to avoid damage by transient over-voltage.
7. Always disconnect this device from any AC supply before cleaning.
8. While cleaning, use a damp cloth instead of liquid or spray detergents.
9. Make sure the device is installed near a power outlet and is easily accessible.
10. Keep this device away from humidity.
11. Place the device on a solid surface during installation to prevent falls
12. Do not cover the openings on the device to ensure optimal heat dissipation.

13. Watch out for high temperatures when the system is running.
14. Do not touch the heat sink or heat spreader when the system is running
15. Never pour any liquid into the openings. This could cause fire or electric shock.
16. As most electronic components are sensitive to static electrical charge, be sure to ground yourself to prevent static charge when installing the internal components. Use a grounding wrist strap and contain all electronic components in any static-shielded containers.
17. If any of the following situations arises, please the contact our service personnel:
  - i. Damaged power cord or plug
  - ii. Liquid intrusion to the device
  - iii. Exposure to moisture
  - iv. Device is not working as expected or in a manner as described in this manual
  - v. The device is dropped or damaged
  - vi. Any obvious signs of damage displayed on the device
18. **DO NOT LEAVE THIS DEVICE IN AN UNCONTROLLED ENVIRONMENT WITH TEMPERATURES BEYOND THE DEVICE'S PERMITTED STORAGE TEMPERATURES (SEE CHAPTER 1) TO PREVENT DAMAGE.**

## FCC Statement

---

### **Warning!**



This device complies with Part 15 FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

### **Caution:**

*There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions and your local government's recycling or disposal directives.*

### **Attention:**

*Il y a un risque d'explosion si la batterie est remplacée de façon incorrecte. Ne la remplacer qu'avec le même modèle ou équivalent recommandé par le constructeur. Recycler les batteries usées en accord avec les instructions du fabricant et les directives gouvernementales de recyclage.*



## China RoHS Requirements (CN)

产品中有毒有害物质或元素名称及含量

GIGAIPC Main Board/ Daughter Board/ Backplane

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板 及其电 子组件	○	○	○	○	○	○
外部信号 连接器 及线材	○	○	○	○	○	○

○: 表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T 11363-2006 标准规定的限量要求以下。  
 X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求。  
 备注: 此产品所标示之环保使用期限, 系指在一般正常使用状况下。

# China RoHS Requirement (EN)

## Poisonous or Hazardous Substances or Elements in Products GIGAIPC Main Board/ Daughter Board/ Backplane

Component	Poisonous or Hazardous Substances or Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
PCB & Other Components	○	○	○	○	○	○
Wires & Connectors for External Connections	○	○	○	○	○	○
<p>○ : The quantity of poisonous or hazardous substances or elements found in each of the component's parts is below the SJ/T 11363-2006-stipulated requirement.</p> <p>X: The quantity of poisonous or hazardous substances or elements found in at least one of the component's parts is beyond the SJ/T 11363-2006-stipulated requirement.</p> <p>Note: The Environment Friendly Use Period as labeled on this product is applicable under normal usage only</p>						

## Table Contents

<b>mITX-H610A Mini-ITX Motherboard User's Manual 1st Ed</b>	<b>1</b>
Copyright Notice .....	2
Acknowledgement .....	3
Packing List.....	4
About this Document .....	5
Safety Precautions .....	6
FCC Statement.....	8
China RoHS Requirements (CN).....	9
China RoHS Requirement (EN) .....	10
<b>Chapter 1 - Product Specifications</b>	<b>14</b>
1.1 Specifications .....	16
<b>Chapter 2 – Hardware Information</b>	<b>18</b>
2.1 Jumpers and Connectors .....	19
2.2.1 IO Connector Information.....	22
2.2.2 DC_IN1 (DC In Jack 4 Pin Din) .....	23
2.2.3 DC_IN2 (ATX 2x2 Pin Power Connector).....	24
2.2.4 VGA (VGA Port) .....	25
2.2.5 COM1 (COM1 Port (RS-232/422/485 & RI/5V/12V)) ....	26
2.2.6 HDMI_DP (HDMI + DP Connector) .....	27
2.2.7 USB32_LAN1 (USB + GbE LAN Connector) .....	28
2.2.8 USB32_LAN2 (USB + 2.5GbE LAN Connector) .....	29
2.2.9 CPU Socket (LGA 1700 Socket) .....	30

2.2.10	LVDS (LVDS Connector) .....	31
2.2.11	COM2 (COM2 header (RS-232)) .....	32
2.2.12	SYS_FAN (System Fan Connector) .....	33
2.2.13	GPIO_CNT (General purpose input/out header).....	34
2.2.14	BUZZER (Buzzer header) .....	35
2.2.15	SATA_PWR (SATA Power Connector) .....	36
2.2.16	SATA4, SATA5 (SATA 6Gb/s Connector).....	37
2.2.17	SYS_PANEL (System Panel header) .....	38
2.2.18	CLR_CMOS (Clear CMOS jumper) .....	39
2.2.19	FUSB2_1, FUSB2_2 (USB 2.0 header).....	40
2.2.20	SODIMM1, SODIMM2 (2 x DDR4 SO-DIMM Sockets) ...	41
2.2.21	CPU_FAN (CPU FAN Connector) .....	42
2.2.22	PCIEX16 (1 x PCIe x16 (Gen4 x16 Bus) Slot) .....	43
2.2.23	SPKR (Speaker Out Connector) .....	44
2.2.24	FP_AUDIO (Front Panel Audio header) .....	45
2.2.25	Battery (Battery Connector) .....	46
2.2.26	JCOM1 (RI# pin RI#/5V/12V Select jumper for COM1 Port) .....	47
2.2.27	TPM (TPM header).....	48
2.2.28	BKL_CN (Backlight Control Connector) .....	49
2.2.29	AT_CN (AT/ATX mode select jumper).....	50
2.2.30	M2E (M.2 Slot, 2230 E-Key) .....	51
2.2.31	M2M (M.2 Slot, 2280 M-Key) .....	52

## Chapter 3 – BIOS 53




3.1	Introduction .....	54
-----	--------------------	----

3.2	The Main Menu.....	55
3.3	Advanced .....	56
3.3.1	TPM Configuration.....	57
3.3.2	CPU Configuration .....	59
3.3.3	SATA Configuration .....	60
3.3.4	IT8786 Super IO Configuration .....	61
3.3.5	Hardware Monitor .....	62
3.3.6	S5 RTC Wake Settings .....	63
3.3.7	AMI Graphic Output Protocol Policy.....	64
3.3.8	Network Stack Configuration.....	65
3.3.9	NVMe Configuration.....	66
3.3.10	Offboard SATA Controller Configuration .....	67
3.3.11	Digital IO Port Configuration .....	68
3.3.12	TIs Auth Configuration .....	69
3.4	Chipset .....	70
3.5	Security .....	72
3.6	Boot.....	75
3.7	Save & Exit .....	76

# Chapter 1

---

## Chapter 1 - Product Specifications



## 1.1 Specifications

Motherboard	mITX-H610A (MH610AI-SI)
Form Factor	Mini-ITX 170W x 170D (mm)
CPU	Support for 13th/12th Generation Intel® Core™ i9/ i7/ i5/ i3, Pentium® and Celeron® processors in the LGA1700 package TDP under 65W
Socket	1 x LGA 1700
Chipset	Intel® H610 Chipset
Memory	2 x DDR4 SO-DIMM sockets, Max. Capacity 64 GB Support Dual channel DDR4 3200 MHz memory modules
Ethernet	1 x GbE LAN Port (Intel® I219V) 1 x 2.5GbE LAN Port (Intel® I226V)
Video	Integrated Graphics Processor - depends on CPU: 1 x HDMI 2.0 port, supporting a maximum resolution of 4096x2160 @60Hz 1 x DP port, supporting a maximum resolution of 4096x2160 @60Hz 1 x VGA port, supporting a maximum resolution of 1920x1200 @60Hz 1 x LVDS port, supporting a maximum resolution of 1920x1200 @60Hz  (3 independent display outputs)
Audio	Realtek® Audio codec
Storage	2 x SATA 6Gb/s Ports
Expansion Slots	1 x PCIe x16 (Gen4 x16) 1 x 2280 M.2 M-Key (PCIe x4) 1 x 2230 M.2 E-Key (WiFi/BT)
Internal I/O	1 x 4-pin ATX main power connector 2 x SATA power connectors 1 x CPU fan header 1 x System fan header 1 x Front panel header 1 x Front panel audio header 1 x 2W Speaker out header 4 x USB 2.0 headers 1 x COM header (RS-232) 1 x GPIO (8 bits) & SMBus header 1 x Backlight Control header 1 x Clear CMOS jumper 1 x Buzzer header 1 x AT/ATX mode select jumper




Motherboard	mITX-H610A (MH610AI-SI)
Rear I/O	2 x Audio Jacks (Line out, Mic in) 1 x COM Port (RS-232/422/485 & RI/5V/12V) 1 x HDMI 1 x Display Port 1 x D-Sub 2 x RJ45 LAN Ports 4 x USB 3.2 Gen 1 1 x DC Jack (+12V/+19V~+24VDC)
TPM	1 x TPM header
OS Compatibility	Windows® 10/11 (x64)
Operating Properties	Operating temperature: 0°C to 60°C Operating humidity: 0-90% (non-condensing) Non-operating temperature: -40°C to 85°C Non-operating humidity: 0%-95% (non-condensing)
Order Information	Motherboard: 9MH610AIMR-SI
Optional kit:	CPU Cooler : 25ST0-037820-Y0R CPU Cooler Backplate : 12KRH-0A1700-00R TPM 2.0 module: 9CTM010NR-00


# Chapter 2

---

## Chapter 2 – Hardware Information

## 2.1 Jumpers and Connectors






No	Code	Description
1	DC_IN1	DC In Jack 4 pin Din
2	DC_IN2	ATX 2x2 pin power Connector
3	VGA	VGA Port
4	COM1	COM1 Port (RS-232/422/485 & RI/5V/12V)
5	HDMI_DP	HDMI Connector
6		Display Port Connector
7	USB32_LAN1	USB 3.2 Gen 1 Connector
8		GbE LAN port
9	USB32_LAN2	USB 3.2 Gen 1 Connector
10		2.5GbE LAN port
11	MIC_IN	Mic In port (Pink)
12	LINE_OUT	Line out port (Green)
13	CPU Socket	1 x LGA 1700 Socket

No	Code	Description
14	LVDS	LVDS Connector
15	COM2	COM2 header (RS-232)
16	SYS_FAN	System Fan Connector
17	GPIO_CNT	General purpose input/output header
18	BUZZER	Buzzer header
19	SATA_PWR	SATA Power Connector
20	SATA4, SATA5	SATA 6Gb/s Connector x 2
21	SYS_PANEL	System Panel header
22	CLR_CMOS	Clear CMOS jumper
23	FUSB2_1 FUSB2_2	USB 2.0 header
24	SODIMM1, SODIMM2	2 x DDR4 SO-DIMM Sockets
25	CPU_FAN	CPU FAN Connector
26	PCIEX16	1 x PCIe x16 (Gen4 x16 bus) slot
27	SPKR	Speaker out Connector
28	FP_AUDIO	Front Panel Audio header
29	BATTERY	Battery Connector
30	JCOM1	RI# pin RI#/5V/12V Select jumper for COM1 port
31	TPM	TPM header
32	BKL_CN	Backlight Control connector
33	AT_CN	AT/ATX mode select jumper
34	M2E	M.2 Slot, 2230 E-Key
35	M2M	M.2 Slot, 2280 M-Key


## 2.2.1 IO Connector Information




	Code	Description
1	DC_IN1	DC In Jack 4 pin Din
2	VGA	VGA Port
3	COM1	COM1 Port (RS-232/422/485 & RI/5V/12V)
4	HDMI_DP	HDMI Connector
5		Display Port Connector
6	USB32_LAN1	USB 3.2 Gen 1 Connector
7		GbE LAN port
8	USB32_LAN2	USB 3.2 Gen 1 Connector
9		2.5GbE LAN port
10	MIC_IN	Mic In port (Pink)
11	LINE_OUT	Line out port (Green)

## 2.2.2 DC\_IN1 (DC In Jack 4 Pin Din)

1



DC In Jack 4 Pin Din



Connector PN


2MJ-3422A1I0

Vendor


SINGATRON

## 2.2.3 DC\_IN2 (ATX 2x2 Pin Power Connector)

2



Power Connector



Connector PN

740-81-04TW56

Vendor



PINREX

Pin No.	Definition
1	GND
2	GND
3	DC IN
4	DC IN



## 2.2.4 VGA (VGA Port)

3





Connector PN	Vendor
DZ11AA1-H5A7-4F	FOXCONN
D11015S021126N	FENYING

Pin No.	Definition	Pin No.	Definition
1	Red	9	5V
2	Green	10	GND
3	Blue	11	NC
4	NC	12	DDCSDA
5	GND	13	HSYNC
6	GND	14	VSYNC
7	GND	15	DDCSCL
8	GND		

## 2.2.5 COM1 (COM1 Port (RS-232/422/485 & RI/5V/12V))

4




Connector PN	Vendor
DM10151-N5W3-4F	FOXCONN


Pin No.	RS-232	RS-422 Full Duplex	RS-485 Half Duplex
1	DCD	TXD-	D-
2	RXD	TXD+	D+
3	TXD	RXD+	-
4	DTR	RXD-	-
5	GND		
6	DSR	-	-
7	RTS	-	-
8	CTS	-	-
9	RI	-	-

## 2.2.6 HDMI\_DP (HDMI + DP Connector)

5 6



HDMI & DP Connector




HDMI Connector			
Pin No.	Definition	Pin No.	Definition
1	TX2p	11	GND
2	GND	12	CLKn
3	TX2n	13	NC
4	TX1p	14	NC
5	GND	15	SCL
6	TX1n	16	SDA
7	TX0p	17	GND
8	GND	18	5V
9	TX0n	19	Hot Plug Detect
10	CLKp		


DP Connector			
Pin No.	Definition	Pin No.	Definition
1	TX0p	11	GND
2	GND	12	TX3n
3	TX0n	13	GND
4	TX1p	14	GND
5	GND	15	AUXp
6	TX1n	16	GND
7	TX2p	17	AUXn
8	GND	18	Hot Plug Detect
9	TX2n	19	3.3V
10	TX3p	20	3.3V

## 2.2.7 USB32\_LAN1 (USB + GbE LAN Connector)

7 8



USB & LAN Connector



USB Connector			
Pin No.	Definition	Pin No.	Definition
1	5V	10	5V
2	D1n	11	D0n
3	D1p	12	D0p
4	GND	13	GND
5	USB3_RX1n	14	USB3_RX2n
6	USB3_RX1p	15	USB3_RX2p
7	GND	16	GND
8	USB3_TX1n	17	USB3_TX2n
9	USB3_TX1p	18	USB3_TX2p


LAN Connector			
Pin No.	Definition	Pin No.	Definition
1	TX1+	4	TX3+
2	TX1-	5	TX3-
3	TX2+	7	TX4+
6	TX2-	8	TX4-


State	Description
Orange On	1Gbps data rate
Green On	100Mbps data rate
Off	10Mbps data rate

## 2.2.8 USB32\_LAN2 (USB + 2.5GbE LAN Connector)

9 10



### USB & LAN Connector



USB Connector			
Pin No.	Definition	Pin No.	Definition
1	5V	10	5V
2	D1n	11	D0n
3	D1p	12	D0p
4	GND	13	GND
5	USB3_RX1n	14	USB3_RX2n
6	USB3_RX1p	15	USB3_RX2p
7	GND	16	GND
8	USB3_TX1n	17	USB3_TX2n
9	USB3_TX1p	18	USB3_TX2p


LAN Connector			
Pin No.	Definition	Pin No.	Definition
1	TX1+	4	TX3+
2	TX1-	5	TX3-
3	TX2+	7	TX4+
6	TX2-	8	TX4-

State	Description
Orange On	2.5Gbps data rate
Green On	1Gbps data rate
Off	100M&10Mbps data rate



## 2.2.9 CPU Socket (LGA 1700 Socket)

13



## 2.2.10 LVDS (LVDS Connector)

14



Pin No.	Definition	Pin No.	Definition
1	3.3V	21	A5+
2	5V	22	A4+
3	3.3V	23	A5-
4	5V	24	A4-
5	SPECO	25	GND
6	SPEDO	26	GND
7	GND	27	A7+
8	GND	28	A6+
9	A1+	29	A7-
10	A0+	30	A6-
11	A1-	31	GND
12	A0-	32	GND
13	GND	33	CLK2+
14	GND	34	CLK1+
15	A3+	35	CLK2-

Pin No.	Definition	Pin No.	Definition
16	A2+	36	CLK1-
17	A3-	37	GND
18	A2-	38	GND
19	GND	39	12V
20	GND	40	12V


Connector PN	Vendor
712-76-40GWE0	PINREX
A1252WV-SF-2X20PD01	JOINT-TECH

For each model support LVDS function.  
But below model no need to add.  
A0~A3 is odd channel 0~3, A4~A7 is even channel.


**Note:** \*The LVDS output connector of the unit is only intended to be connected to an UL/IEC/EN approval equipment with fire enclosure.

## 2.2.11 COM2 (COM2 header (RS-232))

15



COM 2 header



Connector PN

725-81-10TW00

Vendor

PINREX

A2004WV-2X05P46

JOINT-TECH



Pin No.	Definition
1	RXD
2	DCD
3	DTR
4	TXD
5	DSR
6	GND
7	CTS
8	RTS
9	No connect
10	RI

Pin No.	Definition
1	RXD
2	DCD
3	DTR
4	TXD
5	DSR
6	GND
7	CTS
8	RTS
9	No connect
10	RI



## 2.2.12 SYS\_FAN (System Fan Connector)

16




Connector PN	Vendor
744-81-045R11	PINREX


Pin No.	Definition
1	GND
2	12V
3	Detect
4	Speed Control

## 2.2.13 GPIO\_CNT (General purpose input/out header)

17



GPIO Connector




Pin No.	Definition
9	SMBus Clock
10	SMBus DATA
11	5V
12	GND


Pin No.	Definition
1	GPIO-output_1
2	GPIO-input_1
3	GPIO-output_2
4	GPIO-input_2
5	GPIO-output_3
6	GPIO-input_3
7	GPIO-output_4
8	GPIO-input_4

Connector PN	Vendor
725-81-12TW00	PINREX
A2004WV-2X06P46	JOINT-TECH

## 2.2.14 BUZZER (Buzzer header)

18




Buzzer


Connector PN	Vendor
712-71-02TW01	PINREX
A1250WV-02P	JOINT-TECH


Pin No.	Definition
1	Buzzer
2	5V

## 2.2.15 SATA\_PWR (SATA Power Connector)

19



SATA Power Connector



Connector PN

743-81-04TW00

Vendor

PINREX



Pin No.

Definition

1	5V
2	GND
3	GND
4	5V

## 2.2.16 SATA4, SATA5 (SATA 6Gb/s Connector)


20



Pin No.	Definition
1	GND
2	TXp
3	TXn
4	GND
5	RXn
6	RXp
7	GND

## 2.2.17 SYS\_PANEL (System Panel header)

21



System Panel Header



Connector PN

210-92-05GW5W


Vendor

PINREX

Pin No.	Definition
1	HD-P
2	MPD-P
3	HD-N
4	MPD-N
5	GND
6	POWER-ON
7	Reset
8	GND
9	Reserved
10	NC

## 2.2.18 CLR\_CMOS (Clear CMOS jumper)

22



Pin 1


Clear CMOS Jumper

Connector PN	Vendor
212-91-03GBE00K	PINREX

Pin No.	Definition
1	NC
2	GND
3	Clear CMOS
1-2 Close: Normal Operator (Default setting)	
2-3 Close: Clear CMOS data	

## 2.2.19 FUSB2\_1, FUSB2\_2 (USB 2.0 header)

23



Pin 1

USB 2.0 Header



Connector PN

210-92-05GB04

Vendor

PINREX

PH10R53BAZ009

HORNGTONG

Pin No.


Definition

1	5V
2	5V
3	D2n
4	D1n
5	D2p
6	D1p
7	GND
8	GND
9	No Pin
10	NC




## 2.2.20 SODIMM1, SODIMM2 (2 x DDR4 SO-DIMM Sockets)

24



## 2.2.21 CPU\_FAN (CPU FAN Connector)

25



CPU Fan Connector



Connector PN

744-81-045W11

Vendor

PINREX



Pin No.

Definition

1	GND
2	12V
3	Detect
4	Speed Control


## 2.2.22 PCIEX16 (1 x PCIe x16 (Gen4 x16 Bus) Slot)

26




## 2.2.23 SPKR (Speaker Out Connector)

27



Speaker Out Connector





Connector PN	Vendor
721-81-045W00	PINREX
A2001WV-04P146	JOINT-TECH

Pin No.	Definition
1	SPEAKER L+
2	SPEAKER L-
3	SPEAKER R-
4	SPEAKER R+

## 2.2.24 FP\_AUDIO (Front Panel Audio header)

28




Connector PN	Vendor
725-81-10TW00	PINREX
A2004WV-2X05P46	JOINT-TECH


Pin No.	Definition	Pin No.	Definition
1	MIC-LEFT	6	GND
2	GND	7	JACKSENCE DETECT
3	MIC-RIGHT	8	NC
4	DETECT	9	LINE-LEFT
5	LINE-RIGHT	10	GND

## 2.2.25 Battery (Battery Connector)

29




**Battery Connector**






Pin No.	Definition
1	3V
2	GND

## 2.2.26 JCOM1 (RI# pin RI#/5V/12V Select jumper for COM1 Port)

30




JCOM1 Jumper Select	
5 6  1 2	1-2 Close: 5V (Power COM)
5 6  1 2	3-4 Close: RI (Stand COM)
5 6  1 2	5-6 Close: 12V (Power COM)

Connector PN	Vendor
210-92-03GB01	PINREX
PH06R53BAZ000	HORNGTONG

## 2.2.27 TPM (TPM header)

31



TPM Module Connector



Pin No.	Definition
1	Clock
2	3.3V
3	Reset
4	3.3V
5	SDO
6	IRQ_SERIAL
7	SDIN
8	NC
9	NC
10	NC
11	NC


Pin No.	Definition
12	GND
13	CS
14	GND

Connector PN	Vendor
52M-90-14GBE7	PINREX
LCB25-I1424S01C-12	LIONCONN




## 2.2.28 BKL\_CN (Backlight Control Connector)

32



**Backlight Control Connector**



**Connector PN**

721-81-05TW00

**Vendor**

PINREX


A2001WV-05P146

JOINT-TECH

Pin No.	Definition
1	5V (12V optional)
2	PWM
3	Backlight enable
4	GND
5	12V

## 2.2.29 AT\_CN (AT/ATX mode select jumper)

33



AT/ATX mode select jumper



Connector PN

220-96-03GB001K  
PH03N2-7BAN000

Vendor

PINREX  
HORNGTONG

Pin No.	Definition
1	AT MODE
2	Detect
3	ATX MODE


Jumper setting

1-2 Close : AT mode.

2-3 Close : ATX mode.(Default setting)

## 2.2.30 M2E (M.2 Slot, 2230 E-Key)

34



**M.2 E Key Connector**



Pin No.	Definition	Pin No.	Definition
1	GND	2	3.3V
3	D1p	4	3.3V
5	D1n	6	NC
7	GND	8	NC
9	NC	10	NC
11	NC	12	NC
13	GND	14	NC
15	NC	16	NC
17	NC	18	GND
19	GND	20	NC
21	NC	22	NC
23	NC		


Pin No.	Definition	Pin No.	Definition
33	GND	32	NC
35	PCIE_TXp	34	NC
37	PCIE_TXn	36	NC
39	GND	38	CL_Reset

41	PCIE_RXp	40	CL_DATA
43	PCIE_RXn	42	CL_Clock
45	GND	44	NC
47	PCIE CLOCKp	46	NC
49	PCIE CLOCKn	48	NC
51	GND	50	SUSCLK
53	PCIE Clock Request	52	PCIRST
55	PCIE wake up	54	BT_Disable
57	GND	56	WLAN_DISABLE
59	NC	58	NC
61	NC	60	NC
63	GND	62	NC
65	NC	64	NC
67	NC	66	NC
69	GND	68	NC
71	NC	70	NC
73	NC	72	3.3V
75	GND	74	3.3V


Connector PN	Vendor
2E0BC21-S85BE-7H	FOXCONN
80152-8521	BELLWETHER
APCI0095-P002A	LOTES

## 2.2.31 M2M (M.2 Slot, 2280 M-Key)

35



**M.2 M Key Connector**



Pin No.	Definition	Pin No.	Definition
1	GND	2	3.3V
3	GND	4	3.3V
5	PCIe3 RXn	6	NC
7	PCIe3 RXp	8	NC
9	GND	10	SSD LED
11	PCIe3 TXn	12	3.3V
13	PCIe3 TXp	14	3.3V
15	GND	16	3.3V
17	PCIe2 RXn	18	3.3V
19	PCIe2 RXp	20	NC
21	GND	22	NC
23	PCIe2 TXn	24	NC
25	PCIe2 TXp	26	NC
27	GND	28	NC
29	PCIe1 RXn	30	NC
31	PCIe1 RXp	32	NC
33	GND	34	NC
35	PCIe1 TXn	36	NC

Pin No.	Definition	Pin No.	Definition
37	PCIe2 TXp	38	DEVSLP
39	GND	40	NC
41	PCIe0 RXn	42	NC
43	PCIe0 RXp	44	NC
45	GND	46	NC
47	PCIe0 TXn	48	NC
49	PCIe0 TXp	50	PCI Reset
51	GND	52	PCI Clock Request
53	PCIe Clockn	54	Wakeup
55	PCIe Clockp	56	NC
57	GND	58	NC

Pin No.	Definition	Pin No.	Definition
67	NC	68	SUSCLK
69	Detect	70	3.3V
71	GND	72	3.3V
73	GND	74	3.3V
75	GND		

Connector PN	Vendor
AS0BC21-S40BM-7H	FOXCONN
APCI0073-P001A	LOTES

# Chapter 3

---

Chapter 3 – BIOS

## 3.1 Introduction

BIOS (Basic input/output system) provides hardware detailed information and boot-up options, which include firmware to control, set-up and test all hardware settings. Therefore, BIOS is the communication bridge between OS/application software and hardware.

### 3.1.1 How to Entering into BIOS menu


Once the system is power on, press the <DEL> key as soon as possible to access into BIOS Setup program.

### 3.1.2 Function Keys to setup in BIOS Setup program

Function keys	Description
→←	Select Screen
↑↓	Select Item
Enter	Execute command or enter the submenu
+	Increase the numeric value or make changes
—	Decrease the numeric value or make changes
F1	General Help
F2	Previous Values
F3	Load Optimized Defaults Settings
F4	Save changes & Exit the BIOS Setup program
ESC	Exit the BIOS Setup program

## 3.2 The Main Menu


The main menu shows the basic system information. Use arrow keys to move among the items.



Items	Description
<b>Project Name</b>	<b>Shows Project name information</b>
<b>BIOS Version</b>	<b>Shows the BIOS version of the system</b>
<b>Build Date and Time</b>	<b>Shows the Build Date and Time when the BIOS was created.</b>
<b>LAN1 MAC Address</b>	<b>Shows LAN 1 MAC Address information</b>
<b>LAN2 MAC Address</b>	<b>Shows LAN 2 MAC Address information</b>
<b>Total Memory</b>	<b>Shows the total memory size of the installed memory</b>
<b>ME FW version</b>	<b>Shows ME firmware version</b>
<b>System Date</b>	<b>Set the Date for the system (Format : Week - Month - Day - Year)</b>
<b>System Time</b>	<b>Set the time for the system (Format : Hour - Minute - Second)</b>

### 3.3 Advanced


The Advanced menu is to configure the functions of hardware settings through submenu. Use arrow keys to move among the items, and press <Enter> to access into the related submenu.





## 3.3.1 TPM Configuration

Use TPM Configuration submenu to choose TPM interface.



Item	Description
TPM Device Selection	<b>PTT : Internal TPM (Default setting)</b> <b>dTPM : External TPM (When using External TPM module or having TPM chip on MB)</b>


Trusted Computing : Shows TPM information, and TPM module configuration setting.



Item	Description
<b>Security Device Support</b>	<b>Enabled : Enables TPM feature (Default setting)</b> <b>Disabled : Disables TPM feature</b>
<b>Pending operation</b>	<b>None : No execution will be conducted (Default setting)</b> <b>TPM clear : Set to clear data on TPM</b>


## 3.3.2 CPU Configuration

This submenu shows detailed CPU informations.




Item	Description
<b>Intel (VMX) Virtualization Technology</b>	Virtualization enhanced by Intel® Virtualization Technology will allow a platform to run multiple operating systems and applications in independent partitions. With virtualization, one computer system can function as multiple virtual systems. <b>Enabled : Enables Intel Virtualization Technology (Default setting)</b> <b>Disabled : Disables Intel Virtualization Technology</b>
<b>Intel(R) Speed Shift Technology</b>	To speed up CPU frequency transition time from basic frequency to maximum frequency. <b>Enabled : Enables Intel(R) Speed Shift Technology Interrupt control (Default setting)</b> <b>Disabled : Disables Intel(R) Speed Shift Technology Interrupt control</b>
<b>Intel(R) SpeedStep(tm)</b>	According to Intel CPU loading, Intel SpeedStep Technology will automatically adjust the CPU voltage and core frequency to decrease heat and power consumption for power saving. <b>Enabled : Enables Intel SpeedStep Technology (Default setting)</b> <b>Disabled : Disables Intel SpeedStep Technology</b>
<b>Turbo Mode</b>	<b>Enabled : Enables Turbo Mode (Default setting)</b> <b>Disabled : Disables Turbo Mode</b>
<b>C states</b>	Command CPU to enter into low power consumption mode when CPU is under idle mode. <b>Enabled : Enables CPU C states function (Default setting)</b> <b>Disabled : Disables CPU C states function</b>
<b>Dual Tau Boost</b>	To optimize CPU performance. <b>Enabled : Enables Dual Tau Boost function</b> <b>Disabled : Disables Dual Tau Boost function (Default setting)</b>

### 3.3.3 SATA Configuration




Item	Description
Serial ATA Port 4	shows 2.5" SATA HDD/SSD information
Serial ATA Port 5	

### 3.3.4 IT8786 Super IO Configuration




Item	Description
<b>Serial Port 1 Configuration</b>	<p>Press [Enter] to configure advanced items :</p> <p>Serial Port :  <b>Enabled : Enables allows you to configure the serial port settings</b>  <b>Disabled : if Disabled, displays no configuration for the serial port</b></p> <p>Device settings :                      Display the specified Serial Port base I/O address and IRQ</p> <p>COM Port Mode :                      Choose RS-232, RS-422, or RS-485 feature</p>
<b>Serial Port 2 Configuration</b>	<p>Press [Enter] to configure advanced items :</p> <p>Serial Port :  <b>Enabled : Enables allows you to configure the serial port settings</b>  <b>Disabled : if Disabled, displays no configuration for the serial port</b></p> <p>Device settings :                      Display the specified Serial Port base I/O address and IRQ</p>

### 3.3.5 Hardware Monitor




Item	Description
<b>CPU Fan Fail Warning</b>	<b>Enabled</b> : Enables CPU FAN Fail warning alert function (Default setting) <b>Disabled</b> : Disables CPU FAN Fail warning alert function
<b>System Fan Fail Warning</b>	<b>Enabled</b> : Enables System FAN Fail warning alert function <b>Disabled</b> : Disables System FAN Fail warning alert function (Default setting)
<b>CPU Fan Speed Control</b>	<b>Normal</b> : Fan speed set by BIOS default (Default setting) <b>Full Speed</b> : Set Fan operates at full speed
<b>System Fan Speed Control</b>	<b>Normal</b> : Fan speed set by BIOS default (Default setting) <b>Full Speed</b> : Set Fan operates at full speed
<b>CPU Temperature</b>	Shows current CPU temperature
<b>System Temperature</b>	Shows current system temperature
<b>CPU Fan Speed</b>	Shows current CPU fan Speed
<b>SYS Fan Speed</b>	Shows current System fan Speed

### 3.3.6 S5 RTC Wake Settings



Item	Description
<p><b>Wake system from S5</b></p>	<p>Enable or Disable System to wake on a specific time.  <b>Disabled : Disables system to wake on a specific time (Default setting)</b>  <b>Fixed Time : Enables system to wake on a specific time (Format : hr : min : sec)</b></p>


### 3.3.7 AMI Graphic Output Protocol Policy




Item	Description
Output Select	Choose default monitor output when there are more than one monitor plugged on the motherboard.



## 3.3.8 Network Stack Configuration



When Network stack is enabled :




Item	Description
<b>Network Stack</b>	When system is power on, install LAN driver under UEFI mode <b>Disabled : Disables UEFI Network Stack (Default setting)</b> <b>Enabled : Enables UEFI Network Stack</b>
<b>IPv4 PXE Support</b>	When Network stack is enabled : <b>Disabled : Disables IPv4 PXE Support</b> <b>Enabled : Enables IPv4 PXE Support</b>
<b>IPv4 HTTP Support</b>	When Network stack is enabled : <b>Disabled : Disables IPv4 HTTP Support</b> <b>Enabled : Enables IPv4 HTTP Support</b>
<b>IPv6 PXE Support</b>	When Network stack is enabled : <b>Disabled : Disables IPv6 PXE Support</b> <b>Enabled : Enables IPv6 PXE Support</b>
<b>IPv6 HTTP Support</b>	When Network stack is enabled : <b>Disabled : Disables IPv6 HTTP Support</b> <b>Enabled : Enables IPv6 HTTP Support</b>
<b>PXE boot wait time</b>	Wait time in seconds, or use ESC key to abort the PXE boot.
<b>Media detect count</b>	Number of times the presence of media will be checked.


### 3.3.9 NVMe Configuration

---


NVMe Configuration shows information when your M.2 NVMe PCIe SSD is installed.



## 3.3.10 Offboard SATA Controller Configuration




### 3.3.11 Digital IO Port Configuration




Item	Description
OS control Digital IO	<p><b>Disabled :</b> If Digital IO Output value/level is modified in OS, they will not be memorized and kept. (Default setting)</p> <p><b>Enabled :</b> If Digital IO Output value/level is modified in OS, they will be memorized and kept.</p>
<p><b>SOGPO_1 (Pin 1)</b>  <b>SOGPI_1 (Pin 2)</b>  <b>SOGPO_2 (Pin 3)</b>  <b>SOGPI_2 (Pin 4)</b>  <b>SOGPO_3 (Pin 5)</b>  <b>SOGPI_3 (Pin 6)</b>  <b>SOGPO_4 (Pin 7)</b>  <b>SOGPI_4 (Pin 8)</b></p>	Configure Digital IO Input or Output values for each pin.

### 3.3.12 Tls Auth Configuration



Item	Description
<b>Enroll Cert</b>	<p>Press [Enter] to configure advanced items :</p> <p><b>Server CA Configuration :</b></p> <p><b>Enroll Cert :</b></p> <ol style="list-style-type: none"> <li>1. Enroll Cert Using File</li> <li>2. Cert GUID : Input digit character in 11111111-2222-3333-4444-1234567 890ab format.</li> <li>3. Commit Changes and Exit</li> <li>4. Discard Changes and Exit</li> </ol>


## 3.4 Chipset



Item	Description
VT-d	<b>Enabled : Enables VT-d function (Default setting)</b> <b>Disabled : Disables VT-d function</b>
DVMT Pre-Allocated	Use DVMT Pre-Allocated to set the amount of system memory which is installed to the integrated graphics processor <b>Option items : 32M , 64M, 128M, 256M (Default setting)</b>
Primary Display	<b>Auto : When detects PCIe Graphic card, primary display will set to PCIe (Default setting)</b> <b>IGFX : Force IGFX Graphic card as the primary display device</b> <b>PEG : Force PEG Graphic card as the primary display device</b>
Internal Graphics	Enables or disables the onboard graphics function <b>Auto : Detects display device automatically (Default setting)</b> <b>Enabled : Enables onboard graphics</b> <b>Disabled : Disables onboard graphics</b>
Onboard LAN1 Onboard LAN2	Enable/Disable onboard LAN controller <b>Enabled : Enables onboard LAN controller (Default setting)</b> <b>Disabled : Disables onboard LAN controller</b>
HD Audio	Enable/Disable onboard audio controller <b>Enabled : Enables onboard audio controller (Default setting)</b> <b>Disabled : Disables onboard audio controller</b>

<b>ErP Lowest Power State Mode</b>	Enable/Disable power saving function <b>Enabled : Enables ErP Lowest Power State Mode</b> <b>Disabled : Disabled ErP Lowest Power State Mode (Default setting)</b>
<b>Restore AC Power Loss</b>	To set which option the system should returns if a sudden power loss occurred <b>Power off : Do not power on when the power is back (Default setting)</b> <b>Power on : System power on when the power is back</b> <b>Last state : Restore the system to the state before power loss occurs</b>
<b>LVDS Support</b>	<b>Disabled : Disables LVDS Support (Default setting)</b> <b>Enabled : Enables LVDS Support</b>
<b>LVDS Brightness Level</b>	When LVDS Support is enabled : To modified the backlight brightness of the LVDS panel <b>Option items : 10%, 20%, 30%, 40%, 50%, 60%, 70%, 80%, 90%, 100% (Default Setting)</b>
<b>LVDS Resolution</b>	When LVDS Support is enabled : To modified the LVDS resolution <b>Option items : 800x600 18bit (Default Setting) , 1024x768 18bit, 1024x768 24bit, 1024x600 18bit, 1280x800 18bit, 1280x960 18bit, 1280x1024 24bit, 1366x768 18bit, 1366x768 24bit, 1440x900 24bit, 1400x1050 24bit, 1600x900 24bit, 1680x1050 24bit, 1600x1200 24bit, 1920x1080 24bit, 1920x1200 24bit</b>
<b>Watchdog Timer</b>	Enable/Disable Watchdog Timer function <b>Disabled : Disables Watchdog Timer function (Default setting)</b> <b>Enabled : Enables Watchdog Timer function</b>
<b>BIOS Lock</b>	Enable/Disable BIOS Lock function <b>Enabled : Enables BIOS Lock function (Default setting)</b> <b>Disabled : Disabled BIOS Lock function</b>

## 3.5 Security




Item	Description
<b>Administrator Password</b>	To set up Administrator's password <b>Minimum length : 3</b> <b>Maximum length : 20</b>
<b>User Password</b>	To set up User's password <b>Minimum length : 3</b> <b>Maximum length : 20</b>
<b>Secure Boot</b>	Press <Enter> to configure the advanced items





Item	Description
Secure Boot	Secure Boot requires all the applications that are running during the booting process to be pre-signed with valid digital certificates <b>Enabled : Enables Secure Boot function</b> <b>Disabled : Disables Secure Boot function (Default setting)</b>
Secure Boot Mode	<b>Standard : Standard mode</b> <b>Custom : Custom mode (Default setting)</b>
Restore Factory Keys	To restore factory settings <b>Yes : Agree to restore factory settings</b> <b>No : Cancel to restore factory settings</b>
Reset To Setup Mode	<b>Yes : Agree to setup mode</b> <b>No : Cancel to setup mode</b>
Key Management	Enables expert users to modify Secure boot policy variables without full authentication Press <Enter> to configure the advanced items




Item	Description
<b>Factory Key Provision</b>	Install factory default Secure Boot keys after the platform reset and while the system is in Setup mode <b>Enabled : Enables Factory Key Provision (Default setting)</b> <b>Disabled : Disables Factory Key Provision</b>
<b>Restore Factory Keys</b>	To restore factory settings <b>Yes : Agree to restore factory settings</b> <b>No : Cancel to restore factory settings</b>
<b>Reset To Setup Mode</b>	<b>Yes : Agree to setup mode</b> <b>No : Cancel to setup mode</b>
<b>Export Secure Boot variables</b>	Copy NVRAM content of Secure Boot variables to files in a root folder on a file system device
<b>Enroll Efi Image</b>	Allow the image to run in Secure Boot mode

Item	Description
<b>Platform Key (PK)</b>	These items allows you to enroll factory defaults or load Certificates from a file.
<b>Key Exchange Keys</b>	
<b>Authorized Signatures</b>	
<b>Forbidden Signatures</b>	
<b>Authorized TimeStamps</b>	
<b>OsRecovery Signatures</b>	
<b>MS UEFI CA Key</b>	Device Guard ready system must not list 'Microsoft UEFI CA' Certificate in Authorized Signature database(db)


## 3.6 Boot

This Boot menu allows you to set/change system boot options



Item	Description
<b>Full Screen LOGO Show</b>	Enable/Disable full screen LOGO show on POST screen <b>Enabled : Enables Full screen LOGO Show on POST screen</b> <b>Disabled : Disables Full screen LOGO Show on POST screen (Default setting)</b>
<b>Built-in EFI Shell</b>	Enable/Disable Built-in EFI Shell <b>Enabled : Enables Built-in EFI Shell</b> <b>Disabled : Disables Built-in EFI Shell (Default setting)</b>
<b>Boot Option #1</b>	Shows the information of the storage that be installed in the system <b>Choose/set the boot priority</b>

## 3.7 Save & Exit



Item	Description
<b>Save Changes and Reset</b>	After configuring all the options that you wish to change, choose this option to save all the changes and reboot the system <b>Yes : Agree to save and reset</b> <b>No : Cancel to save and reset</b>
<b>Discard Changes and Reset</b>	Choose this option to reboot the system without saving any changes <b>Yes : Agree to discard changes and reset</b> <b>No : Cancel to discard changes and reset</b>
<b>Restore Defaults</b>	Restore/Load default values for all the setup options <b>Yes : Agree to load optimized defaults</b> <b>No : Cancel to load optimized defaults</b>
<b>Me FW Image Re-Flash</b>	Enable/Disable Me FW image re-flash function <b>Enabled : Enables Me FW image re-flash function</b> <b>Disabled : Disables Me FW image re-flash function (Default setting)</b>