



IEI Technology Corp.



MODEL:
UPC-V315-NM70

Panel PC with Touch Screen and Intel® Celeron® Processor
847, GbE, Wireless, RFID, Bluetooth, USB, Audio,
RS-232/422/485, RoHS Compliant, IP 65 Protection

User Manual

Rev. 1.00 – 3 May, 2013





Revision

Date	Version	Changes
3 May, 2013	1.00	Initial release

Copyright

COPYRIGHT NOTICE

The information in this document is subject to change without prior notice in order to improve reliability, design and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

TRADEMARKS

All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

Table of Contents

1 INTRODUCTION.....	1
1.1 OVERVIEW.....	2
1.2 MODEL VARIATIONS	3
1.3 FEATURES.....	3
1.4 EXTERNAL OVERVIEW.....	3
1.4.1 Front Panel	3
1.4.1.1 LED Indicators.....	5
1.4.2 Bottom Panel.....	6
1.4.3 Side Panels.....	8
1.4.4 Rear Panel	8
1.4.5 Frame (Function Keys).....	9
1.5 DIMENSIONS.....	10
1.6 SPECIFICATIONS	11
2 UNPACKING	14
2.1 UNPACKING.....	15
2.2 PACKING LIST.....	16
3 INSTALLATION	18
3.1 ANTI-STATIC PRECAUTIONS	19
3.2 INSTALLATION PRECAUTIONS	19
3.3 PREINSTALLED COMPONENTS.....	20
3.4 SSD INSTALLATION	20
3.5 INTERNAL USB DEVICES INSTALLATION	22
3.6 MOUNTING THE SYSTEM	24
3.6.1 Arm Mounting	25
3.6.2 Stand Mounting.....	26
3.6.3 Wall Mounting.....	27
3.7 BOTTOM PANEL CONNECTORS.....	29
3.7.1 External Peripheral Device Connection.....	29
3.7.2 ACC Mode Selection.....	31

UPC-V315-NM70 Panel PC

3.7.3 AT/ATX Power Mode Selection.....	31
3.7.4 Audio Connectors.....	32
3.7.5 CAN-bus Terminal Block.....	32
3.7.6 HDMI Connector	32
3.7.7 LAN Connector	34
3.7.8 Power Input, 3-pin Terminal Block.....	35
3.7.9 Power Input, 4-pin DIN Connector	35
3.7.10 RJ-45 RS-232 Serial Port.....	36
3.7.11 RJ-45 RS-422/485 Serial Port.....	37
3.7.12 USB Connectors.....	39
3.7.13 VGA Connector	40
3.8 REDUNDANT POWER	43
3.8.1 ACC ON	44
3.8.1.1 Boot-up	44
3.8.1.2 Switch to Backup Power	45
3.8.1.3 Shutdown	45
3.8.2 ACC OFF	46
3.8.2.1 Boot-up	46
3.8.2.2 Switch to Backup Power	47
3.8.2.3 Shutdown	48
3.9 REMOTE CONTROL	49
4 BIOS.....	50
4.1 INTRODUCTION.....	51
4.1.1 Starting Setup.....	51
4.1.2 Using Setup	51
4.1.3 Getting Help.....	52
4.1.4 Unable to Reboot after Configuration Changes	52
4.1.5 BIOS Menu Bar.....	52
4.2 MAIN.....	53
4.3 ADVANCED	54
4.3.1 ACPI Settings	55
4.3.2 RTC Wake Settings	56
4.3.3 CPU Configuration.....	57
4.3.4 SATA Configuration	59

4.3.5 USB Configuration.....	60
4.3.6 F81866 Super IO Configuration	61
4.3.6.1 Serial Port n Configuration	62
4.3.7 H/W Monitor	65
4.3.8 Serial Port Console Redirection	66
4.3.9 iEi Feature	68
4.4 CHIPSET	70
4.4.1 PCH-IO Configuration	71
4.4.1.1 PCH Azalia Configuration	73
4.4.2 System Agent (SA) Configuration	74
4.4.2.1 Graphics Configuration.....	74
4.4.2.2 NB PCIe Configuration.....	78
4.4.2.3 Memory Configuration	79
4.5 BOOT.....	79
4.6 SECURITY	82
4.7 SAVE & EXIT	83
A BIOS MENU OPTIONS	85
B ONE KEY RECOVERY	88
B.1 ONE KEY RECOVERY INTRODUCTION	89
B.1.1 System Requirement.....	90
B.1.2 Supported Operating System	91
B.2 SETUP PROCEDURE FOR WINDOWS	92
B.2.1 Hardware and BIOS Setup	93
B.2.2 Create Partitions	93
B.2.3 Install Operating System, Drivers and Applications.....	97
B.2.4 Building the Recovery Partition	98
B.2.5 Create Factory Default Image.....	100
B.3 AUTO RECOVERY SETUP PROCEDURE	105
B.4 SETUP PROCEDURE FOR LINUX	109
B.5 RECOVERY TOOL FUNCTIONS	113
B.5.1 Factory Restore	114
B.5.2 Backup System.....	115
B.5.3 Restore Your Last Backup.....	116
B.5.4 Manual.....	117

UPC-V315-NM70 Panel PC

B.6 RESTORE SYSTEMS FROM A LINUX SERVER THROUGH LAN	118
<i>B.6.1 Configure DHCP Server Settings</i>	<i>119</i>
<i>B.6.2 Configure TFTP Settings</i>	<i>120</i>
<i>B.6.3 Configure One Key Recovery Server Settings</i>	<i>121</i>
<i>B.6.4 Start the DHCP, TFTP and HTTP</i>	<i>122</i>
<i>B.6.5 Create Shared Directory.....</i>	<i>122</i>
<i>B.6.6 Setup a Client System for Auto Recovery</i>	<i>123</i>
B.7 OTHER INFORMATION	126
<i>B.7.1 Using AHCI Mode or ALi M5283 / VIA VT6421A Controller.....</i>	<i>126</i>
<i>B.7.2 System Memory Requirement</i>	<i>128</i>
C SAFETY PRECAUTIONS	129
C.1 SAFETY PRECAUTIONS.....	130
<i>C.1.1 General Safety Precautions.....</i>	<i>130</i>
<i>C.1.2 Anti-static Precautions</i>	<i>131</i>
<i>C.1.3 Product Disposal.....</i>	<i>131</i>
C.2 MAINTENANCE AND CLEANING PRECAUTIONS	132
<i>C.2.1 Maintenance and Cleaning</i>	<i>132</i>
<i>C.2.2 Cleaning Tools.....</i>	<i>133</i>
D HAZARDOUS MATERIALS DISCLOSURE	134
D.1 HAZARDOUS MATERIAL DISCLOSURE TABLE FOR IPB PRODUCTS CERTIFIED AS ROHS COMPLIANT UNDER 2002/95/EC WITHOUT MERCURY	135

List of Figures

Figure 1-1: UPC-V315-NM70 Panel PC.....	2
Figure 1-2: Front View	4
Figure 1-3: LED Indicators	5
Figure 1-4: Bottom View	7
Figure 1-5: Left Side View	8
Figure 1-6: Right Side View	8
Figure 1-7: Rear View	8
Figure 1-8: Function Key Locations	9
Figure 1-9: UPC-V315-NM70 Dimensions (mm).....	10
Figure 3-1: Remove the SSD Drive Bay Access Panel	21
Figure 3-2: Inserting the SSD	21
Figure 3-3: Securing the SSD	22
Figure 3-4: SSD Installation.....	22
Figure 3-5: Internal USB Port Cover Retention Screws.....	23
Figure 3-6: Internal USB Port Location	23
Figure 3-7: VESA Mount Retention Screw Holes	24
Figure 3-8: Mounting Brackets (Side Panels)	25
Figure 3-9: VESA Compliant Arm.....	25
Figure 3-10: VESA Compliant Stand.....	26
Figure 3-11: Wall-mounting Bracket	27
Figure 3-12: Chassis Support Screws.....	28
Figure 3-13: Secure the Panel PC	29
Figure 3-14: I/O Cover Retention Screws	30
Figure 3-15: External Peripheral Device Connection.....	30
Figure 3-16: Rubber Gasket Removal.....	30
Figure 3-17: Rubber Gasket and Cable	31
Figure 3-18: External Peripheral Device Connection Complete	31
Figure 3-19: ACC Mode Switch	31
Figure 3-20: AT/ATX Power Mode Switch	32
Figure 3-21: CAN-bus Terminal Block Pinouts.....	32
Figure 3-22: HDMI Connection	33

UPC-V315-NM70 Panel PC

Figure 3-23: LAN Connection	34
Figure 3-24: RJ-45 Ethernet Connector.....	34
Figure 3-25: 3-pin Terminal Block Pinouts	35
Figure 3-26: Power Input Connector.....	36
Figure 3-27: RJ-45 RS-232 Serial Port Pinout Location.....	36
Figure 3-28: DB-9 Connector Pinout Location	36
Figure 3-29: RJ-45 RS-232 Serial Device Connection.....	37
Figure 3-30: RJ-45 RS-422/485 Serial Port Pinout Location.....	38
Figure 3-31: DB-9 Connector Pinout Location	38
Figure 3-32: RJ-45 RS-422/485 Serial Device Connection.....	39
Figure 3-33: USB Device Connection	40
Figure 3-34: VGA Connector	41
Figure 3-35: VGA Connector	42
Figure 3-36: Power Connectors	43
Figure 3-37: ACC On: AT Mode.....	44
Figure 3-38: ACC On: ATX Mode.....	44
Figure 3-39: ACC On: Switch Between PWR1 and PWR2	45
Figure 3-40: ACC On: Shutdown.....	46
Figure 3-41: ACC Off: AT Mode.....	47
Figure 3-42: ACC Off: ATX Mode	47
Figure 3-43: ACC Off: Switch Between PWR1 and PWR2	47
Figure 3-44: ACC Off: Shutdown.....	48
Figure 3-45: Remote Control	49
Figure B-1: IEI One Key Recovery Tool Menu	89
Figure B-2: Launching the Recovery Tool	94
Figure B-3: Recovery Tool Setup Menu	94
Figure B-4: Command Prompt	95
Figure B-5: Partition Creation Commands.....	96
Figure B-6: Launching the Recovery Tool	98
Figure B-7: Manual Recovery Environment for Windows	98
Figure B-8: Building the Recovery Partition.....	99
Figure B-9: Press Any Key to Continue	99
Figure B-10: Press F3 to Boot into Recovery Mode.....	100
Figure B-11: Recovery Tool Menu	100
Figure B-12: About Symantec Ghost Window.....	101

Figure B-13: Symantec Ghost Path	101
Figure B-14: Select a Local Source Drive	102
Figure B-15: Select a Source Partition from Basic Drive	102
Figure B-16: File Name to Copy Image to	103
Figure B-17: Compress Image.....	103
Figure B-18: Image Creation Confirmation	104
Figure B-19: Image Creation Complete	104
Figure B-20: Image Creation Complete	104
Figure B-21: Press Any Key to Continue	105
Figure B-22: Auto Recovery Utility	106
Figure B-23: Launching the Recovery Tool	106
Figure B-24: Auto Recovery Environment for Windows	106
Figure B-25: Building the Auto Recovery Partition.....	107
Figure B-26: Factory Default Image Confirmation	107
Figure B-27: Image Creation Complete	108
Figure B-28: Press any key to continue	108
Figure B-29: Partitions for Linux.....	110
Figure B-30: Manual Recovery Environment for Linux	111
Figure B-31: Access menu.lst in Linux (Text Mode).....	112
Figure B-32: Recovery Tool Menu	112
Figure B-33: Recovery Tool Main Menu	113
Figure B-34: Restore Factory Default	114
Figure B-35: Recovery Complete Window	115
Figure B-36: Backup System.....	115
Figure B-37: System Backup Complete Window	116
Figure B-38: Restore Backup	116
Figure B-39: Restore System Backup Complete Window	117
Figure B-40: Symantec Ghost Window	117

List of Tables

Table 1-1: LED Indicators	6
Table 1-2: Function Keys	9
Table 1-3: System Specifications.....	13
Table 3-1: HDMI Pinouts	33
Table 3-2: LAN Pinouts	35
Table 3-3: RJ-45 Ethernet Connector LEDs	35
Table 3-4: RJ-45 RS-232 Serial Port Pinouts	36
Table 3-5: DB-9 Connector Pinouts	37
Table 3-6: RJ-45 RS-422/485 Serial Port Pinouts	38
Table 3-7: DB-9 Connector Pinouts	38
Table 3-8: USB Port Pinouts (USB 2.0).....	40
Table 3-9: VGA Connector Pinouts	41
Table 4-1: BIOS Navigation Keys	52

Chapter

1

Introduction

1.1 Overview



Figure 1-1: UPC-V315-NM70 Panel PC

The fanless UPC-V315-NM70 is Intel® Celeron® processor 847 powered panel PC with a rich variety of functions and peripherals. The UPC-V315-NM70 panel PC is designed for easy and simplified integration into various vehicle applications.

An Intel® NM70 express chipset ensures optimal memory, graphics, and peripheral I/O support. The system comes with 2GB of preinstalled DDR3 SDRAM ensuring smooth data throughputs with reduced bottlenecks and fast system access.

The redundant dual DC power input of the UPC-V315-NM70 increases the reliability of the system and prevents data loss and system corruption from sudden power failure.

The CAN-bus interface allows the UPC-V315-NM70 to communication with vehicles. Four serial ports and two external USB 2.0 ports ensure simplified connectivity to a variety of external peripheral devices. Wi-Fi capabilities and dual RJ-45 GbE connectors ensure smooth connection of the system to an external LAN.

UPC-V315-NM70 Panel PC

1.2 Model Variations

The model numbers and model variations are listed below.

Model	CPU
UPC-V315-NM70-C/R/2G-R10	Intel® Celeron® Processor 847

1.3 Features

All the UPC-V315-NM70 models feature the following:

- Intel Ivy Bridge mobile chipset (NM70)
- 15" 400 nits 1024 x 768 LCD with LED backlight
- Full IP 65 compliant die-casting aluminum chassis
- PCIe mini card expansion
- Dual-DC input, 9V ~ 36V and 10.5V ~ 36V, switch automatically
- ACC power support
- Dual-band 2.4/5GHz Wi-Fi 802.11 a/b/g/n 3T3R MIMO design
- Reserved space for 3.75G / HSUPA USB dongle
- Optional EM or Mifare RFID reader
- Optional Bluetooth module
- Built-in 2M pixels webcam with AF, AE and AWB capabilities
- CAN-bus interface with isolation
- F1 ~ F10 function keys with customization options

1.4 External Overview

The panel PC is a rectangular cubic structure that comprises of a screen, rear panel, top panel, bottom panel and two side panels (left and right). An aluminum frame surrounds the front screen. The rear panel provides screw holes for a wall-mounting bracket, and an arm mounting interface. The bottom panel provides access to external interface connectors.

1.4.1 Front Panel

The front side of the UPC-V315-NM70 is a flat panel TFT LCD screen surrounded by an aluminum frame. At the top of the front panel features one 2.0 megapixel webcam that

supports auto-focus (AF), auto-exposure (AE) and auto white balance (AWB). The front panel also has following buttons, LED indicators and sensors:

- Buttons: F1~F10 (same as the function key on the keyboard)
- LEDs
 - Power 1 LED
 - Power 2 LED
 - AT/ATX power mode LED
 - CPU temperature alert LED
 - Wi-Fi connection LED
 - RFID LED
 - Bluetooth LED
 - 3G connection LED
 - Auto dimming LED
 - Microphone on/off LED
 - Audio mute LED
- Sensors
 - Ambient light sensor
 - Infrared remote control sensor




Figure 1-2: Front View

UPC-V315-NM70 Panel PC

1.4.1.1 LED Indicators

The LED indicators on the front panel of the UPC-V315-NM70 are shown below.




Figure 1-3: LED Indicators

The descriptions of each LED indicator are listed below.

LED Indicator	Description
Power 1	Pulsing Orange: Power 1 is the main power and is in standby mode Solid Orange: Power 1 is the second power and is in standby mode Solid Blue: Power 1 is providing power to the system
Power 2	Pulsing Orange: Power 2 is the main power and is in standby mode Solid Orange: Power 2 is the second power and is in standby mode Solid Blue: Power 2 is providing power to the system
AT/ATX Power Mode	Shows the power mode status. Controlled by the AT/ATX power mode switch.
CPU Temperature Alert	Blue: the CPU temperature is normal. Red: the CPU temperature is too high.
Wi-Fi	The Wi-Fi module is enabled or disabled. Controlled by the BIOS (see Section 4.4.1).
RFID Reader	The optional RFID reader is enabled or disabled. Controlled by the hot keys (see Section 1.4.5).
Bluetooth	The Bluetooth module is enabled or disabled. Controlled by the BIOS (see Section 4.4.1).
3G	The 3G module is enabled or disabled.

	Controlled by the BIOS (see Section 4.4.1).
Auto Dimming	The auto dimming function is enabled or disabled. Controlled by the BIOS (4.4.1).
Microphone	The microphone is enabled or disabled. Controlled by the BIOS (Section 4.4.1).
Audio Mute	Light on when the audio is turned off. Controlled by the hot keys (see Section 1.4.5).
Function	Shows the status of the function key below the LED indicator. Blinks when the corresponding button is pushed.
LCD on/off	
Volume Down	
Volume Up	
Brightness Down	
Brightness Up	

Table 1-1: LED Indicators**CAUTION:**

If the CPU temperature alert LED shows in red, the user must lower the environment temperature or close some running applications to cool down the CPU.

1.4.2 Bottom Panel

The following is a list of the bottom panel peripheral device connectors on the UPC-V315-NM70.

- 1 x 9 V ~ 36 V DC power input terminal block (Power I)
- 1 x 10.5 V ~ 36 V DC power input connector (Power II)
- 2 x Audio jacks (Line out ,MIC)
- 1 x CAN bus connector

UPC-V315-NM70 Panel PC

- 1 x HDMI connector
- 2 x RJ-45 GbE connectors
- 3 x RS-232 serial port connectors by RJ-45
- 1 x RS-422/485 serial port connector by RJ-45
- 2 x USB 2.0 connectors
- 1 x VGA connector

The bottom panel also includes the following switches and buttons:

- 1 x ACC on/off switch
- 1 x AT/ATX power mode switch
- 1 x Clear CMOS switch
- 1 x Reset button




Figure 1-4: Bottom View

1.4.3 Side Panels

The left side panel of the panel PC provides access to the HDD drive bay. (**Figure 1-5**)



Figure 1-5: Left Side View



Figure 1-6: Right Side View

1.4.4 Rear Panel

The rear panel has retention screw holes that support a wall-mounting bracket.




Figure 1-7: Rear View

UPC-V315-NM70 Panel PC

1.4.5 Frame (Function Keys)

An aluminum frame surrounds the TFT LCD screen. The aluminum frame of the UPC-V315-NM70 contains several function keys that control audio volume, LCD brightness and some other system components.



Figure 1-8: Function Key Locations

The following table describes the function of these function keys.












Buttons	Function	Buttons	Function
	Function		
	LCD on/off		Enable/Disable RFID
	Audio volume down		Mute audio
	Audio volume up		Enable/Disable webcam
	Brightness up		Enable/Disable 3G USB 2.0 port
	Brightness down		Power on/off (Turn on: press 3 seconds Turn off: press 6 seconds)

Table 1-2: Function Keys

1.5 Dimensions

The dimensions of the UPC-V315-NM70 are shown in **Figure 1-9** and listed below.




Figure 1-9: UPC-V315-NM70 Dimensions (mm)

1.6 Specifications

The technical specifications for the UPC-V315-NM70 system are listed in **Table 1-3**.

Specification	UPC-V315-NM70
Display	
LCD Size	15"
Max. Resolution	1024(W) x 768(H)
Brightness (cd/m²)	400
Contrast Ratio	700:1
LCD Color	16.2 M
Pixel Pitch (mm)(HxV)	0.297(H) x 0.297(V)
Viewing Angle (V/H)	125°/ 140°
Backlight MTBF (hrs)	50000
Touch	
Touch Screen	Resistive Type 5-Wire with RS-232 interface
Touch Controller	DMC 9000
Motherboard	
CPU	Intel® Celeron® Processor 847
Chipset	Mobile Intel® NM70 Express Chipset
RAM	Built in 1*2GB DDRIII memory (System Max. 8GB: on board Max. 4GB, socket Max. 4GB)
Ethernet	Intel® 82579 PHY with Intel® iAMT 8.0 supported Intel® 82583V PCIe controller
Audio Codec	Realtek ALC892 HD audio codec
System	

Audio	AMP 3W + 3W (Internal Speaker)
Camera	2M Mega Pixels
Connectivity	
Wireless	IEEE 802.11a/b/g/n 3T3R module (WIFI-RT5393-DB-R10)
Bluetooth	Bluetooth V2.0+EDR with USB interface (optional)
3G	Reserved USB connector (Optional)
Drive Bay	
HDD Driver Bay	1 x 2.5" SATA SSD
SSD	mSATA
CD-ROM Driver Bay	N/A
System Cooling	Fanless
Physical	
Construction Material	Aluminium alloy
Mounting	VESA 100mm x100mm or 75mm x 75mm with M8 screws
Front Panel Color	Orange (Paintone 15C)
Dimension (WxHxD) (mm)	427.19 x 330.63 x 71.6
Net Weight	7.97KG
Environment	
Operation Temperature	-20°C ~60°C
Storage Temperature	-30°C ~70°C
Operating Humidity	5% ~90%, non-condensing
Shock	Half-sine wave shock 3G; 11ms; 3 shocks per axis
Vibration	MIL-STD-810F 514.5C-1 (with CF card or SSD)
IP Rating	Full IP 65

UPC-V315-NM70 Panel PC

Power	
Adapter	90 W; 63040-010090-020-RS
Requirement	Power1:9V~36V(+/-0.3V) Power2:10.5V~36V(+/-0.3V)
I/O Ports and Switches	3 x RS-232 (RJ-45)
	1 x RS-422/485 (RJ-45)
	1 x CAN-BUS
	1 x VGA
	1 x HDMI port
	2 x GbE LAN
	2 x USB 2.0
	1 x Reset button
	1 x Audio jack (Line out ,MIC)
	1 x DC Jack (10.5 V ~36 V DC)
	1 x Terminal block (9 V ~36 V DC)
	1 x AT / ATX mode switch
	1 x ACC on/off switch
	1 x Clear CMOS switch
	1 x Reset button

Table 1-3: System Specifications



Chapter

2

Unpacking

2.1 Unpacking

To unpack the panel PC, follow the steps below:



WARNING!

The front side LCD screen has a protective plastic cover stuck to the screen. Only remove the plastic cover after the panel PC has been properly installed. This ensures the screen is protected during the installation process.

- Step 1:** Use box cutters, a knife or a sharp pair of scissors that seals the top side of the external (second) box.
- Step 2:** Open the external (second) box.
- Step 3:** Use box cutters, a knife or a sharp pair of scissors that seals the top side of the internal (first) box.
- Step 4:** Lift the monitor out of the boxes.
- Step 5:** Remove both polystyrene ends, one from each side.
- Step 6:** Pull the plastic cover off the panel PC.
- Step 7:** Make sure all the components listed in the packing list are present.

2.2 Packing List

The UPC-V315-NM70 panel PC is shipped with the following components:

Quantity	Item	Image
1	UPC-V315-NM70 panel PC	
1	Power adapter (P/N: 63040-010065-010-RS)	
1	Power cord (P/N: 32702-000401-100-RS)	
1	Power transfer cord (P/N: 32702-000300-100-RS)	
4	RJ-45 to DB-9 COM port cable (P/N: 32005-000200-200-RS)	
1	Remote control (P/N: 7Z000-SLPCB001-RS)	
8	VESA mount screw (M8) (P/N: 44325-080081-RS)	

UPC-V315-NM70 Panel PC

8	VESA mount screw (M4) (P/N: 44005-040082-RS)	
2	Mounting bracket (side panels) (P/N: 41003-0382C2-00-RS)	
1	Screw driver (P/N: 45019-001004-00)	
1	One Key Recover CD	
1	Utility CD	

If any of these items are missing or damaged, contact the distributor or sales representative immediately.

Chapter

3

Installation

3.1 Anti-static Precautions



WARNING:

Failure to take ESD precautions during the maintenance of the EP series may result in permanent damage to the EP series and severe injury to the user.

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the UPC-V315-NM70. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the UPC-V315-NM70 is accessed internally, or any other electrical component is handled, the following anti-static precautions are strictly adhered to.

- ***Wear an anti-static wristband:*** - Wearing a simple anti-static wristband can help to prevent ESD from damaging the board.
- ***Self-grounding:*** - Before handling the board touch any grounded conducting material. During the time the board is handled, frequently touch any conducting materials that are connected to the ground.
- ***Use an anti-static pad:*** - When configuring the UPC-V315-NM70, place it on an anti-static pad. This reduces the possibility of ESD damaging the UPC-V315-NM70.
- ***Only handle the edges of the PCB:*** - When handling the PCB, hold the PCB by the edges.

3.2 Installation Precautions

When installing the panel PC, please follow the precautions listed below:

- **Power turned off:** When installing the panel PC, make sure the power is off. Failing to turn off the power may cause severe injury to the body and/or damage to the system.
- **Certified Engineers:** Only certified engineers should install and modify onboard functionalities.
- **Anti-static Discharge:** If a user opens the rear panel of the panel PC, to

configure the jumpers or plug in added peripheral devices, ground themselves first and wear an anti-static wristband.

3.3 Preinstalled Components

The following components are all preinstalled.

- Motherboard
- TFT LCD screen
- DDR3 memory module
- Resistive type touch screen
- Stereo speakers
- Wireless module
- Webcam



CAUTION:

The UPC-V315-NM70 is an IP 65 compliant panel PC. A user cannot open the rear cover and install any components inside the UPC-V315-NM70. Doing so may compromise the system's waterproof performance. To install components in the system, please contact the system vendor, reseller or an IEI sales person directly.

3.4 SSD Installation

To install the SSD into the UPC-V315-NM70, please follow the steps below:

Step 1: **Locate the SSD drive bay access panel.** The SSD drive bay access panel is located on the left side panel of the UPC-V315-NM70.

Step 2: **Remove the SSD drive bay access panel** by removing the four retention screws.

**NOTE:**

Please use the screw driver that comes with the UPC-V315-NM70 to remove the screws on the chassis.




Figure 3-1: Remove the SSD Drive Bay Access Panel

Step 3: Insert the SSD into the bracket as shown.



Figure 3-2: Inserting the SSD

Step 4: Secure the SSD to the bracket using four retention screws.



Figure 3-3: Securing the SSD

Step 5: Install the SSD. Correctly align the SSD bracket with the system and insert the SSD bracket into the system.



Figure 3-4: SSD Installation

Step 6: Reinstall the SSD drive bay access panel.

3.5 Internal USB Devices Installation

The UPC-V315-NM70 has one internal USB 2.0 port inside the chassis. This USB port is reserved for the 3G USB dongle. To install the 3G USB dongle, follow the instructions below.

UPC-V315-NM70 Panel PC

Step 1: Remove the internal USB port cover by removing the seven retention screws.




Figure 3-5: Internal USB Port Cover Retention Screws

Step 2: Remove the internal USB port cover and locate the internal USB port.



Figure 3-6: Internal USB Port Location

Step 3: Install the USB dongle. Correctly align the USB dongle with the connector and insert the USB dongle into the connector.

Step 4: Reinstall the internal USB port cover.

3.6 Mounting the System



WARNING:

When mounting the panel PC onto an arm or onto the wall, it is better to have more than one person to help with the installation to make sure the panel PC does not fall down and get damaged.

The panel PC is VESA (Video Electronics Standards Association) compliant and can be mounted on an arm, a stand or a bracket with a 100 mm/75 mm interface pad. M8 and M4 mounting screws can both be used for VESA mount. The VESA mount retention screw holes of the UPC-V315-NM70 are shown in **Figure 3-7**.

100 mm x 100mm VESA Mount

75 mm x 75mm VESA Mount




Figure 3-7: VESA Mount Retention Screw Holes

To enhance the stability, the user can use the mounting brackets, which are shipped with the UPC-V315-NM70 and can be attached on both side panels. An additional mounting device is required for the mounting brackets.

UPC-V315-NM70 Panel PC



Figure 3-8: Mounting Brackets (Side Panels)

**NOTE:**

When mounting the UPC-V315-NM70 on a vehicle, it is recommended to use the **M8** mounting screws on the rear panel. A special mounting bracket is required for M8 mounting screw. Please contact IEI for more information.

The following installation options are available:

- Arm mounting
- Stand mounting
- Wall mounting

The mounting methods are described below.

3.6.1 Arm Mounting

The UPC-V315-NM70 can be installed on any arm that supports the standard VESA mounting interface. An example arm is shown below.



Figure 3-9: VESA Compliant Arm

To install the UPC-V315-NM70 on the arm, follow the directions below.

**NOTE:**

Make sure the arm supports standard VESA mounting. The UPC-V315-NM70 uses a VESA mounting to attach to the arm.

-
- Step 1:** The arm is purchased separately. Follow the instructions in the arm's user manual to securely attach the arm to the wall.
- Step 2:** Once the mounting arm has been firmly attached to the surface, lift the panel PC onto the interface pad of the mounting arm.
- Step 3:** Align the retention screw holes on the mounting arm interface with those in the panel PC. The arm mount retention screw holes are shown in **Figure 3-7**.
- Step 4:** Secure the flat panel PC to the interface pad by inserting four retention screws through the bottom of the mounting arm interface pad and into the flat panel PC.

3.6.2 Stand Mounting

The UPC-V315-NM70 can be installed on any stand that supports the standard VESA mounting interface. An example stand is shown below.



Figure 3-10: VESA Compliant Stand

To install the UPC-V315-NM70 on the stand, follow the directions below.

UPC-V315-NM70 Panel PC

- Step 1:** Locate the screw holes on the rear of the UPC-V315-NM70. This is where the stand bracket will be attached. The stand mount retention screw holes are shown in **Figure 3-7**.
- Step 2:** Align the bracket with the screw holes.
- Step 3:** Insert the retention screws into the screw holes to secure the bracket to the UPC-V315-NM70.

3.6.3 Wall Mounting

To mount the panel PC onto the wall, please follow the steps below.

- Step 1:** Select the location on the wall for the wall-mounting bracket.
- Step 2:** Carefully mark the locations of the four brackets screw holes on the wall.
- Step 3:** Drill four pilot holes at the marked locations on the wall for the bracket retention screws.
- Step 4:** Align the wall-mounting bracket screw holes with the pilot holes.
- Step 5:** Secure the mounting-bracket to the wall by inserting the retention screws into the four pilot holes and tightening them (Figure 3-11).




Figure 3-11: Wall-mounting Bracket

- Step 6:** Insert the four monitor mounting screws provided in the wall mounting kit into the four screw holes on the rear panel of the flat panel PC and tighten until the screw shank is secured against the rear panel (Figure 3-12).
- Step 7:** Align the mounting screws on the monitor rear panel with the mounting holes on the bracket.
- Step 8:** Carefully insert the screws through the holes and gently pull the monitor downwards until the monitor rests securely in the slotted holes (Figure 3-12). Ensure that all four of the mounting screws fit snugly into their respective slotted holes.




Figure 3-12: Chassis Support Screws



NOTE:

In the diagram below the bracket is already installed on the wall.

UPC-V315-NM70 Panel PC

Step 9: Secure the panel PC by fastening the retention screw of the wall-mounting bracket. (Figure 3-13).




Figure 3-13: Secure the Panel PC

3.7 Bottom Panel Connectors

The bottom panel of the UPC-V315-NM70 contains I/O connectors, switches and a reset button. These connectors are protected by an I/O cover. Detailed descriptions of the connectors can be found in the subsections below.

3.7.1 External Peripheral Device Connection

To install external peripheral devices to the UPC-V315-NM70, please follow the steps below.

Step 1: Remove the I/O cover by removing the ten retention screws as shown in **Figure 3-14**.



Figure 3-14: I/O Cover Retention Screws

Step 2: Connect the cable from the external peripheral device to the corresponding connector of the UPC-V315-NM70 (**Figure 3-15**).



Figure 3-15: External Peripheral Device Connection

Step 3: Take out a rubber gasket from the I/O cover (**Figure 3-16**).



Figure 3-16: Rubber Gasket Removal

Step 4: Remove some rubber rings from the gasket to make the gasket fit perfectly to the size of the cable (**Figure 3-17**).

UPC-V315-NM70 Panel PC



Figure 3-17: Rubber Gasket and Cable

Step 5: Repeat steps to other connected cables.

Step 6: Install the I/O cover and make sure each rubber gasket snaps into place tightly.

Step 7: Secure the I/O cover by the previously removed retention screws.



Figure 3-18: External Peripheral Device Connection Complete

3.7.2 ACC Mode Selection

The ACC mode can be turned on or off. The setting is made through the ACC mode switch on the bottom panel as shown below.



Figure 3-19: ACC Mode Switch

3.7.3 AT/ATX Power Mode Selection

The UPC-V315-NM70 supports both AT and ATX power modes. The setting can be made through the AT/ATX power mode switch on the bottom panel as shown below.



Figure 3-20: AT/ATX Power Mode Switch

3.7.4 Audio Connectors

The audio jacks connect to external audio devices.

- **Microphone (Pink):** Connects a microphone.
- **Line Out port (Green):** Connects to a headphone or a speaker. With multi-channel configurations, this port can also connect to front speakers.

3.7.5 CAN-bus Terminal Block

There is one 3-pin CAN-bus terminal block. The pinouts are shown in **Figure 3-21**





Figure 3-21: CAN-bus Terminal Block Pinouts

3.7.6 HDMI Connector

The HDMI connector transmits a digital signal to compatible HDMI display devices such as a TV or computer screen. To connect the HDMI cable to the UPC-V315-NM70, follow the steps below.

Step 1: **Locate the HDMI connector.** The location is shown in **Chapter 1**.

Step 2: **Align the connector.** Align the HDMI connector with the HDMI port. Make sure the orientation of the connector is correct.

**Figure 3-22: HDMI Connection**

Step 3: Insert the HDMI connector. Gently insert the HDMI connector. The connector should engage with a gentle push. If the connector does not insert easily, check again that the connector is aligned correctly, and that the connector is being inserted with the right way up.

The pinouts of the HDMI connector is shown below.

Pin	Description	Pin	Description
1	HDMI_DATA2	2	GND
3	HDMI_DATA2#	4	HDMI_DATA1
5	GND	6	HDMI_DATA1#
7	HDMI_DATA2	8	GND
9	HDMI_DATA2#	10	HDMI_CLK
11	GND	12	HDMI_CLK#
13	NC	14	NC
15	HDMI_SCL	16	HDMI_SDA
17	GND	18	+5V
19	HDMI_HPD		

Table 3-1: HDMI Pinouts

3.7.7 LAN Connector

To connect the UPC-V315-NM70 to a network through the RJ-45 LAN connector, follow the steps below.

- Step 1:** Locate the RJ-45 connector. The location of the RJ-45 connectors is shown in **Figure 1-4**.
- Step 2:** **Align the connectors.** Align the RJ-45 connector on the LAN cable with one of the RJ-45 connectors on the UPC-V315-NM70. See **Figure 3-23**.




Figure 3-23: LAN Connection

- Step 3:** **Insert the LAN cable RJ-45 connector.** Once aligned, gently insert the LAN cable RJ-45 connector into the on-board RJ-45 connector.




Figure 3-24: RJ-45 Ethernet Connector

UPC-V315-NM70 Panel PC

The pinouts of the RJ-45 LAN connector is shown below.

Pin	Description	Pin	Description
1	MDI0+	2	MDI0-
3	MDI1+	4	MDI1-
5	MDI2+	6	MDI2-
7	MDI3+	8	MDI3-

Table 3-2: LAN Pinouts

The RJ-45 Ethernet connector has two status LEDs, one green and one yellow. See **Figure 3-24**.

LED	Description	LED	Description
A	on: linked blinking: data is being sent/received	B	off: 10 Mb/s green: 100 Mb/s orange: 1000 Mb/s

Table 3-3: RJ-45 Ethernet Connector LEDs

3.7.8 Power Input, 3-pin Terminal Block

The power connector connects the leads of a 9V~36V DC power supply into the terminal block. Make sure that the power and ground wires are attached to the correct sockets of the connector.




Figure 3-25: 3-pin Terminal Block Pinouts

3.7.9 Power Input, 4-pin DIN Connector

The power connector connects to the 10.5 V ~ 36 V DC power adapter.



Figure 3-26: Power Input Connector

3.7.10 RJ-45 RS-232 Serial Port

RS-232 serial port devices can be attached to the RJ-45 RS-232 serial ports on the bottom panel. The pinouts of the RJ-45 RS-232 serial port is shown below.




Figure 3-27: RJ-45 RS-232 Serial Port Pinout Location

Pin	Description	Pin	Description
1	RI	5	RTS
2	DTR	6	RX
3.	CTS	7	DSR
4.	TX	8	DCD

Table 3-4: RJ-45 RS-232 Serial Port Pinouts




Figure 3-28: DB-9 Connector Pinout Location

Pin	Description	Pin	Description
1	DCD	6	DSR
2	RX	7	RTS

UPC-V315-NM70 Panel PC

Pin	Description	Pin	Description
3	TX	8	CTS
4	DTR	9	RI
5	GND		

Table 3-5: DB-9 Connector Pinouts

To install the RS-232 devices, follow the steps below.

Step 1: Locate the RJ-45 RS-232 connector. The location of the RJ-45 RS-232 connector is shown in **Figure 1-4**.

Step 2: Insert the RJ-45 connector. Insert the RJ-45 connector on the RJ-45 to DB-9 COM port cable to the RJ-45 RS-232 connector on the UPC-V315-NM70. See **Figure 3-29**.




Figure 3-29: RJ-45 RS-232 Serial Device Connection

Step 3: Insert the serial connector. Insert the DB-9 connector of a serial device into the DB-9 connector on the RJ-45 to DB-9 COM port cable.

Step 4: Secure the connector. Secure the serial device connector to the external interface by tightening the two retention screws on either side of the connector.

3.7.11 RJ-45 RS-422/485 Serial Port

A RS-422/485 serial port device can be connected to the RS-422/485 serial port on the bottom panel. The pinouts of the RS-422/485 serial port is shown below.




Figure 3-30: RJ-45 RS-422/485 Serial Port Pinout Location

Pin	Description	Pin	Description
1	N/A	5	N/A
2	TXD485#	6	RXD485#
3	N/A	7	N/A
4	TXD485+	8	RXD485+

Table 3-6: RJ-45 RS-422/485 Serial Port Pinouts




Figure 3-31: DB-9 Connector Pinout Location

Pin	Description (RS-422)	Description (RS-485)
1	RXD422+	N/A
2	RXD422#	N/A
3	TXD422+	TXD485+
4	TXD422#	TXD485#
5	N/A	N/A
6	N/A	N/A
7	N/A	N/A
8	N/A	N/A
9	N/A	N/A

Table 3-7: DB-9 Connector Pinouts

To install the RS-422/485 devices, follow the steps below.

UPC-V315-NM70 Panel PC

- Step 5: Locate the RJ-45 RS-422/485 connector.** The location of the RJ-45 RS-422/485 connector is shown in **Figure 1-4**.
- Step 6: Insert the RJ-45 connector.** Insert the RJ-45 connector on the RJ-45 to DB-9 COM port cable to the RJ-45 RS-422/485 connector on the UPC-V315-NM70. See **Figure 3-29**.




Figure 3-32: RJ-45 RS-422/485 Serial Device Connection

- Step 7: Insert the serial connector.** Insert the DB-9 connector of a serial device into the DB-9 connector on the RJ-45 to DB-9 COM port cable.
- Step 8: Secure the connector.** Secure the serial device connector to the external interface by tightening the two retention screws on either side of the connector.

3.7.12 USB Connectors

The USB ports are for attaching USB peripheral devices to the system. To install a USB device, follow the steps below.

- Step 1: Locate the USB connectors.** The locations of the USB connectors are shown in **Figure 1-4**.
- Step 2: Align the connectors.** Align the USB device connector with one of the connectors. See **Figure 3-33**.




Figure 3-33: USB Device Connection

Step 3: Insert the device connector. Once aligned, gently insert the USB device connector into the on-board connector.

The pinouts of the USB ports are shown below.

Pin	Description	Pin	Description
1	+5V	5	+5V
2	USB_PN0	6	USB_PN1
3	USB_PP0	7	USB_PP1
4	GND	8	GND

Table 3-8: USB Port Pinouts (USB 2.0)

3.7.13 VGA Connector

The VGA connector connects to a monitor that accepts VGA video input. The pinouts of the VGA connector is shown below.




Figure 3-34: VGA Connector

Pin	Description	Pin	Description
1	RED	2	GREEN
3	BLUE	4	NC
5	GND	6	GND
7	GND	8	GND
9	VCC / NC	10	GND
11	NC	12	DDC DAT
13	HSYNC	14	VSYNC
15	DDCCLK		

Table 3-9: VGA Connector Pinouts

To connect the UPC-V315-NM70 to a monitor that accepts VGA video input, follow the steps below,

- Step 1: Locate the female DB-15 connector.** The location of the female DB-15 connector is shown in Figure 1-4.
- Step 2: Align the VGA connector.** Align the male DB-15 connector on the VGA screen cable with the female DB-15 connector on the external peripheral interface.
- Step 3: Insert the VGA connector** Once the connectors are properly aligned with the insert the male connector from the VGA screen into the female connector on the UPC-V315-NM70. See **Figure 3-35**.




Figure 3-35: VGA Connector



CAUTION:

It is suggested that not to open the rear cover and replace any components. If the components fail, it must be shipped back to IEI to be replaced. If the system has failed, please contact the system vendor, reseller or an IEI sales person directly.

3.8 Redundant Power

The UPC-V315-NM70 is a system that supports redundant power. The redundant power input increases the reliability of the system while preventing data loss and system corruption from sudden power failure. The system can instantly and uninterruptedly switch to the second power input when the main power is unavailable or in low voltage capacity.

There are two power connectors on the bottom panel. Power 1 connector is a 3-pin terminal block that supports ACC On signal. Power 2 connector is a DIN connector that can directly connect to a power adapter. The supported power input voltages are:

- **Power 1 (Terminal block):** 9 V (+/-0.3 V) ~ 36 V
- **Power 2 (DC jack):** 10.5 V (+/-0.3 V) ~ 36 V




Figure 3-36: Power Connectors

When the system is in ACC On mode, the main power input is from the Power 1 connector. When the system is in ACC Off mode, the main power input is from the Power 2 connector. The ACC on/off mode is selected by the ACC on/off switch on the bottom panel.

(Figure 3-19).

The following sections describe how redundant power works in ACC On mode and ACC Off mode.

3.8.1 ACC ON



NOTE:

In ACC On mode, the Power 1 connector must connect to the ACC on signal to be able to control system power.

The ACC On mode is designed for vehicle applications. When the UPC-V315-NM70 is in ACC On mode, the main power input is the Power 1 connector and the backup power is from the Power 2 connector.

3.8.1.1 Boot-up

When both power connectors are connected to the power source with over 9 V, the two power LEDs on the front panel remain off until **the ACC ON signal jumps from low to high**. The user can choose AT power mode or ATX power mode to control the system. The following flow diagrams show the boot-up process and the LED status in AT and ATX power modes.




Figure 3-37: ACC On: AT Mode




Figure 3-38: ACC On: ATX Mode

3.8.1.2 Switch to Backup Power

During operation, system power will switch from Power 1 to Power 2 automatically when the following situations occur:

- Power 1 < 9V and Power 2 > 10.5V
- Power 1 > 9V, but the ACC ON signal jump from high to low
- Power 1 is unplugged and Power 2 > 10.5V

The following flow diagram shows how the power is switched between Power 1 and Power 2 and their LED statuses.






Figure 3-39: ACC On: Switch Between PWR1 and PWR2

3.8.1.3 Shutdown

The system will shutdown in the following situations:

- Power 1 < 9V and Power 2 < 10.5V
- Power 1 > 9V, Power 2 < 10.5V and ACC ON signal jump from high to low
- Press  +  buttons for 6 seconds

The following flow diagram shows the system shutdown process and the LED statuses.






Figure 3-40: ACC On: Shutdown



NOTE:

To turn on the system in ATX power mode, press the  +  button for three seconds. Press these two buttons for six seconds to turn off the system.

3.8.2 ACC OFF

When the UPC-V315-NM70 is in ACC Off mode, the main power input is the Power 2 connector and the backup power is from the Power 1 connector.

3.8.2.1 Boot-up

When both power connectors are connected to the power source with over 9 V, the two power LEDs on the front panel turn on. The user can choose AT power mode or ATX power mode to control the system. The following flow diagrams show the boot-up process and the LED status in AT and ATX power modes.




Figure 3-41: ACC Off: AT Mode




Figure 3-42: ACC Off: ATX Mode

3.8.2.2 Switch to Backup Power

During operation, system power switches from Power 2 to Power 1 automatically when the following situations occur:

- Power 2 < 10.5V and Power 1 > 9V
- Power 2 is unplugged and Power 1 > 9V

The following flow diagram shows how the power is switched between Power 2 and Power 1 and their LED statuses.




Figure 3-43: ACC Off: Switch Between PWR1 and PWR2

3.8.2.3 Shutdown

The system will shutdown in the following situations:

- Power 2 < 10.5V and Power 1 < 9V
- Press **Fn** + **⏻** buttons for 6 seconds

The following flow diagram shows the system shutdown process and the LED statuses.




Figure 3-44: ACC Off: Shutdown



NOTE:

The power LED turns off when the power cable is unplugged from the system.

3.9 Remote Control

The UPC-V315-NM70 comes with a remote control for easy configuration. **Figure 3-45** shows the remote control and its function keys.




Figure 3-45: Remote Control

- **System On/Off:** Press this button to turn the UPC-V315-NM70 on or off.
- **LCD On/Off.** Press this button to turn the LCD monitor on or off.
- **Auto-Dimming.** Press this button to turn the auto-dimming function on or off.
- **Brightness.** Use these control buttons to adjust the brightness of the LCD screen.
- **Volume.** Press these buttons to adjust the audio volume level.

Chapter

4

BIOS

4.1 Introduction

The BIOS is programmed onto the BIOS chip. The BIOS setup program allows changes to certain system settings. This chapter outlines the options that can be changed.

4.1.1 Starting Setup

The UEFI BIOS is activated when the computer is turned on. The setup program can be activated in one of two ways.

1. Press the **DEL** or **F2** key as soon as the system is turned on or
2. Press the **DEL** or **F2** key when the “**Press DEL or F2 to enter SETUP**” message appears on the screen.

If the message disappears before the **DEL** or **F2** key is pressed, restart the computer and try again.

4.1.2 Using Setup

Use the arrow keys to highlight items, press **ENTER** to select, use the PageUp and PageDown keys to change entries, press **F1** for help and press **ESC** to quit. Navigation keys are shown in.

Key	Function
Up arrow	Move to previous item
Down arrow	Move to next item
Left arrow	Move to the item on the left hand side
Right arrow	Move to the item on the right hand side
+	Increase the numeric value or make changes
-	Decrease the numeric value or make changes
Page Up key	Move to the previous page
Page Dn key	Move to the next page

Key	Function
Esc key	Main Menu – Quit and not save changes into CMOS Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu
F1	General help, only for Status Page Setup Menu and Option Page Setup Menu
F2	Load previous values
F3	Load optimized defaults
F4	Save changes and Exit BIOS

Table 4-1: BIOS Navigation Keys

4.1.3 Getting Help

When **F1** is pressed a small help window describing the appropriate keys to use and the possible selections for the highlighted item appears. To exit the Help Window press **Esc** or the **F1** key again.

4.1.4 Unable to Reboot after Configuration Changes

If the computer cannot boot after changes to the system configuration is made, CMOS defaults. Use the jumper described in Chapter 4.

4.1.5 BIOS Menu Bar

The **menu bar** on top of the BIOS screen has the following main items:

- Main – Changes the basic system configuration.
- Advanced – Changes the advanced system settings.
- Chipset – Changes the chipset settings.
- Boot – Changes the system boot configuration.
- Security – Sets User and Supervisor Passwords.
- Save & Exit – Selects exit options and loads default settings

The following sections completely describe the configuration options found in the menu items at the top of the BIOS screen and listed above.

4.2 Main

The **Main** BIOS menu (**BIOS Menu 1**) appears when the **BIOS Setup** program is entered.

The **Main** menu gives an overview of the basic system information.

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
BIOS Information					Set the Date. Use Tab to switch between Data elements.
BIOS Vendor			American Megatrends		
Core Version			4.6.5.3		
Compliance			UEFI 2.3; PI 1.2		
Project Version			SE81AR10.ROM		
Build Date and Time			04/12/2013 13:47:22		
IWDD Vender			ICP		
IWDD Version			SE81ER10.BIN		
Processor Information					
Name			SandyBridge		
Brand String			Intel(R) Celeron(R) CPU		
Frequency			1100 MHz		
Processor ID			206a7		
Stepping			D2		
Number of Processors			2Core(s) / 2Thread(s)		
Microcode Revision			28		
GT Info			GT2 (800 MHz)		
IGFX VBIOS Version			2137		
Memory RC Version			1.2.2.0		
Total Memory			2048 MB (DDR3)		
Memory Frequency			1333 MHz		
PCH Information					
Name			PantherPoint		
Stepping			04/C1		
LAN PHY Revision			C0		
ME FW Version			8.1.0.1248		
ME Firmware SKU			1.5MB		

SPI Clock Frequency			Supported		
DOFR Support			Supported		
Read Status Clock Frequency			33 MHz		
Write Status Clock Frequency			33 MHz		
Fast Read Status Clock Frequency			33 MHz		
System Date			[Mon 04/22/2013]		
System Time			[15:10:27]		
Access Level			Administrator		
Version 2.15.1229. Copyright (C) 2012 American Megatrends, Inc.					

Set the Date. Use Tab to switch between Data elements.

→←: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

BIOS Menu 1: Main

➔ System Overview

The system overview lists a brief summary of the BIOS. The fields in system overview cannot be changed. The items shown in the system overview include:

- BIOS Information
- IWDD Information
- Processor Information
- Memory Information
- PCH Information
- ME Information
- SPI Clock Frequency

The **Main** menu has two user configurable fields:

➔ System Date [xx/xx/xx]

Use the **System Date** option to set the system date. Manually enter the day, month and year.

➔ System Time [xx:xx:xx]

Use the **System Time** option to set the system time. Manually enter the hours, minutes and seconds.

4.3 Advanced


Use the **Advanced** menu (**BIOS Menu 2**) to configure the CPU and peripheral devices through the following sub-menus:



WARNING!

Setting the wrong values in the sections below may cause the system to malfunction. Make sure that the settings made are compatible with the hardware.


UPC-V315-NM70 Panel PC



BIOS Menu 2: Advanced

4.3.1 ACPI Settings

The **ACPI Settings** menu (**BIOS Menu 3**) configures the Advanced Configuration and Power Interface (ACPI) options.



BIOS Menu 3: ACPI Configuration


→ ACPI Sleep State [S1 (CPU Stop Clock)]

Use the **ACPI Sleep State** option to specify the sleep state the system enters when it is not being used.

- | | |
|-------------------------------------|--|
| <p>→ S1 (CPU Stop Clock)</p> | <p>DEFAULT The system enters S1 (POS) sleep state. The system appears off. The CPU is stopped; RAM is refreshed; the system is running in a low power mode.</p> |
| <p>→ S3 (Suspend to RAM)</p> | <p>The caches are flushed and the CPU is powered off. Power to the RAM is maintained. The computer returns slower to a working state, but more power is saved.</p> |

4.3.2 RTC Wake Settings

The **RTC Wake Settings** menu (**BIOS Menu 4**) enables the system to wake at the specified time.



BIOS Menu 4: RTC Wake Settings

UPC-V315-NM70 Panel PC

→ Wake system with Fixed Time [Disabled]

Use the **Wake system with Fixed Time** option to enable or disable the system wake on alarm event.

→ **Disabled** **DEFAULT** The real time clock (RTC) cannot generate a wake event

→ **Enabled** If selected, the **Wake up every day** option appears allowing you to enable to disable the system to wake every day at the specified time. Besides, the following options appear with values that can be selected:

Wake up date

Wake up hour


Wake up minute

Wake up second

After setting the alarm, the computer turns itself on from a suspend state when the alarm goes off.

4.3.3 CPU Configuration

Use the **CPU Configuration** menu (**BIOS Menu 5**) to view detailed CPU specifications or enable the Intel Virtualization Technology.



BIOS Menu 5: CPU Configuration

→ Intel Virtualization Technology [Disabled]

Use the **Intel Virtualization Technology** option to enable or disable virtualization on the system. When combined with third party software, Intel® Virtualization technology allows several OSs to run on the same system at the same time.

- **Disabled** **DEFAULT** Disables Intel Virtualization Technology.
- **Enabled** Enables Intel Virtualization Technology.

4.3.4 SATA Configuration

Use the **SATA Configuration** menu (**BIOS Menu 6**) to change and/or set the configuration of the SATA devices installed in the system.



BIOS Menu 6: SATA Configuration


→ SATA Mode Selection [IDE]

Use the **SATA Mode Selection** option to configure SATA devices as normal IDE devices.

- **IDE** **DEFAULT** Configures SATA devices as normal IDE device.
- **AHCI** Configures SATA devices as AHCI device.

4.3.5 USB Configuration

Use the **USB Configuration** menu (**BIOS Menu 7**) to read USB configuration information and configure the USB settings.



BIOS Menu 7: USB Configuration

➔ USB Devices

The **USB Devices** field lists the USB devices that are enabled on the system

➔ Legacy USB Support [Enabled]

Use the **Legacy USB Support** BIOS option to enable USB mouse and USB keyboard support. Normally if this option is not enabled, any attached USB mouse or USB keyboard does not become available until a USB compatible operating system is fully booted with all USB drivers loaded. When this option is enabled, any attached USB mouse or USB keyboard can control the system even when there is no USB driver loaded onto the system.


➔ **Enabled** **DEFAULT** Legacy USB support enabled

UPC-V315-NM70 Panel PC

- ➔ **Disabled** Legacy USB support disabled
- ➔ **Auto** Legacy USB support disabled if no USB devices are connected

4.3.6 F81866 Super IO Configuration


Use the **F81866 Super IO Configuration** menu (**BIOS Menu 8**) to set or change the configurations for the parallel ports and serial ports.



BIOS Menu 8: F81866 Super IO Configuration

4.3.6.1 Serial Port n Configuration

Use the **Serial Port n Configuration** menu (**BIOS Menu 9**) to configure the serial port n.



BIOS Menu 9: Serial Port n Configuration Menu

4.3.6.1.1 Serial Port 1 Configuration

→ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- **Disabled** Disable the serial port
- **Enabled** **DEFAULT** Enable the serial port

→ Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.
- **IO=3F8h; IRQ=4** Serial Port I/O port address is 3F8h and the interrupt address is IRQ4

- ➔ **IO=3F8h;**
IRQ=3, 4 Serial Port I/O port address is 3F8h and the interrupt address is IRQ3, 4
- ➔ **IO=2F8h;**
IRQ=3, 4 Serial Port I/O port address is 2F8h and the interrupt address is IRQ3, 4

4.3.6.1.2 Serial Port 2 Configuration

➔ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled** Disable the serial port
- ➔ **Enabled** **DEFAULT** Enable the serial port

➔ Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

- ➔ **Auto** **DEFAULT** The serial port IO port address and interrupt address are automatically detected.
- ➔ **IO=2F8h;**
IRQ=3 Serial Port I/O port address is 2F8h and the interrupt address is IRQ3
- ➔ **IO=3F8h;**
IRQ=3, 4 Serial Port I/O port address is 3F8h and the interrupt address is IRQ3, 4
- ➔ **IO=2F8h;**
IRQ=3, 4 Serial Port I/O port address is 2F8h and the interrupt address is IRQ3, 4

4.3.6.1.3 Serial Port 3 Configuration

➔ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

- ➔ **Disabled** Disable the serial port

➔ **Enabled** **DEFAULT** Enable the serial port

➔ Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.

➔	Auto	DEFAULT	The serial port IO port address and interrupt address are automatically detected.
➔	IO=2E0h; IRQ=5		Serial Port I/O port address is 2E0h and the interrupt address is IRQ5
➔	IO=2E0h; IRQ=5, 7		Serial Port I/O port address is 2E0h and the interrupt address is IRQ5, 7
➔	IO=2E8h; IRQ=5, 7		Serial Port I/O port address is 2E8h and the interrupt address is IRQ5, 7

4.3.6.1.4 Serial Port 4 Configuration

➔ Serial Port [Enabled]

Use the **Serial Port** option to enable or disable the serial port.

➔	Disabled		Disable the serial port
➔	Enabled	DEFAULT	Enable the serial port

➔ Change Settings [Auto]

Use the **Change Settings** option to change the serial port IO port address and interrupt address.


➔	Auto	DEFAULT	The serial port IO port address and interrupt address are automatically detected.
➔	IO=2E8h; IRQ=7		Serial Port I/O port address is 2E8h and the interrupt address is IRQ7

UPC-V315-NM70 Panel PC

- ➔ **IO=2E0h;** Serial Port I/O port address is 2E0h and the interrupt
IRQ=5, 7 address is IRQ5, 7
- ➔ **IO=2E8h;** Serial Port I/O port address is 2E8h and the interrupt
IRQ=5, 7 address is IRQ5, 7

4.3.7 H/W Monitor

The H/W Monitor menu (**BIOS Menu 10**) shows the operating temperature, fan speeds and system voltages.



BIOS Menu 10: Hardware Health Configuration

➔ PC Health Status


The following system parameters and values are shown. The system parameters that are monitored are:

- Temperatures:
 - CPU Temperature
 - System Temperature
- Voltages:
 - V_CORE

- V_5S
- V_12S
- V_1.5V
- VSB5V
- VCC3V
- VSB3V

4.3.8 Serial Port Console Redirection

The **Serial Port Console Redirection** menu (**BIOS Menu 11**) allows the console redirection options to be configured. Console redirection allows users to maintain a system remotely by re-directing keyboard input and text output through the serial port.



BIOS Menu 11: Serial Port Console Redirection

➔ Console Redirection [Disabled]

Use **Console Redirection** option to enable or disable the console redirection function.

- ➔ **Disabled** **DEFAULT** Disabled the console redirection function
- ➔ **Enabled** Enabled the console redirection function

UPC-V315-NM70 Panel PC

→ Terminal Type [ANSI]

Use the **Terminal Type** option to specify the remote terminal type.

- **VT100** The target terminal type is VT100
- **VT100+** The target terminal type is VT100+
- **VT-UTF8** The target terminal type is VT-UTF8
- **ANSI** **DEFAULT** The target terminal type is ANSI

→ Bits per second [115200]

Use the **Bits per second** option to specify the serial port transmission speed. The speed must match the other side. Long or noisy lines may require lower speeds.

- **9600** Sets the serial port transmission speed at 9600.
- **19200** Sets the serial port transmission speed at 19200.
- **38400** Sets the serial port transmission speed at 38400.
- **57600** Sets the serial port transmission speed at 57600.
- **115200** **DEFAULT** Sets the serial port transmission speed at 115200.

→ Data Bits [8]

Use the **Data Bits** option to specify the number of data bits.

- **7** Sets the data bits at 7.
- **8** **DEFAULT** Sets the data bits at 8.

→ Parity [None]

Use the **Parity** option to specify the parity bit that can be sent with the data bits for detecting the transmission errors.

- **None** **DEFAULT** No parity bit is sent with the data bits.

- ➔ **Even** The parity bit is 0 if the number of ones in the data bits is even.
- ➔ **Odd** The parity bit is 0 if the number of ones in the data bits is odd.
- ➔ **Mark** The parity bit is always 1. This option does not provide error detection.
- ➔ **Space** The parity bit is always 0. This option does not provide error detection.

➔ **Stop Bits [1]**


Use the **Stop Bits** option to specify the number of stop bits used to indicate the end of a serial data packet. Communication with slow devices may require more than 1 stop bit.

- ➔ **1** **DEFAULT** Sets the number of stop bits at 1.
- ➔ **2** Sets the number of stop bits at 2.

4.3.9 iEi Feature

Use the **iEi Feature** menu (**BIOS Menu 12**) to configure One Key Recovery function.

UPC-V315-NM70 Panel PC



BIOS Menu 12: iEi Feature

→ Auto Recovery Function [Disabled]

Use the **Auto Recovery Function** BIOS option to enable or disable the auto recovery function of the IEI One Key Recovery.

- **Disabled** **DEFAULT** Auto recovery function disabled
- **Enabled** Auto recovery function enabled


4.4 Chipset

Use the **Chipset** menu (**BIOS Menu 13**) to access the PCH IO and System Agent (SA) configuration menus.



WARNING!

Setting the wrong values for the Chipset BIOS selections in the Chipset BIOS menu may cause the system to malfunction.




BIOS Menu 13: Chipset

UPC-V315-NM70 Panel PC

4.4.1 PCH-IO Configuration

Use the **PCH-IO Configuration** menu (**BIOS Menu 14**) to configure the PCH parameters.



BIOS Menu 14: PCH-IO Configuration

➔ WIFI Support [Enabled]

Use the **WIFI Support** option to enable or disable the Wi-Fi function.

- ➔ **Enabled** **DEFAULT** Enables Wi-Fi function
- ➔ **Disabled** Disables Wi-Fi function

➔ Bluetooth Support [Disabled]

Use the **Bluetooth Support** option to enable or disable the Bluetooth function.

- ➔ **Enabled** Enables Bluetooth function
- ➔ **Disabled** **DEFAULT** Disables Bluetooth function

➔ 3G Support [Disabled]

Use the **3G Support** option to enable or disable the 3G connection.

- ➔ **Enabled** Enables 3G connection

➔ **Disabled** **DEFAULT** Disables 3G connection

➔ GPS Support [Disabled]

Use the **GPS Support** option to enable or disable the GPS function.

➔ **Enabled** Enables GPS function

➔ **Disabled** **DEFAULT** Disables GPS function

➔ MIC Support [Enabled]

Use the **MIC Support** option to enable or disable the microphone.

➔ **Enabled** **DEFAULT** Enables microphone

➔ **Disabled** Disables microphone

➔ Auto Dimming Support [Disabled]

Use the **Auto Dimming Support** option to enable or disable the auto dimming function.

➔ **Enabled** Enables auto dimming function

➔ **Disabled** **DEFAULT** Disables auto dimming function

➔ Power Saving Function [Disabled]


Use the **Power Saving Function** BIOS option to enable or disable the power saving function.

➔ **Enabled** Power saving function is enabled. It will reduce power consumption when the system is off.

➔ **Disabled** **DEFAULT** Power saving function is disabled.

4.4.1.1 PCH Azalia Configuration

Use the **PCH Azalia Configuration** menu (**BIOS Menu 15**) to configure the PCH Azalia settings.



BIOS Menu 15: PCH Azalia Configuration Menu

➔ Azalia [Enabled]

Use the **Azalia** option to enable or disable the High Definition Audio controller.

- ➔ **Disabled** The onboard High Definition Audio controller is disabled
- ➔ **Enabled** **DEFAULT** The onboard High Definition Audio controller automatically detected and enabled


➔ Azalia internal HDMI codec [Enabled]

Use the **Azalia internal HDMI codec** option to enable or disable the internal HDMI codec for High Definition Audio.

- ➔ **Disabled** Disables the internal HDMI codec for High Definition Audio
- ➔ **Enabled** **DEFAULT** Enables the internal HDMI codec for High Definition Audio

4.4.2 System Agent (SA) Configuration

Use the **System Agent (SA) Configuration** menu (**BIOS Menu 16**) to configure the System Agent (SA) parameters.




BIOS Menu 16: System Agent (SA) Configuration

4.4.2.1 Graphics Configuration

Use the **Graphics Configuration** (**BIOS Menu 17**) menu to configure the video device connected to the system.

UPC-V315-NM70 Panel PC



BIOS Menu 17: Graphics Configuration

→ Primary Display [Auto]

Use the **Primary Display** option to select the primary graphics controller the system uses.

The following options are available:

- Auto **Default**
- IGFX
- PEG
- PCI
- SG

→ DVTM Pre-Allocated [256M]

Use the **DVTM Pre-Allocated** option to set the amount of system memory allocated to the integrated graphics processor when the system boots. The system memory allocated can then only be used as graphics memory, and is no longer available to applications or the operating system. Configuration options are listed below:


- 32M
- 64M
- 128M
- 256M **Default**
- 512M

➔ DVMT Total Gfx Mem [MAX]

Use the **DVMT Total Gfx Mem** option to select DVMT5.0 total graphic memory size used by the internal graphic device. The following options are available:

- 128M
- 256M
- MAX **Default**

4.4.2.1.1 LCD Control



BIOS Menu 18: LCD Control

➔ Primary IGFX Boot Display [VBIOS]

Use the **Primary IGFX Boot Display** option to select the display device used by the system when it boots. Configuration options are listed below.

- VBIOS **DEFAULT**
- CRT
- HDMI
- LVDS

UPC-V315-NM70 Panel PC

➔ LCD Panel Type [VBIOS]

Use the **LCD Panel Type** option to select the type of flat panel connected to the system.
Configuration options are listed below.


VBIOS	DEFAULT
640x480	LVDS
800x600	LVDS
1024x768	LVDS1
1280x1024	LVDS
1400x1050(RB)	LVDS1
1400x1050	LVDS2
1600x1200	LVDS
1366x768	LVDS
1680x1050	LVDS
1920x1200	LVDS
1440x900	LVDS
1600x900	LVDS
1024x768	LVDS2
1280x800	LVDS
1920x1080	LVDS
2048x1536	LVDS

➔ Backlight Control [Inverted]

Use the **Backlight Control** option to select the backlight control mode.

➔ Inverted	DEFAULT	Brightest at low voltage level
➔ Normal		Brightest at high voltage level

4.4.2.2 NB PCIe Configuration



BIOS Menu 19: NB PCIe Configuration


➔ PEG0 – Gen X [Auto]

Use the **PEG0 – Gen X** option to select the support type of the PCI Express (PEG) controller. The following options are available:

- Auto **Default**
- Gen1
- Gen2
- Gen3

4.4.2.3 Memory Configuration


Use the **Memory Configuration** submenu (**BIOS Menu 20**) to view memory information.



BIOS Menu 20: Memory Configuration

4.5 Boot

Use the **Boot** menu (**BIOS Menu 21**) to configure system boot options.



BIOS Menu 21: Boot

→ Bootup NumLock State [On]

Use the **Bootup NumLock State** BIOS option to specify if the number lock setting must be modified during boot up.

- | | | | |
|---|------------|----------------|--|
| → | On | DEFAULT | Allows the Number Lock on the keyboard to be enabled automatically when the computer system boots up. This allows the immediate use of the 10-key numeric keypad located on the right side of the keyboard. To confirm this, the Number Lock LED light on the keyboard is lit. |
| → | Off | | Does not enable the keyboard Number Lock automatically. To use the 10-keys on the keyboard, press the Number Lock key located on the upper left-hand corner of the 10-key pad. The Number Lock LED on the keyboard lights up when the Number Lock is engaged. |

→ Quiet Boot [Enabled]

Use the **Quiet Boot** BIOS option to select the screen display when the system boots.

- | | | | |
|---|-----------------|----------------|---|
| → | Disabled | | Normal POST messages displayed |
| → | Enabled | DEFAULT | OEM Logo displayed instead of POST messages |

→ Launch PXE OpROM [Disabled]

Use the **Launch PXE OpROM** option to enable or disable boot option for legacy network devices.

- | | | | |
|---|-----------------|----------------|----------------------------|
| → | Disabled | DEFAULT | Ignore all PXE Option ROMs |
| → | Enabled | | Load PXE Option ROMs. |

→ Option ROM Messages [Keep Current]

Use the **Option ROM Messages** option to set the Option ROM display mode.

UPC-V315-NM70 Panel PC

➔ **Force BIOS** Sets display mode to force BIOS.

➔ **Keep Current** **DEFAULT** Sets display mode to current.

➔ UEFI Boot [Disabled]

Use the **UEFI Boot** option to enable or disable to boot from the UEFI devices.

➔ **Enabled** Boot from UEFI devices is enabled.


➔ **Disabled** **DEFAULT** Boot from UEFI devices is disabled.

➔ Boot Option Priority

Use the **Boot Option Priority** function to set the system boot sequence from the available devices. The drive sequence also depends on the boot sequence in the individual device section.

4.6 Security

Use the **Security** menu (**BIOS Menu 22**) to set system and user passwords.



BIOS Menu 22: Security

➔ Administrator Password


Use the **Administrator Password** to set or change a administrator password.

➔ User Password

Use the **User Password** to set or change a user password.

4.7 Save & Exit

Use the **Safe & Exit** menu (**BIOS Menu 23**) to load default BIOS values, optimal failsafe values and to save configuration changes.



BIOS Menu 23: Save & Exit

➔ Save Changes and Reset

Use the **Save Changes and Reset** option to save the changes made to the BIOS options and reset the system.

➔ Discard Changes and Reset

Use the **Discard Changes and Reset** option to exit the system without saving the changes made to the BIOS configuration setup program.

➔ Restore Defaults

Use the **Restore Defaults** option to load the optimal default values for each of the parameters on the Setup menus. **F3 key can be used for this operation.**

➔ Save as User Defaults

Use the **Save as User Defaults** option to save the changes done so far as user defaults.

➔ Restore User Defaults

Use the **Restore User Defaults** option to restore the user defaults to all the setup options.

Appendix

A

BIOS Menu Options

➔ System Overview	54
➔ System Date [xx/xx/xx]	54
➔ System Time [xx:xx:xx]	54
➔ ACPI Sleep State [S1 (CPU Stop Clock)]	56
➔ Wake system with Fixed Time [Disabled]	57
➔ Intel Virtualization Technology [Disabled]	58
➔ SATA Mode Selection [IDE]	59
➔ USB Devices	60
➔ Legacy USB Support [Enabled]	60
➔ Serial Port [Enabled]	62
➔ Change Settings [Auto]	62
➔ Serial Port [Enabled]	63
➔ Change Settings [Auto]	63
➔ Serial Port [Enabled]	63
➔ Change Settings [Auto]	64
➔ Serial Port [Enabled]	64
➔ Change Settings [Auto]	64
➔ PC Health Status	65
➔ Console Redirection [Disabled]	66
➔ Terminal Type [ANSI]	67
➔ Bits per second [115200]	67
➔ Data Bits [8]	67
➔ Parity [None]	67
➔ Stop Bits [1]	68
➔ Auto Recovery Function [Disabled]	69
➔ WIFI Support [Enabled]	71
➔ Bluetooth Support [Disabled]	71
➔ 3G Support [Disabled]	71
➔ GPS Support [Disabled]	72
➔ MIC Support [Enabled]	72
➔ Auto Dimming Support [Disabled]	72
➔ Power Saving Function [Disabled]	72
➔ Azalia [Enabled]	73
➔ Azalia internal HDMI codec [Enabled]	73

UPC-V315-NM70 Panel PC

➔ Primary Display [Auto]	75
➔ DVMT Pre-Allocated [256M]	75
➔ DVMT Total Gfx Mem [MAX].....	76
➔ Primary IGFX Boot Display [VBIOS]	76
➔ LCD Panel Type [VBIOS].....	77
➔ Backlight Control [Inverted].....	77
➔ PEG0 – Gen X [Auto]	78
➔ Bootup NumLock State [On].....	80
➔ Quiet Boot [Enabled]	80
➔ Launch PXE OpROM [Disabled]	80
➔ Option ROM Messages [Keep Current]	80
➔ UEFI Boot [Disabled]	81
➔ Boot Option Priority.....	81
➔ Administrator Password	82
➔ User Password	82
➔ Save Changes and Reset	83
➔ Discard Changes and Reset	83
➔ Restore Defaults	83
➔ Save as User Defaults	84
➔ Restore User Defaults	84

Appendix

B

One Key Recovery

B.1 One Key Recovery Introduction

The IEI one key recovery is an easy-to-use front end for the Norton Ghost system backup and recovery tool. This tool provides quick and easy shortcuts for creating a backup and reverting to that backup or reverting to the factory default settings.



NOTE:

The latest One Key Recovery software provides an auto recovery function that allows a system running Microsoft Windows OS to automatically restore from the factory default image after encountering a Blue Screen of Death (BSOD) or a hang for around 10 minutes. Please refer to Section B.3 for the detailed setup procedure.

The IEI One Key Recovery tool menu is shown below.




Figure B-1: IEI One Key Recovery Tool Menu

Prior to using the IEI One Key Recovery tool (as shown in **Figure B-1**) to backup or restore Windows system, five setup procedures are required.

1. Hardware and BIOS setup (see **Section B.2.1**)
2. Create partitions (see **Section B.2.2**)
3. Install operating system, drivers and system applications (see **Section B.2.3**)
4. Build the recovery partition (see **Section B.2.4**)
5. Create factory default image (see **Section B.2.5**)

After completing the five initial setup procedures as described above, users can access the recovery tool by pressing <F3> while booting up the system. The detailed information of each function is described in **Section B.5**.



NOTE:


The initial setup procedures for Linux system are described in **Section B.3**.

B.1.1 System Requirement



NOTE:

The recovery CD can only be used with IEI products. The software will fail to run and a warning message will appear when used on non-IEI hardware.



To create the system backup, the main storage device must be split into two partitions (three partitions for Linux). The first partition will be for the operating system, while the second partition will be invisible to the operating system and contain the backup made by the one key recovery software.

The partition created for recovery images must be big enough to contain both the factory default image and the user backup image. The size must be calculated before creating the

partitions. Please take the following table as a reference when calculating the size of the partition.

	OS	OS Image after Ghost	Compression Ratio
Windows® 7	7 GB	5 GB	70%
Windows® XPE	776 MB	560 MB	70%
Windows® CE 6.0	36 MB	28 MB	77%



NOTE:

Specialized tools are required to change the partition size if the operating system is already installed.

B.1.2 Supported Operating System

The recovery CD is compatible with both Microsoft Windows and Linux operating systems (OS). The supported OS versions are listed below.

- Microsoft Windows
 - Windows XP (Service Pack 2 or 3 required)
 - Windows Vista
 - Windows 7
 - Windows CE 5.0
 - Windows CE 6.0
 - Windows XP Embedded
- Linux
 - Fedora Core 12 (Constantine)
 - Fedora Core 11 (Leonidas)
 - Fedora Core 10 (Cambridge)
 - Fedora Core 8 (Werewolf)
 - Fedora Core 7 (Moonshine)
 - RedHat RHEL-5.4
 - RedHat 9 (Ghirke)

- Ubuntu 8.10 (Intrepid)
- Ubuntu 7.10 (Gutsy)
- Ubuntu 6.10 (Edgy)
- Debian 5.0 (Lenny)
- Debian 4.0 (Etch)
- SuSe 11.2
- SuSe 10.3

**NOTE:**

Installing unsupported OS versions may cause the recovery tool to fail.

B.2 Setup Procedure for Windows

Prior to using the recovery tool to backup or restore, a few setup procedures are required.

Step 4: Hardware and BIOS setup (see **Section B.2.1**)

Step 5: Create partitions (see **Section B.2.2**)

Step 6: Install operating system, drivers and system applications (see **Section B.2.3**)

Step 7: Build the recovery partition (see **Section B.2.4**) or build the auto recovery partition (see **Section B.3**)

Step 8: Create factory default image (see **Section B.2.5**)

The detailed descriptions are described in the following sections.

**NOTE:**

The setup procedures described below are for Microsoft Windows operating system users. For Linux, most of the setup procedures are the same except for several steps described in **Section B.3**.

B.2.1 Hardware and BIOS Setup

- Step 1:** Make sure the system is powered off and unplugged.
- Step 2:** Install a hard drive or SSD in the system. An unformatted and unpartitioned disk is recommended.
- Step 3:** Connect an optical disk drive to the system and insert the recovery CD.
- Step 4:** Turn on the system.
- Step 5:** Press the <**DELETE**> key as soon as the system is turned on to enter the BIOS.
- Step 6:** Select the connected optical disk drive as the 1st boot device. (**Boot → Boot Device Priority → 1st Boot Device**).
- Step 7:** Save changes and restart the computer. Continue to the next section for instructions on partitioning the internal storage.

B.2.2 Create Partitions

To create the system backup, the main storage device must be split into two partitions (three partitions for Linux). The first partition will be for the operating system, while the second partition will be invisible to the operating system and contain the backup made by the one key recovery software.

- Step 1:** Put the recovery CD in the optical drive of the system.
- Step 2:** **Boot the system from recovery CD.** When prompted, press any key to boot from the recovery CD. It will take a while to launch the recovery tool. Please be patient!




Figure B-2: Launching the Recovery Tool

Step 3: The recovery tool setup menu is shown as below.




Figure B-3: Recovery Tool Setup Menu

Step 4: Press <6> then <Enter>.




Figure B-4: Command Prompt

Step 5: The command prompt window appears. Type the following commands (marked in red) to create two partitions. One is for the OS installation; the other is for saving recovery files and images which will be an invisible partition. (Press <Enter> after entering each line below)

```
system32>diskpart
DISKPART>list vol
DISKPART>sel disk 0
DISKPART>create part pri size= ____
DISKPART>assign letter=N
DISKPART>create part pri size= ____
DISKPART>assign letter=F
DISKPART>exit
system32>format N: /fs:ntfs /q /y
system32>format F: /fs:ntfs /q /v:Recovery /y
system32>exit
```

```
X:\I386\SYSTEM32\CMD.EXE
X:\I386\SYSTEM32>diskpart → Starts the Microsoft disk partitioning tool.
Microsoft DiskPart version 5.2.3790.1830
Copyright (C) 1999-2001 Microsoft Corporation.
On computer: MININT-JUC

DISKPART>list vol → Show partition information

Volume ### Ltr Label Fs Type Size Status Info
-----
Volume 0 X CD_ROM CDFS DVD-ROM 405 MB Healthy Boot
Volume 1 D FAT32 Removeable 3854 MB Healthy

DISKPART>sel disk 0 → Select a disk
Disk 0 is now the selected disk.

DISKPART>create part pri size=2000 → Create partition 1 and assign a size.
This partition is for OS installation.
DiskPart succeeded in creating the specified partition.

DISKPART>assign letter=N → Assign partition 1 a code name (N).
DiskPart successfully assigned the drive letter or mount point.

DISKPART>create part pri size=1800 → Create partition 2 and assign a size.
This partition is for recovery images.
DiskPart succeeded in creating the specified partition.

DISKPART>assign letter=F → Assign partition 2 a code name (F).
DiskPart successfully assigned the drive letter or mount point.

DISKPART>exit → Exit diskpart
X:\I386\SYSTEM32>format n: /fs:ntfs /q /y → Format partition 1 (N) as NTFS format.
The type of the file system is RAW.
The new file system is NTFS.
QuickFormatting 2000M
Creating file system structures.
Format complete.
2048254 KB total disk space.
2035620 KB are available.

X:\I386\SYSTEM32>format f: /fs:ntfs /q /v:Recovery /y → Formate partition 2 (F) as NTFS formate and
name it as "Recovery".
The type of the file system is RAW.
The new file system is NTFS.
QuickFormatting 1800M
Creating file system structures.
Format complete.
1847474 KB total disk space.
1835860 KB are available.

X:\I386\SYSTEM32>exit → Exit Windows PE
```

Figure B-5: Partition Creation Commands

**NOTE:**

Use the following commands to check if the partitions were created successfully.

```
X:\I386\SYSTEM32>diskpart
Microsoft DiskPart version 5.2.3790.1830
Copyright (C) 1999-2001 Microsoft Corporation.
On computer: MININT-JUC

DISKPART> sel disk 0
Disk 0 is now the selected disk.

DISKPART> list part

   Partition ###   Type              Size          Offset
-----
Partition 1        Primary           2000 MB         32 KB
Partition 2        Primary          1804 MB        2000 MB

DISKPART> exit
```

Step 6: Press any key to exit the recovery tool and automatically reboot the system.

Please continue to the following procedure: Build the Recovery Partition.

B.2.3 Install Operating System, Drivers and Applications

Install the operating system onto the unlabelled partition. The partition labeled "Recovery" is for use by the system recovery tool and should not be used for installing the operating system or any applications.

**NOTE:**

The operating system installation program may offer to reformat the chosen partition. DO NOT format the partition again. The partition has already been formatted and is ready for installing the new operating system.

To install the operating system, insert the operating system installation CD into the optical drive. Restart the computer and follow the installation instructions.

B.2.4 Building the Recovery Partition

- Step 1:** Put the recover CD in the optical drive.
- Step 2:** Start the system.
- Step 3:** **Boot the system from the recovery CD.** When prompted, press any key to boot from the recovery CD. It will take a while to launch the recovery tool. Please be patient!




Figure B-6: Launching the Recovery Tool

- Step 4:** When the recovery tool setup menu appears, press <2> then <Enter>.




Figure B-7: Manual Recovery Environment for Windows

UPC-V315-NM70 Panel PC

Step 5: The Symantec Ghost window appears and starts configuring the system to build a recovery partition. In this process the partition created for recovery files in **Section B.2.2** is hidden and the recovery tool is saved in this partition.




Figure B-8: Building the Recovery Partition

Step 6: After completing the system configuration, press any key in the following window to reboot the system.




Figure B-9: Press Any Key to Continue

Step 7: Eject the recovery CD.

B.2.5 Create Factory Default Image



NOTE:

Before creating the factory default image, please configure the system to a factory default environment, including driver and application installations.

To create a factory default image, please follow the steps below.

Step 1: Turn on the system. When the following screen displays (**Figure B-10**), press the <F3> key to access the recovery tool. The message will display for 10 seconds, please press F3 before the system boots into the operating system.




Figure B-10: Press F3 to Boot into Recovery Mode

Step 2: The recovery tool menu appears. Type <4> and press <Enter>. (**Figure B-11**)




Figure B-11: Recovery Tool Menu

Step 3: The About Symantec Ghost window appears. Click **OK** button to continue.

UPC-V315-NM70 Panel PC




Figure B-12: About Symantec Ghost Window

Step 4: Use mouse to navigate to the option shown below (**Figure B-13**).




Figure B-13: Symantec Ghost Path

Step 5: Select the local source drive (Drive 1) as shown in **Figure B-14**. Then click OK.




Figure B-14: Select a Local Source Drive

Step 6: Select a source partition (Part 1) from basic drive as shown in **Figure B-15**.
Then click OK.




Figure B-15: Select a Source Partition from Basic Drive

Step 7: Select **1.2: [Recovery] NTFS drive** and enter a file name called **iei** (**Figure B-16**). Click **Save**. The factory default image will then be saved in the selected recovery drive and named IEI.GHO.



WARNING:

The file name of the factory default image must be **iei.GHO**.




Figure B-16: File Name to Copy Image to

Step 8: When the Compress Image screen in **Figure B-17** prompts, click **High** to make the image file smaller.




Figure B-17: Compress Image

Step 9: The Proceed with partition image creation window appears, click **Yes** to continue.




Figure B-18: Image Creation Confirmation

Step 10: The Symantec Ghost starts to create the factory default image (**Figure B-19**).




Figure B-19: Image Creation Complete

Step 11: When the image creation completes, a screen prompts as shown in **Figure B-20**.

Click **Continue** and close the Ghost window to exit the program.




Figure B-20: Image Creation Complete

Step 12: The recovery tool main menu window is shown as below. Press any key to reboot the system.




Figure B-21: Press Any Key to Continue

B.3 Auto Recovery Setup Procedure

The auto recovery function allows a system to automatically restore from the factory default image after encountering a Blue Screen of Death (BSoD) or a hang for around 10 minutes. To use the auto recovery function, follow the steps described in the following sections.



CAUTION:

The setup procedure may include a step to create a factory default image. It is suggested to configure the system to a factory default environment before the configuration, including driver and application installations.

Step 1: Follow the steps described in **Section B.2.1 ~ Section B.2.3** to setup BIOS, create partitions and install operating system.

Step 2: Install the auto recovery utility into the system by double clicking the **Utility/AUTORECOVERY-SETUP.exe** in the One Key Recovery CD. This utility **MUST** be installed in the system, otherwise, the system will automatically restore from the factory default image every ten (10) minutes.



Figure B-22: Auto Recovery Utility

Step 3: Reboot the system from the recovery CD. When prompted, press any key to boot from the recovery CD. It will take a while to launch the recovery tool. Please be patient!




Figure B-23: Launching the Recovery Tool

Step 4: When the recovery tool setup menu appears, press <4> then <Enter>.




Figure B-24: Auto Recovery Environment for Windows

UPC-V315-NM70 Panel PC

Step 5: The Symantec Ghost window appears and starts configuring the system to build an auto recovery partition. In this process the partition created for recovery files in **Section B.2.2** is hidden and the auto recovery tool is saved in this partition.




Figure B-25: Building the Auto Recovery Partition

Step 6: After completing the system configuration, the following message prompts to confirm whether to create a factory default image. Type **Y** to have the system create a factory default image automatically. Type **N** within 6 seconds to skip this process (The default option is YES). It is suggested to choose YES for this option.



Figure B-26: Factory Default Image Confirmation

Step 7: The Symantec Ghost starts to create the factory default image (**Figure B-27**).




Figure B-27: Image Creation Complete

Step 8: After completing the system configuration, press any key in the following window to restart the system.





Figure B-28: Press any key to continue

Step 9: Eject the One Key Recovery CD and restart the system.

Step 10: Press the <DELETE> key as soon as the system is turned on to enter the BIOS.

Step 11: Enable the Auto Recovery Function option (**Advanced** → **iEi Feature** → **Auto Recovery Function**).



BIOS Menu 24: IEI Feature

Step 12: Save changes and restart the system. If the system encounters a Blue Screen of Death (BSoD) or a hang for around 10 minutes, it will automatically restore from the factory default image.



CAUTION:

The auto recovery function can only apply on a Microsoft Windows system running the following OS versions:

- Windows XP
- Windows Vista
- Windows 7

B.4 Setup Procedure for Linux

The initial setup procedure for Linux system is mostly the same with the procedure for Microsoft Windows. Please follow the steps below to setup recovery tool for Linux OS.

Step 1: **Hardware and BIOS setup.** Refer to **Section B.2.1.**

Step 2: Install Linux operating system. Make sure to install GRUB (v0.97 or earlier) MBR type and Ext3 partition type. Leave enough space on the hard drive to create the recover partition later.

**NOTE:**

If the Linux OS is not installed with GRUB (v0.97 or earlier) and Ext3, the Symantec Ghost may not function properly.

While installing Linux OS, please create two partitions:

- Partition 1: /
- Partition 2: **SWAP**

**NOTE:**

Please reserve enough space for partition 3 for saving recovery images.




Figure B-29: Partitions for Linux

Step 3: Create a recovery partition. Insert the recovery CD into the optical disk drive. Follow **Step 1 ~ Step 3** described in **Section B.2.2**. Then type the following commands (marked in red) to create a partition for recovery images.

system32>diskpart

DISKPART>list vol

DISKPART>sel disk 0

```
DISKPART>create part pri size= ____  
DISKPART>assign letter=N  
DISKPART>exit  
system32>format N: /fs:ntfs /q /v:Recovery /y  
system32>exit
```

Step 4: **Build the recovery partition.** Press any key to boot from the recovery CD. It will take a while to launch the recovery tool. Please be patient. When the recovery tool setup menu appears, type <3> and press <Enter> (**Figure B-30**). The Symantec Ghost window appears and starts configuring the system to build a recovery partition. After completing the system configuration, press any key to reboot the system. Eject the recovery CD.




Figure B-30: Manual Recovery Environment for Linux

Step 5: **Access the recovery tool main menu by modifying the “menu.lst”.** To first access the recovery tool main menu, the menu.lst must be modified. In Linux, enter Administrator (root). When prompt appears, type:

```
cd /boot/grub  
vi menu.lst
```

```
Fedora release 9 (Sulphur)
Kernel 2.6.25-14.fc9.i686 on an i686 (tty2)

localhost login: root
Password:
[root@localhost ~]# cd /boot/grub/
[root@localhost grub]# vi menu.lst _
```

Figure B-31: Access menu.lst in Linux (Text Mode)

Step 6: Modify the menu.lst as shown below.

```
#boot=/dev/sda
default=0
timeout=10 ← Modify timeout=10
splashimage=(hd0,0)/grub/splash.xpm.gz
hiddenmenu
title Fedora (2.6.25-14.fc9.i686)
    root (hd0,0)
    kernel /vmlinuz-2.6.25-14.fc9.i686 ro root=UUID=10f1acda-
ac38b5c78910 rhgb quiet
    initrd /initrd-2.6.25-14.fc9.i686.img

title Recovery Partition
root (hd0,2)
makeactive ← Type command
chainloader +1
```

- Type command:
title Recovery Partition
root (hd0,2)
makeactive
chainloader +1

Step 7: The recovery tool menu appears. (Figure B-32)

```
1. Factory Restore
2. Backup system
3. Restore your last backup.
4. Manual
5. Quit
Please type the number to select and then press Enter:
```

Figure B-32: Recovery Tool Menu

Step 8: Create a factory default image. Follow Step 2 ~ Step 12 described in Section B.2.5 to create a factory default image.

B.5 Recovery Tool Functions

After completing the initial setup procedures as described above, users can access the recovery tool by pressing <F3> while booting up the system. However, if the setup procedure in Section B.3 has been completed and the auto recovery function is enabled, the system will automatically restore from the factory default image without pressing the F3 key. The recovery tool main menu is shown below.




Figure B-33: Recovery Tool Main Menu

The recovery tool has several functions including:

1. **Factory Restore:** Restore the factory default image (iei.GHO) created in Section B.2.5.
2. **Backup system:** Create a system backup image (iei_user.GHO) which will be saved in the hidden partition.
3. **Restore your last backup:** Restore the last system backup image
4. **Manual:** Enter the Symantec Ghost window to configure manually.
5. **Quit:** Exit the recovery tool and restart the system.



WARNING:

Please do not turn off the system power during the process of system recovery or backup.



WARNING:

All data in the system will be deleted during the system recovery. Please backup the system files before restoring the system (either Factory Restore or Restore Backup).

B.5.1 Factory Restore

To restore the factory default image, please follow the steps below.

Step 1: Type <1> and press <Enter> in the main menu.

Step 2: The Symantec Ghost window appears and starts to restore the factory default. A factory default image called **iei.GHO** is created in the hidden Recovery partition.




Figure B-34: Restore Factory Default

Step 3: The screen shown in **Figure B-35** appears when completed. Press any key to reboot the system.




Figure B-35: Recovery Complete Window

B.5.2 Backup System

To backup the system, please follow the steps below.

Step 1: Type <2> and press <Enter> in the main menu.

Step 2: The Symantec Ghost window appears and starts to backup the system. A backup image called **iei_user.GHO** is created in the hidden Recovery partition.




Figure B-36: Backup System

Step 3: The screen shown in **Figure B-37** appears when system backup is complete. Press any key to reboot the system.




Figure B-37: System Backup Complete Window

B.5.3 Restore Your Last Backup

To restore the last system backup, please follow the steps below.

Step 1: Type <3> and press <Enter> in the main menu.

Step 2: The Symantec Ghost window appears and starts to restore the last backup image (iei_user.GHO).




Figure B-38: Restore Backup

Step 3: The screen shown in **Figure B-39** appears when backup recovery is complete. Press any key to reboot the system.




Figure B-39: Restore System Backup Complete Window

B.5.4 Manual

To restore the last system backup, please follow the steps below.

Step 1: Type <4> and press <Enter> in the main menu.

Step 2: The Symantec Ghost window appears. Use the Ghost program to backup or recover the system manually.





Figure B-40: Symantec Ghost Window

Step 3: When backup or recovery is completed, press any key to reboot the system.

B.6 Restore Systems from a Linux Server through LAN

The One Key Recovery allows a client system to automatically restore to a factory default image saved in a Linux system (the server) through LAN connectivity after encountering a Blue Screen of Death (BSoD) or a hang for around 10 minutes. To be able to use this function, the client system and the Linux system MUST reside in the same domain.



NOTE:

The supported client OS includes:

- Windows 2000
- Windows XP
- Windows Vista
- Windows 7
- Windows CE
- Windows XP Embedded

Prior to restoring client systems from a Linux server, a few setup procedures are required.

Step 1: Configure DHCP server settings

Step 2: Configure TFTP settings

Step 3: Configure One Key Recovery server settings

Step 4: Start DHCP, TFTP and HTTP

Step 5: Create a shared directory

Step 6: Setup a client system for auto recovery

The detailed descriptions are described in the following sections. In this document, two types of Linux OS are used as examples to explain the configuration process – CentOS 5.5 (Kernel 2.6.18) and Debian 5.0.7 (Kernel 2.6.26).

B.6.1 Configure DHCP Server Settings

Step 1: Install the DHCP

`#yum install dhcp` (CentOS, commands marked in red)

`#apt-get install dhcp3-server` (Debian, commands marked in blue)

Step 2: Confirm the operating system default settings: dhcpd.conf.

CentOS

Use the following command to show the DHCP server sample location:

`#vi /etc/dhcpd.conf`

The DHCP server sample location is shown as below:

```
# DHCP Server Configuration file.
# see /usr/share/doc/dhcp*/dhcpd.conf.sample
```

Use the following command to copy the DHCP server sample to etc/dhcpd.conf:

`#cp /usr/share/doc/dhcp-3.0.5/dhcpd.conf.sample /etc/dhcpd.conf`

`#vi /etc/dhcpd.conf`

```
ddns-update-style interim;
ignore client-updates;

subnet 192.168.0.0 netmask 255.255.255.0 {
# --- default gateway
    option routers                192.168.0.2;
    option subnet-mask            255.255.255.0;

    option nis-domain              "domain.org";
    option domain-name            "domain.org";
    option domain-name-servers    192.168.0.1;
    next-server 192.168.0.6;
    filename "pxelinux.0";
    option time-offset             -18000; # Eastern Standard Time
    option ntp-servers            192.168.1.1;
}
```

Debian

`#vi /etc/dhcpd.conf`

Edit “/etc/dhcpd.conf” for your environment. For example, add

`next-server PXE server IP address;`

```
filename "pxelinux.0";
```

```
ddns-update-style interim;
ignore client-updates;

subnet 192.168.0.0 netmask 255.255.255.0 {

# --- default gateway
    option routers                192.168.0.2;
    option subnet-mask            255.255.255.0;

    option nis-domain              "domain.org";
    option domain-name             "domain.org";
    option domain-name-servers    192.168.0.1;
    next-server 192.168.0.6;
    filename "pxelinux.0";
    option time-offset             -18000; # Eastern Standard time
    option ntp-servers             192.168.1.1;
}
```

B.6.2 Configure TFTP Settings

Step 1: Install the tftp, httpd and syslinux.

```
#yum install tftp-server httpd syslinux (CentOS)
```

```
#apt-get install tftpd-hpa xinetd syslinux (Debian)
```

Step 2: Enable the TFTP server by editing the "/etc/xinetd.d/tftp" file and make it use the remap file. The "-vvv" is optional but it could definitely help on getting more information while running the remap file. For example:

CentOS

```
#vi /etc/xinetd.d/tftp
```

Modify:

```
disable = no
```

```
server_args = -s /tftpboot -m /tftpboot/tftpd.remap -vvv_
```

```
socket_type      = dgram
protocol         = udp
wait            = yes
user            = root
server          = /usr/sbin/in.tftpd
server_args      = -s /tftpboot -m /tftpboot/tftpd.remap -vvv
disable         = no
per_source      = 11
cps             = 100 2
flags           = IPv4
```


Debian

Replace the TFTP settings from “inetd” to “xinetd” and annotate the “inetd” by adding “#”.

`#vi /etc/inetd.conf`

Modify: `#tftp dgram udp wait root /usr/sbin/.....` (as shown below)

```
#:BOOT: TFTP service is provided primarily for booting. Most sites
#      run this only on machines acting as "boot servers."
#tftp  dgram  udp    wait  root  /usr/sbin/in.tftpd /usr/sbin/in.tftpd -s
#      /var/lib/tftpboot
```

`#vi /etc/xinetd.d/tftp`

```
socket_type      = dgram
protocol         = udp
wait             = yes
user             = root
server           = /usr/sbin/in.tftpd
server_args      = -s /tftpboot -m /tftpboot/tftpd.remap -vvv
disable          = no
per_source       = 11
cps              = 100 2
flags            = IPv4
```

B.6.3 Configure One Key Recovery Server Settings

Step 1: Copy the **Utility/RECOVERYR10.TAR.BZ2** package from the One Key Recovery CD to the system (server side).



Step 2: Extract the recovery package to /.

`#cp RecoveryR10.tar.bz2 /`

`#cd /`

`#tar -xvf RecoveryR10.tar.bz2`

Step 3: Copy “pxelinux.0” from “syslinux” and install to “tftboot”.

`#cp /usr/lib/syslinux/pxelinux.0 /tftpboot/`

B.6.4 Start the DHCP, TFTP and HTTP

Start the DHCP, TFTP and HTTP. For example:

CentOS

```
#service xinetd restart
```

```
#service httpd restart
```

```
#service dhcpd restart
```

Debian

```
#!/etc/init.d/xinetd reload
```

```
#!/etc/init.d/xinetd restart
```

```
#!/etc/init.d/dhcp3-server restart
```

B.6.5 Create Shared Directory

Step 1: Install the samba.

```
#yum install samba
```

Step 2: Create a shared directory for the factory default image.

```
#mkdir /share
```

```
#cd /share
```

```
#mkdir /image
```

```
#cp iei.gho /image
```



WARNING:

The file name of the factory default image must be **iei.gho**.

Step 3: Confirm the operating system default settings: smb.conf.

```
#vi /etc/samba/smb.conf
```

Modify:

[image]

comment = One Key Recovery

path = /share/image

browseable = yes

writable = yes

public = yes

create mask = 0644

directory mask = 0755

Step 4: Edit “/etc/samba/smb.conf” for your environment. For example:

```
# "security = user" is always a good idea. This will require a Unix account
# in this server for every user accessing the server. See
# /usr/share/doc/samba-doc/htmldocs/Samba3-HOWTO/ServerType.html
# in the samba-doc package for details.
security = share
```

```
[image]
comment = One Key Recovery
path = /share/image
browseable = yes
writable = yes
public = yes
create mask = 0644
directory mask = 0755
```

Step 5: Modify the hostname

#vi /etc/hostname

Modify: RecoveryServer

```
RecoveryServer
```

B.6.6 Setup a Client System for Auto Recovery

Step 1: Configure the following BIOS options of the client system.

Advanced → iEi Feature → Auto Recovery Function → **Enabled**

Advanced → iEi Feature → Recover from PXE → **Enabled**

Boot → Launch PXE OpROM → **Enabled**

Step 2: Continue to configure the **Boot Option Priorities** BIOS option of the client system:

Boot Option #1 → remain the default setting to boot from the original OS.

Boot Option #2 → select the boot from LAN option.

Step 3: Save changes and exit BIOS menu.

Exit → **Save Changes and Exit**

Step 4: Install the auto recovery utility into the system by double clicking the **Utility/AUTORECOVERY-SETUP.exe** in the One Key Recovery CD. This utility **MUST** be installed in the system, otherwise, the system will automatically restore from the factory default image every ten (10) minutes.




Step 5: Restart the client system from LAN. If the system encounters a Blue Screen of Death (BSoD) or a hang for around 10 minutes, it will automatically restore from the factory default image. The following screens will show when the system starts auto recovering.

```
Realtek PCIe GBE Family Controller Series v2.35 (06/14/10)
CLIENT MAC ADDR: 00 18 7D 13 E6 89  GUID: 00020003-0004-0005-0006-0007000000
DHCP.../
```

```
My IP address seems to be C0A80009 192.168.0.9
ip=192.168.0.9:192.168.0.8:192.168.0.2:255.255.255.0
TFTP prefix:
Trying to load: pxelinux.cfg/00020003-0004-0005-0006-000700080009
Trying to load: pxelinux.cfg/01-00-18-7d-13-e6-89
Trying to load: pxelinux.cfg/C0A80009
Trying to load: pxelinux.cfg/C0A8000
Trying to load: pxelinux.cfg/C0A800
Trying to load: pxelinux.cfg/C0A80
Trying to load: pxelinux.cfg/C0A8
Trying to load: pxelinux.cfg/C0A
Trying to load: pxelinux.cfg/C0
Trying to load: pxelinux.cfg/C
Trying to load: pxelinux.cfg/default
boot:
```

Windows is loading files...

IP: 192.168.0.8, File: \Boot\WinPE.wim



NOTE:

A firewall or a SELinux is not in use in the whole setup process. If there is a firewall or a SELinux protecting the system, modify the configuration information to accommodate them.

B.7 Other Information

B.7.1 Using AHCI Mode or ALi M5283 / VIA VT6421A Controller


When the system uses AHCI mode or some specific SATA controllers such as ALi M5283 or VIA VT6421A, the SATA RAID/AHCI driver must be installed before using one key recovery. Please follow the steps below to install the SATA RAID/AHCI driver.

Step 1: Copy the SATA RAID/AHCI driver to a floppy disk and insert the floppy disk into a USB floppy disk drive. The SATA RAID/AHCI driver must be especially designed for the on-board SATA controller.

Step 2: Connect the USB floppy disk drive to the system.


Step 3: Insert the One Key Recovery CD into the system and boot the system from the CD.

Step 4: When launching the recovery tool, press <F6>.




UPC-V315-NM70 Panel PC

Step 5: When the following window appears, press <S> to select “Specify Additional Device”.



Step 6: In the following window, select a SATA controller mode used in the system. Then press <Enter>. The user can now start using the SATA HDD.



Step 7: After pressing <Enter>, the system will get into the recovery tool setup menu.

Continue to follow the setup procedure from **Step 4** in **Section B.2.2 Create Partitions** to finish the whole setup process.

B.7.2 System Memory Requirement

To be able to access the recovery tool by pressing <F3> while booting up the system, please make sure to have enough system memory. The minimum memory requirement is listed below.

- Using Award BIOS: 128 MB system memory
- Using AMI BIOS: 512 MB system memory.

Appendix

C

Safety Precautions

**WARNING:**

The precautions outlined in this chapter should be strictly followed. Failure to follow these precautions may result in permanent damage to the EP series.

C.1 Safety Precautions

Please follow the safety precautions outlined in the sections that follow:

C.1.1 General Safety Precautions

Please ensure the following safety precautions are adhered to at all times.

- ***Follow the electrostatic precautions*** outlined below whenever the EP series is opened.
- ***Make sure the power is turned off and the power cord is disconnected*** whenever the EP series is being installed, moved or modified.
- ***Do not apply voltage levels that exceed the specified voltage range.*** Doing so may cause fire and/or an electrical shock.
- ***Electric shocks can occur*** if the EP series chassis is opened when the EP series is running.
- ***Do not drop or insert any objects*** into the ventilation openings of the EP series.
- ***If considerable amounts of dust, water, or fluids enter the EP series***, turn off the power supply immediately, unplug the power cord, and contact the EP series vendor.
- **DO NOT:**
 - Drop the EP series against a hard surface.
 - Strike or exert excessive force onto the LCD panel.
 - Touch any of the LCD panels with a sharp object
 - In a site where the ambient temperature exceeds the rated temperature

C.1.2 Anti-static Precautions



WARNING:

Failure to take ESD precautions during the installation of the EP series may result in permanent damage to the EP series and severe injury to the user.

Electrostatic discharge (ESD) can cause serious damage to electronic components, including the EP series. Dry climates are especially susceptible to ESD. It is therefore critical that whenever the EP series is opened and any of the electrical components are handled, the following anti-static precautions are strictly adhered to.

- ***Wear an anti-static wristband:*** Wearing a simple anti-static wristband can help to prevent ESD from damaging any electrical component.
- ***Self-grounding:*** Before handling any electrical component, touch any grounded conducting material. During the time the electrical component is handled, frequently touch any conducting materials that are connected to the ground.
- ***Use an anti-static pad:*** When configuring or working with an electrical component, place it on an anti-static pad. This reduces the possibility of ESD damage.
- ***Only handle the edges of the electrical component:*** When handling the electrical component, hold the electrical component by its edges.

C.1.3 Product Disposal




CAUTION:

Risk of explosion if battery is replaced by an incorrect type. Only certified engineers should replace the on-board battery.

Dispose of used batteries according to instructions and local regulations.

- Outside the European Union - If you wish to dispose of used electrical and electronic products outside the European Union, please contact your local authority so as to comply with the correct disposal method.
- Within the European Union:



EU-wide legislation, as implemented in each Member State, requires that waste electrical and electronic products carrying the mark (left) must be disposed of separately from normal household waste. This includes monitors and electrical accessories, such as signal cables or power cords. When you need to dispose of your display products, please follow the guidance of your local authority, or ask the shop where you purchased the product. The mark on electrical and electronic products only applies to the current European Union Member States.

Please follow the national guidelines for electrical and electronic product disposal.

C.2 Maintenance and Cleaning Precautions

When maintaining or cleaning the EP series, please follow the guidelines below.

C.2.1 Maintenance and Cleaning

Prior to cleaning any part or component of the EP series, please read the details below.

- Except for the LCD panel, never spray or squirt liquids directly onto any other components. To clean the LCD panel, gently wipe it with a piece of soft dry cloth or a slightly moistened cloth.
- The interior of the EP series does not require cleaning. Keep fluids away from the EP series interior.
- Be cautious of all small removable components when vacuuming the EP series.
- Turn the EP series off before cleaning the EP series.
- Never drop any objects or liquids through the openings of the EP series.
- Be cautious of any possible allergic reactions to solvents or chemicals used when cleaning the EP series.
- Avoid eating, drinking and smoking within vicinity of the EP series.

C.2.2 Cleaning Tools

Some components in the EP series may only be cleaned using a product specifically designed for the purpose. In such case, the product will be explicitly mentioned in the cleaning tips. Below is a list of items to use when cleaning the EP series.

- **Cloth** – Although paper towels or tissues can be used, a soft, clean piece of cloth is recommended when cleaning the EP series.
- **Water or rubbing alcohol** – A cloth moistened with water or rubbing alcohol can be used to clean the EP series.
- **Using solvents** – The use of solvents is not recommended when cleaning the EP series as they may damage the plastic parts.
- **Vacuum cleaner** – Using a vacuum specifically designed for computers is one of the best methods of cleaning the EP series. Dust and dirt can restrict the airflow in the EP series and cause its circuitry to corrode.
- **Cotton swabs** - Cotton swaps moistened with rubbing alcohol or water are excellent tools for wiping hard to reach areas.
- **Foam swabs** - Whenever possible, it is best to use lint free swabs such as foam swabs for cleaning.

Appendix

E

Hazardous Materials Disclosure

D.1 Hazardous Material Disclosure Table for IPB Products Certified as RoHS Compliant Under 2002/95/EC Without Mercury

The details provided in this appendix are to ensure that the product is compliant with the Peoples Republic of China (China) RoHS standards. The table below acknowledges the presences of small quantities of certain materials in the product, and is applicable to China RoHS only.

A label will be placed on each product to indicate the estimated “Environmentally Friendly Use Period” (EFUP). This is an estimate of the number of years that these substances would “not leak out or undergo abrupt change.” This product may contain replaceable sub-assemblies/components which have a shorter EFUP such as batteries and lamps. These components will be separately marked.

Please refer to the table on the next page.

Part Name	Toxic or Hazardous Substances and Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (CR(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
Housing	X	O	O	O	O	X
Display	X	O	O	O	O	X
Printed Circuit Board	X	O	O	O	O	X
Metal Fasteners	X	O	O	O	O	O
Cable Assembly	X	O	O	O	O	X
Fan Assembly	X	O	O	O	O	X
Power Supply Assemblies	X	O	O	O	O	X
Battery	O	O	O	O	O	O
<p>O: This toxic or hazardous substance is contained in all of the homogeneous materials for the part is below the limit requirement in SJ/T11363-2006</p> <p>X: This toxic or hazardous substance is contained in at least one of the homogeneous materials for this part is above the limit requirement in SJ/T11363-2006</p>						

UPC-V315-NM70 Panel PC

此附件旨在确保本产品符合中国 RoHS 标准。以下表格标示此产品中某有毒物质的含量符合中国 RoHS 标准规定的限量要求。

本产品上会附有“环境友好使用期限”的标签，此期限是估算这些物质“不会有泄漏或突变”的年限。本产品可能包含有较短的环境友好使用期限的可替换元件，像是电池或灯管，这些元件将会单独标示出来。

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (CR(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
壳体	X	O	O	O	O	X
显示	X	O	O	O	O	X
印刷电路板	X	O	O	O	O	X
金属螺帽	X	O	O	O	O	O
电缆组装	X	O	O	O	O	X
风扇组装	X	O	O	O	O	X
电力供应组装	X	O	O	O	O	X
电池	O	O	O	O	O	O
<p>O: 表示该有毒有害物质在该部件所有物质材料中的含量均在 SJ/T11363-2006 标准规定的限量要求以下。</p> <p>X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T11363-2006 标准规定的限量要求。</p>						