


# **PulM Series**


PulM-10G4SF-XL710




www.ieiworld.com

### **Package Contents**

#### PulM-10G4SF-XL710



### PulM-10G4SF-XL710 Block Diagram




#### LAN LED Status



LED	State	Description
Link (Right)	Yellow	Active
Speed (Left)	Green	10Gbps data rate
	Off	1 Gbps/100Mbps data rate


#### **Hardware Installation**



## **Networking Module Installation**


## Step 1

Use the Torx wrench to remove the two Torx screws.




# Step 2

Remove the slot cover. Save the slot cover screws.



# Step 3

Slide an IEI networking module into the slot until the module is seated in the slot correctly and securely.



# Step 4

Install the previously-removed Torx screws to secure the module to the chassis.

